

1873 CATTLEMAN EL PATRON REVOLVERS - 1873 CATTLEMAN EL PATRON 9MM LUGER 5.5" BBL BLUED

Lightning fast and reliable, shot after shot, you can depend on Uberti's hand-tuned Cattleman model. In the world of single-action revolvers, it is truly the boss, or El Patr?n, as the Vaqueros of the Old West would say. Uberti's factory custom-tuned models have... Color case-hardened or stainless steel frames Numbered cylinders Steel backstraps and trigger guards Checkered walnut grips Wide, easy-view front and rear sights The gunsmiths at Uberti have fitted each El Patr?n with high-grade, U.S.-manufactured Wolff® springs. And each revolver has been carefully tested and certified for fit and function. They are reliable, light, and fast, with a smooth-tuned action. The new El Patr?n Grizzly Paw revolver was designed for large hands (or "grizzly paws"). The same popular El Patr?n revolver is now outfitted with checkered 1860 Army grips will afford large-handed shooters with a positive grip in all weather conditions.



Attributes

- Name: 1873 CATTLEMAN EL PATRON 9MM LUGER 5.5" BBL BLUED
- Manufacturer: UBERTI
- Product no.: 430101613
- Mfr. No.: 345372
- Action Type: Single Action
- Barrel Length: 5.5"
- Capacity: 6-Round
- Cartridge: 9 mm Luger
- Finish: Polished
- Front Sight: Blade
- Length: 11"
- Magazine Included: NA
- Magazine Type: NA
- Make: Uberti
- Model: 1873 Cattleman
- Muzzle: Non-Threaded
- Rear Sight: None
- Stock Material: Walnut
- Weight: NA
- Shipping height: 51mm
- Shipping width: 152mm
- Shipping length: 305mm
- UPC: 037084965437

Item details

US export classification: 0A501.a

Table of Contents

- Startpage
- Deutsch: Sicherheitshinweise für den 1873 CATTLEMAN EL PATRON REVOLVER
- English: Safety Instruction Guide for the 1873 Cattleman El Patrón Revolver

Sicherheitshinweise für den 1873 CATTLEMAN EL PATRON REVOLVER

Einführung

Herzlichen Glückwunsch zum Erwerb des 1873 CATTLEMAN EL PATRON REVOLVERS von Uberti. Dieser Revolver ist ein handgefertigtes Produkt, das für seine Zuverlässigkeit und Leistung bekannt ist. Um sicherzustellen, dass Sie den Revolver sicher und effektiv verwenden, befolgen Sie bitte die folgenden Sicherheitsrichtlinien und Anweisungen.

Allgemeine Sicherheitsrichtlinien

- Verwenden Sie den Revolver nur für den vorgesehenen Zweck.
- Halten Sie den Revolver immer in einem sicheren Zustand, wenn er nicht in Gebrauch ist.
- Bewahren Sie den Revolver an einem sicheren Ort auf, der für Kinder unzugänglich ist.
- Überprüfen Sie vor jeder Benutzung, ob der Revolver sauber und in gutem Zustand ist.
- Tragen Sie immer geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille.
- Informieren Sie sich über die Gesetze und Vorschriften zur Waffenbesitz und Nutzung in Ihrem Land oder Ihrer Region.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Behandeln Sie jede Waffe, als ob sie geladen wäre.
- Richten Sie den Revolver niemals auf etwas, das Sie nicht beabsichtigen zu treffen.
- Betätigen Sie den Abzug nur, wenn Sie bereit sind, zu schießen.
- Halten Sie den Finger vom Abzug, bis Sie bereit sind zu schießen.
- Verwenden Sie nur die empfohlenen Munitionstypen (9mm Luger) für diesen Revolver.
- Achten Sie darauf, dass sich keine Hindernisse im Weg des Geschosses befinden.
- Lassen Sie den Revolver niemals unbeaufsichtigt, insbesondere in der Nähe von Kindern oder unbefugten Personen.

Anweisungen für Installation und Nutzung

1. Vorbereitung:

- Stellen Sie sicher, dass der Revolver nicht geladen ist, bevor Sie ihn handhaben.
- Reinigen Sie den Revolver, um sicherzustellen, dass keine Rückstände von vorherigen Schüssen vorhanden sind.

2. Laden des Revolvers:

- Öffnen Sie den Zylinder und überprüfen Sie, ob keine Patronen vorhanden sind.
- Laden Sie die Munition (6 Round Kapazität) in die Kammern des Zylinders.
- Schließen Sie den Zylinder sicher.

3. Zielen und Schießen:

- Nehmen Sie eine stabile Schießposition ein.
- Richten Sie den Revolver auf das Ziel und überprüfen Sie die Sichtlinie.
- Betätigen Sie den Abzug sanft, um den Schuss abzugeben.

4. Nach dem Schießen:

- Entladen Sie den Revolver, indem Sie den Zylinder öffnen und die verbleibenden Patronen entfernen.
- Reinigen Sie den Revolver nach jedem Gebrauch, um seine Lebensdauer zu verlängern.

Entsorgungsanweisungen

- Entsorgen Sie alle nicht verwendeten oder abgelaufenen Munition gemäß den örtlichen Vorschriften.
- Entsorgen Sie den Revolver nicht in den normalen Müll. Wenden Sie sich an Ihre örtliche Polizeibehörde oder einen autorisierten Waffenhändler für die sichere Entsorgung.

Kontaktinformationen für weitere Unterstützung

Für Sicherheitsanfragen oder weitere Informationen zu Ihrem Produkt wenden Sie sich bitte an den Kundendienst von Uberti oder an die zuständige Behörde in Ihrem Land.

Bitte beachten Sie, dass es wichtig ist, sich über die neuesten Sicherheitsrichtlinien und Rückrufinformationen zu informieren. Halten Sie sich über die EU Safety GatePlattform auf dem Laufenden, um sicherzustellen, dass Ihr Produkt sicher ist.

Safety Instruction Guide for the 1873 Cattleman El Patrón Revolver

Introduction

Thank you for choosing the 1873 Cattleman El Patrón Revolver. This guide provides essential safety instructions to ensure the safe use and handling of your revolver. Please read this document carefully before using your firearm.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep the muzzle pointed in a safe direction at all times.
- Do not place your finger on the trigger until you are ready to shoot.
- Always be aware of your target and what lies beyond it.
- Store firearms securely and out of reach of unauthorized users, particularly children.
- Use appropriate eye and ear protection when shooting.
- Regularly inspect your revolver for any signs of wear or damage.
- Follow all local laws and regulations regarding firearm ownership and use.

Specific Safety Precautions for Use

- Ensure the revolver is unloaded when not in use or when being cleaned.
- Use only the recommended ammunition type (9mm Luger) for your revolver.
- Avoid using damaged or corroded ammunition.
- Do not modify the revolver in any way that could affect its safety or performance.
- If you experience a misfire, keep the muzzle pointed downrange for at least 30 seconds before attempting to clear the malfunction.
- Be cautious of environmental conditions that may affect shooting, such as wet or windy weather.

Instructions for Installation and Usage

1. Loading the Revolver:

- Open the cylinder by pressing the release latch.
- Insert 9mm Luger cartridges into the cylinder chambers.
- Close the cylinder securely before using.

2. Firing the Revolver:

- Ensure the revolver is pointed in a safe direction.
- Cock the hammer to the rear to prepare for firing.
- Place your finger on the trigger only when ready to shoot.
- Squeeze the trigger smoothly to fire the revolver.

3. Unloading the Revolver:

- Open the cylinder by pressing the release latch.
- Eject spent cartridges using the ejector rod.
- Visually and physically check the cylinder to ensure it is empty before storing.

4. Cleaning and Maintenance:

- Regularly clean your revolver to prevent buildup of residues.
- Use a suitable cleaning kit and follow the manufacturer's instructions for cleaning.
- Inspect springs and other components for wear and replace as necessary.

Disposal Instructions

- Dispose of your revolver in accordance with local laws and regulations.
- If you need to dispose of ammunition, contact local authorities for guidance on safe disposal methods.
- Do not discard firearms or ammunition in regular trash.

Contact Information for Further Support

For safety inquiries or further information about your revolver, please contact your local dealer or manufacturer. They can provide you with the necessary support and guidance.

By following these safety instructions, you can ensure a safe and enjoyable experience with your 1873 Cattleman El Patrón Revolver. Always prioritize safety and responsible handling.