

# **T3X HUNTER FLUTED STAINLESS 6.5 CREEDMOOR BOLT-ACTION RIFLE - T3X HUNTER FLUTED SS 6.5 CREEDMOOR 24.3" BBL (1)3 ROUND MAG**

The Tikka T3x Hunter is designed for the shooter who appreciates the warm feel of a wooden stock combined with solid performance. Combines the benefits of both the stainless and fluted barrel options into an all-weather, modern rifle.



## **Attributes**

- Name: T3X HUNTER FLUTED SS 6.5 CREEDMOOR 24.3" BBL (1)3 ROUND MAG
- Manufacturer: TIKKA
- Product no.: 430105433
- Mfr. No.: JRTXA782
- Action Type: Bolt Action
- Barrel Length: 24.3"
- Capacity: 3-Round
- Cartridge: 6.5 Creedmoor
- Finish: Wood Grain
- Front Sight: None
- Length: 44.5"
- Magazine Included: 1 x 3-Round
- Magazine Type: Removable
- Make: Tikka
- Model: T3x Hunter
- Muzzle: Non-Threaded
- Rear Sight: None
- Stock Material: Wood
- Weight: 6.8 lbs
- Delivery weight: 3.901kg
- UPC: 082442897875

## **Item details**

US export classification: 0A501.a

# Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die Tikka T3x Hunter Fluted Stainless 6.5 Creedmoor BoltAction Rifle](#)
- [English: Tikka T3x Hunter Fluted Stainless 6.5 Creedmoor BoltAction Rifle Safety Instructions](#)

# Sicherheitshinweise für die Tikka T3x Hunter Fluted Stainless 6.5 Creedmoor BoltAction Rifle

## Einleitung

Herzlichen Glückwunsch zu Ihrem Kauf des Tikka T3x Hunter Fluted Stainless 6.5 Creedmoor BoltAction Rifle. Dieses Gewehr wurde entwickelt, um Ihnen eine hervorragende Leistung zu bieten. Um sicherzustellen, dass Sie Ihr Gewehr sicher und effektiv nutzen, befolgen Sie bitte die folgenden Sicherheitshinweise.

## Allgemeine Sicherheitsrichtlinien

- Verwenden Sie das Gewehr nur für den vorgesehenen Zweck.
- Halten Sie das Gewehr immer in einem sicheren Zustand.
- Überprüfen Sie vor jedem Gebrauch, ob das Gewehr entladen ist.
- Verwenden Sie immer die richtige Munition für Ihr Gewehr.
- Lagern Sie das Gewehr an einem sicheren Ort, der für Kinder unzugänglich ist.
- Tragen Sie beim Schießen geeignete Schutzbrillen und Ohrenschützer.
- Informieren Sie sich über die geltenden Gesetze und Vorschriften in Ihrem Land oder Ihrer Region.

## Spezifische Sicherheitsvorkehrungen für die Nutzung

- Stellen Sie sicher, dass der Lauf des Gewehrs frei von Hindernissen ist, bevor Sie abdrücken.
- Halten Sie den Abzug nicht gedrückt, während Sie das Gewehr laden oder entladen.
- Zeigen Sie das Gewehr niemals auf eine Person oder ein Tier.
- Achten Sie auf Ihre Umgebung, bevor Sie schießen, um sicherzustellen, dass sich niemand in der Nähe befindet.
- Verwenden Sie keine beschädigte oder abgenutzte Munition.
- Lassen Sie das Gewehr niemals unbeaufsichtigt, insbesondere in der Nähe von Kindern.
- Bei Fehlzündungen warten Sie mindestens 30 Sekunden, bevor Sie das Gewehr öffnen.

## Anweisungen zur Installation und Nutzung

### • Installation:

1. Überprüfen Sie alle Teile des Gewehrs auf Beschädigungen.
2. Stellen Sie sicher, dass das Gewehr vollständig zusammengebaut ist, bevor Sie es verwenden.

### • Nutzung:

1. Stellen Sie sicher, dass das Gewehr entladen ist, bevor Sie es handhaben.
2. Laden Sie das Gewehr gemäß der Herstelleranweisungen.
3. Positionieren Sie das Gewehr stabil und sicher, bevor Sie abdrücken.
4. Nach dem Schießen entladen Sie das Gewehr sofort und reinigen Sie es gemäß den Pflegehinweisen.

## Entsorgungsanweisungen

- Entsorgen Sie leere Patronen und Munition gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Verwenden Sie für die Entsorgung des Gewehrs die empfohlenen Verfahren, um Umweltschäden zu vermeiden.
- Fragen Sie bei Ihrem örtlichen Entsorgungsdienst nach, wie Sie das Gewehr sicher und umweltfreundlich entsorgen können.

## Kontaktinformationen für weitere Unterstützung

Für Fragen oder weitere Informationen zu Sicherheitsrichtlinien und zur Nutzung Ihres Tikka T3x Hunter Fluted Stainless 6.5 Creedmoor BoltAction Rifle wenden Sie sich bitte an den Hersteller oder an autorisierte Verkaufsstellen.

Bitte beachten Sie, dass diese Sicherheitsrichtlinien nicht alle möglichen Risiken abdecken können. Halten Sie sich stets an die besten Praktiken für die Sicherheit beim Schießen und informieren Sie sich regelmäßig über neue Sicherheitsrichtlinien.

# Tikka T3x Hunter Fluted Stainless 6.5 Creedmoor BoltAction Rifle Safety Instructions

## Introduction

Thank you for choosing the Tikka T3x Hunter Fluted Stainless 6.5 Creedmoor BoltAction Rifle. This guide provides essential safety instructions and guidelines to ensure safe and effective use of your rifle. Please read this manual carefully and keep it for future reference.

## General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep the muzzle pointed in a safe direction at all times.
- Ensure the rifle is unloaded when not in use.
- Store the rifle in a secure location, inaccessible to unauthorized users, especially children.
- Use only the correct ammunition for your rifle (6.5 Creedmoor).
- Wear appropriate eye and ear protection when shooting.
- Be aware of your surroundings and ensure a clear line of fire.
- Follow all local laws and regulations regarding firearm use and ownership.

## Specific Safety Precautions for Use

- Before handling the rifle, ensure you are in a safe environment.
- Always check that the rifle is unloaded before cleaning or making adjustments.
- Do not rely on the safety mechanism alone; always follow safe handling practices.
- Avoid distractions while handling or shooting the rifle.
- Be cautious of the rifle's weight (6.8 lbs) and ensure you have a firm grip.
- Do not attempt to modify the rifle or its components.
- Be aware of the potential hazards of shooting, including ricochets and the impact zone.

## Instructions for Installation and Usage

### Installation

- Ensure you have a clean, dry workspace for installation.
- Follow the manufacturer's instructions for any accessories or modifications.
- Check that all components are compatible with the Tikka T3x Hunter model.

### Usage

- To load the rifle, ensure it is pointed in a safe direction.
- Insert the 3round removable magazine into the rifle until it clicks into place.
- Open the bolt to check that the chamber is empty.
- Load one round into the chamber and close the bolt.
- Keep your finger off the trigger until you are ready to shoot.
- To fire, aim at your target, ensure it is safe to shoot, and gently squeeze the trigger.
- After firing, keep the rifle pointed downrange and open the bolt to eject any spent casing.

## Disposal Instructions

- Dispose of the rifle in accordance with local laws and regulations.
- If the rifle is no longer usable, consider contacting a licensed firearms dealer for safe disposal.
- Do not dispose of ammunition in regular waste; follow hazardous waste guidelines for proper disposal.

## Contact Information for Further Support

For any safety inquiries or concerns regarding your Tikka T3x Hunter Fluted Stainless 6.5 Creedmoor BoltAction Rifle, please refer to the official Tikka website or contact your local Tikka dealer for assistance.

**Note:** Always stay informed about product recalls and safety alerts by checking the EU's Safety Gate platform. Report any unsafe products or accidents to the appropriate authorities.

By following these guidelines, you contribute to a safer shooting experience for yourself and others. Enjoy your shooting sessions responsibly!