

## **LOCK-N-LOAD AP SHELLPLATE - #12 LOCK-N-LOAD AP PROGRESSIVE PRESS SHELLPLATE**

Shell plates for Lock-N-Load AP and Pro-Jector are available to fit most calibers. Each shell plate will also hold additional calibers with the same case head dimensions. Current shell plates are designed to fit Lock-N-Load AP (both EZ-Ject and wire ejector models) and Pro-Jector presses. These shell plates require the purchase of the 749-012-552 Hornady Auto press retrofit kit if your press still has the OLD STYLE SPRING TYPE CARTRIDGE CASE EJECTOR SYSTEM. If you have any questions please contact your Sinclair tech 800-717-8211. View Hornady Shellplate Chart.



### **Attributes**

- Name: #12 LOCK-N-LOAD AP PROGRESSIVE PRESS SHELLPLATE
- Manufacturer: HORNADY
- Product no.: 749004981
- Mfr. No.: 392612
- Cartridge: 25 Remington,6.8 mm Remington SPC,30 Remington,32 Remington,224 Valkyrie
- Style: Press Type
- Delivery weight: 0.227kg
- Shipping height: 18mm
- Shipping width: 99mm
- Shipping length: 109mm
- UPC: 090255926125

### **Item details**

Made in USA  
EU Export Disabled

# Table of Contents

- Startpage
- Deutsch: Sicherheitshinweise für die HORNADY LOCKNLOAD AP SHELLPLATE #12
- English: LOCKNLOAD AP SHELLPLATE #12 Safety Instruction Guide

# Sicherheitshinweise für die HORNADY LOCKNLOAD AP SHELLPLATE #12

## Einleitung

Herzlichen Glückwunsch zu Ihrem Kauf der HORNADY LOCKNLOAD AP SHELLPLATE #12. Dieses Produkt ist für die Verwendung mit der LockNLoad AP und ProJector Presse konzipiert. Bitte lesen Sie diese Sicherheitsanweisungen sorgfältig durch, um eine sichere und effektive Nutzung zu gewährleisten.

## Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass das Produkt für Ihr spezifisches Kaliber geeignet ist.
- Verwenden Sie die Shellplate nur mit kompatiblen Pressen, um Sicherheitsrisiken zu vermeiden.
- Halten Sie alle Sicherheits und Bedienungsanleitungen für Ihre Presse bereit und befolgen Sie diese.
- Lagern Sie die Shellplate an einem trockenen, sicheren Ort, der vor Kindern geschützt ist.
- Überprüfen Sie regelmäßig auf Beschädigungen oder Abnutzung, bevor Sie das Produkt verwenden.

## Spezifische Sicherheitsvorkehrungen für die Nutzung

- Verwenden Sie die Shellplate nur mit den empfohlenen Kalibern: 6.8 mm Remington SPC, 30 Remington, 25 Remington, 32 Remington, 224 Valkyrie.
- Stellen Sie sicher, dass die Presse über das aktuelle Ejektorsystem verfügt. Bei älteren Modellen benötigen Sie das Hornady Auto Press RetrofitKit.
- Tragen Sie beim Umgang mit Munition immer geeignete Schutzausrüstung, einschließlich Schutzbrille und Handschuhe.
- Arbeiten Sie in einem gut beleuchteten Bereich, um Fehler zu vermeiden.
- Halten Sie die Arbeitsfläche sauber und frei von Ablenkungen.

## Anweisungen für Installation und Nutzung

### 1. Installation der Shellplate:

- Stellen Sie sicher, dass die Presse ausgeschaltet und von der Stromversorgung getrennt ist.
- Entfernen Sie die alte Shellplate, falls vorhanden, gemäß den Anweisungen des Herstellers.
- Setzen Sie die HORNADY LOCKNLOAD AP SHELLPLATE #12 auf die Presse, bis sie einrastet.
- Überprüfen Sie, ob die Shellplate sicher sitzt, bevor Sie mit der Nutzung beginnen.

### 2. Nutzung:

- Stellen Sie die Presse gemäß den Anweisungen des Herstellers ein.
- Überprüfen Sie vor jedem Ladevorgang, ob die Shellplate korrekt installiert ist.
- Führen Sie den Ladevorgang gemäß den empfohlenen Verfahren für Ihr Kaliber durch.
- Bei Problemen oder ungewöhnlichen Geräuschen während des Betriebs, stoppen Sie sofort die Nutzung und überprüfen Sie die Presse und die Shellplate.

## Entsorgungsanweisungen

- Entsorgen Sie die Shellplate gemäß den örtlichen Vorschriften für Elektroschrott.
- Stellen Sie sicher, dass alle Teile vollständig recycelt oder sicher entsorgt werden, um Umweltschäden zu vermeiden.

## Kontaktinformationen für weitere Unterstützung

Für Fragen oder weitere Unterstützung wenden Sie sich bitte an einen qualifizierten Techniker oder den Hersteller. Beachten Sie, dass Sie auch Informationen zu Rückrufen und Sicherheitswarnungen auf der EU Safety Gate Plattform finden können.

Bitte beachten Sie, dass Sie alle Sicherheitsrichtlinien befolgen sollten, um die sichere Nutzung der HORNADY LOCKNLOAD AP SHELLPLATE #12 zu gewährleisten. Bei Fragen oder Unsicherheiten sollten Sie sich immer an einen Fachmann wenden.

# LOCKNLOAD AP SHELLPLATE #12 Safety Instruction Guide

## Introduction

Thank you for choosing the LOCKNLOAD AP SHELLPLATE #12. This product is designed for use with the LockNLoad AP and ProJector progressive presses. To ensure safe and effective use, please read this safety instruction guide carefully. It includes important information regarding product safety, usage precautions, installation instructions, and disposal guidelines.

## General Safety Guidelines

- Ensure that the product is used only for its intended purpose, as specified in this manual.
- Always handle the shell plate with care to prevent injury or damage.
- Keep the shell plate out of reach of children and vulnerable individuals.
- Regularly inspect the shell plate for any signs of wear or damage before use.
- If you notice any defects or malfunctions, discontinue use immediately and consult a qualified technician.
- Always follow local regulations regarding the use of reloading equipment.

## Specific Safety Precautions for Use

- Always use the shell plate with compatible cartridges as specified in the product description.
- Ensure that your press is equipped with the necessary retrofit kit if it has the old style spring type cartridge case ejector system.
- Avoid wearing loose clothing or jewelry that may get caught in the machinery during operation.
- Always ensure that the work area is clean and free of obstructions.
- Do not exceed the recommended load limits for your press and shell plate.
- Use appropriate personal protective equipment (PPE) such as safety glasses when reloading.
- Be aware of your surroundings and ensure that no unauthorized persons are in the vicinity while operating the press.

## Instructions for Installation and Usage

### 1. Installation

- Ensure that your LockNLoad AP or ProJector press is turned off and unplugged.
- Remove any existing shell plate from the press.
- Align the new LOCKNLOAD AP SHELLPLATE #12 with the mounting points on the press.
- Secure the shell plate in place according to the manufacturer's instructions.
- If you have the old style spring type cartridge case ejector system, install the 749012552 Hornady Auto press retrofit kit before proceeding.

### 2. Usage

- Load the appropriate cartridges into the shell plate, ensuring they fit securely.
- Follow the operating instructions for your press to begin reloading.
- Monitor the operation closely for any unusual sounds or movements.
- Once reloading is complete, safely remove the shell plate and store it in a safe location.

## Disposal Instructions

- Dispose of the shell plate in accordance with local regulations for electronic and mechanical waste.
- Do not dispose of the shell plate in regular household waste.
- Contact your local waste management authority for guidance on proper disposal methods.

## Contact Information for Further Support

For any inquiries regarding safety, product usage, or technical support, please contact your authorized distributor or manufacturer. Ensure that you have the product details and any relevant information ready to assist in addressing your concerns.

By following these guidelines, you can ensure the safe and effective use of the LOCKNLOAD AP SHELLPLATE #12. Stay informed about any updates or recalls related to this product through the EU's Safety Gate platform. Thank you for prioritizing safety in your reloading activities.