

LOCK-N-LOAD CASE FEEDER & ACCESSORIES - SMALL RIFLE CASE FEEDER PLATE

With Hornadys high volume Lock-N-Load® Case Feeder, the Lock-N-Load® AP™ just got faster. It has the highest torque motor in the industry and an extra large case bowl that makes it possible to load over 500 rounds of high quality ammunition per hour, depending on experience and proficiency. The Lock-N-Load® Case Feeder comes complete with everything you need except the case feeder plates, which are sold separately. Adapts to your Lock-N-Load AP Press Change overs are easy, usually take about 5 minutes



Attributes

- Name: SMALL RIFLE CASE FEEDER PLATE
- Manufacturer: HORNADY
- Product no.: 749012544
- Mfr. No.: 095314
- Delivery weight: 0.703kg
- Shipping height: 762mm
- Shipping width: 315mm
- Shipping length: 325mm
- UPC: 090255953145

Item details

Made in USA
EU Export Disabled

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für den HORNADY LOCKNLOAD CASE FEEDER & ACCESSORIES](#)
- [English: LOCKNLOAD CASE FEEDER & ACCESSORIES SMALL RIFLE CASE FEEDER PLATE Safety Instruction Guide](#)

Sicherheitshinweise für den HORNADY LOCKNLOAD CASE FEEDER & ACCESSORIES

Einführung

Herzlichen Glückwunsch zum Kauf des HORNADY LOCKNLOAD CASE FEEDER! Dieses Produkt wurde entwickelt, um die Effizienz beim Laden von Munition zu erhöhen. Um sicherzustellen, dass du das Produkt sicher und effektiv verwendest, befolge bitte die folgenden Sicherheitsrichtlinien.

Allgemeine Sicherheitsrichtlinien

- Achte darauf, dass das Produkt nur für den vorgesehenen Zweck verwendet wird.
- Halte den Arbeitsplatz sauber und ordentlich, um Unfälle zu vermeiden.
- Verwende geeignete persönliche Schutzausrüstung, wie z.B. Schutzbrille und Handschuhe.
- Bewahre das Produkt außerhalb der Reichweite von Kindern auf.
- Überprüfe regelmäßig alle Teile des Geräts auf Abnutzung oder Beschädigung.
- Melde unsichere Produkte oder Unfälle den zuständigen Behörden.

Spezifische Sicherheitsvorkehrungen für die Benutzung

- Verwende das Gerät nur mit der LockNLoad AP Presse.
- Achte darauf, dass alle Teile ordnungsgemäß montiert und sicher befestigt sind.
- Belade die Hülsenwanne nicht über die empfohlene Kapazität hinaus.
- Vermeide es, während des Betriebs des Case Feeders deine Hände in die Nähe beweglicher Teile zu bringen.
- Stelle sicher, dass der Case Feeder auf einer stabilen, ebenen Fläche steht.
- Beachte die Anweisungen zur Verwendung der Hülsenfütterplatten, die separat erhältlich sind.

Anweisungen für Installation und Nutzung

1. Installation:

- Stelle sicher, dass die LockNLoad AP Presse ausgeschaltet und vom Stromnetz getrennt ist.
- Montiere den Case Feeder gemäß den beiliegenden Montageanleitungen.
- Überprüfe, ob alle Schrauben und Verbindungen fest angezogen sind.

2. Benutzung:

- Fülle die Hülsenwanne mit den entsprechenden Hülsen.
- Schalte den Motor des Case Feeders ein und beobachte den Betrieb.
- Achte darauf, dass die Hülsen gleichmäßig und ohne Blockaden nach unten fallen.
- Bei Störungen oder Blockaden, schalte das Gerät sofort aus und behebe das Problem.

Entsorgungsanweisungen

- Entsorge das Produkt gemäß den örtlichen Vorschriften für Elektro und Elektronikschrott.
- Entferne alle Batterien oder andere Energiequellen, bevor du das Produkt entsorgst.
- Informiere dich über lokale Entsorgungsstellen, die für die Entsorgung elektronischer Geräte zuständig sind.

Kontaktinformationen für weitere Unterstützung

Für weitere Informationen oder Unterstützung wende dich bitte an den Kundendienst von HORNADY. Stelle sicher, dass du die Modellnummer und andere relevante Informationen bereithältst, um eine schnelle und effiziente Unterstützung zu erhalten.

Vielen Dank, dass du dich für den HORNADY LOCKNLOAD CASE FEEDER entschieden hast. Beachte diese Sicherheitsrichtlinien, um eine sichere und effiziente Nutzung zu gewährleisten.

LOCKNLOAD CASE FEEDER & ACCESSORIES

SMALL RIFLE CASE FEEDER PLATE Safety

Instruction Guide

Introduction

Thank you for choosing the Hornady LOCKNLOAD Case Feeder & Accessories Small Rifle Case Feeder Plate. This product is designed to enhance your reloading experience by providing a highvolume, efficient method of feeding cases into your reloading press. To ensure safe and effective use, please read and follow the safety guidelines outlined in this manual.

General Safety Guidelines

- Ensure safe use of the LOCKNLOAD Case Feeder by following these general safety guidelines:
 - Always read and understand the user manual before operating the product.
 - Keep the product out of reach of children and vulnerable individuals.
 - Inspect the equipment regularly for any signs of wear or damage.
 - Use the product only for its intended purpose; do not modify or alter it.
 - Store the product in a dry and secure location when not in use.
 - Follow all local regulations regarding the use and storage of ammunition.

Specific Safety Precautions for Use

- Before using the LOCKNLOAD Case Feeder, observe the following safety precautions:
 - Ensure that the case feeder is properly installed on the LockNLoad AP Press before operation.
 - Do not overload the case bowl beyond its capacity.
 - Always keep hands and clothing clear of moving parts during operation.
 - Do not attempt to clear jams or obstructions while the machine is running.
 - Use appropriate personal protective equipment (PPE) such as safety glasses and gloves.
 - Be aware of your surroundings and ensure that the work area is clean and free of hazards.

Instructions for Installation and Usage

Installation

1. Unpack the Product:

- Carefully remove the LOCKNLOAD Case Feeder and its components from the packaging.
- Check for any visible damage or missing parts.

2. Attach the Case Feeder to the LockNLoad AP Press:

- Align the case feeder with the mounting points on the press.
- Securely fasten the feeder using the provided hardware.

3. Install the Case Feeder Plate:

- Select the appropriate case feeder plate for your specific caliber (sold separately).
- Follow the instructions provided with the plate for proper installation.

Usage

1. Load Cases:

- Fill the case bowl with clean, dry cases.
- Ensure that the cases are compatible with the selected feeder plate.

2. Start the Operation:

- Turn on the LockNLoad AP Press and the case feeder.
- Monitor the feeding process to ensure smooth operation.

3. Adjust Settings as Needed:

- Make any necessary adjustments to the feeder settings for optimal performance.
- Refer to the press manual for guidance on adjustments.

4. End Operation:

- Once you have finished reloading, turn off the equipment.
- Clear any remaining cases from the feeder bowl.

Disposal Instructions

- Dispose of the LOCKNLOAD Case Feeder and its components responsibly:
 - Follow local regulations for the disposal of electronic equipment.
 - Recycle any metal parts where possible.
 - Never dispose of ammunition or reloading components in regular trash.

Contact Information for Further Support

For any inquiries regarding safety, usage, or support for the LOCKNLOAD Case Feeder, please refer to the product packaging or visit the manufacturer's website for additional resources.

By adhering to these safety instructions, you can ensure a safe and efficient reloading experience with the Hornady LOCKNLOAD Case Feeder and Accessories. Always prioritize safety and stay informed about best practices in reloading.