

American Rifle Predator - w/ Cheekriser - .308 Win.

Ruger American Rifle Predator

The Ruger American Rifle Predator combines cutting-edge innovation with Ruger's renowned reliability. Manufactured 100% in the USA, this bolt-action rifle offers exceptional precision and handling.

- **Ergonomic Stock:** Lightweight synthetic stock with a classic design, modern forend styling, and textured grip areas for superior control.
- **Adjustable Trigger:** The Ruger Marksman Adjustable Trigger is externally adjustable between 1.4 and 2.3 kg (3–5 lbs), with the adjustment key securely stored in the bolt.
- **Versatile Performance:** Ideal for hunting and precision shooting under various conditions.

Attributes

- Name: RUGER - American Rifle Predator - w/ Cheekriser - .308 Win.
- Manufacturer: RUGER
- Product no.: BRD113084
- Mfr. No.: 17903528
- Barrel Finish: Matte Black
- Barrel Length: 18"
- Caliber: .308 Winchester
- Capacity: 4-Round
- Color: Moss Green
- Length: 38"
- Make: Ruger
- Material: Alloy Steel
- Model: American Predator
- Muzzle Threads: 5/8-24
- Side: Right
- Twist Rate: 1-10
- Weight: 6.23 lbs
- Delivery weight: 2.8kg
- Shipping height: 200mm
- Shipping width: 25mm
- Shipping length: 965mm

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die Ruger American Rifle Predator](#)
- [English: Ruger American Rifle Predator Safety Instruction Guide](#)

Sicherheitshinweise für die Ruger American Rifle Predator

Einführung

Herzlichen Glückwunsch zu Ihrem Kauf der Ruger American Rifle Predator! Diese Anleitung bietet wichtige Sicherheitsinformationen, um sicherzustellen, dass Sie Ihr Produkt sicher und verantwortungsbewusst verwenden. Bitte lesen Sie die folgenden Hinweise sorgfältig durch.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass Sie die Waffe nur in einem sicheren und kontrollierten Umfeld verwenden.
- Bewahren Sie die Waffe immer entladen und in einem sicheren Behälter auf, wenn sie nicht in Gebrauch ist.
- Halten Sie die Waffe von Kindern und unbefugten Personen fern.
- Überprüfen Sie vor jeder Benutzung den Zustand der Waffe und der Munition.
- Informieren Sie sich über die örtlichen Gesetze und Vorschriften zur Verwendung von Feuerwaffen.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Verwenden Sie nur die empfohlene Munition (.308 Win) für Ihre Ruger American Rifle Predator.
- Achten Sie darauf, dass der Lauf nicht verstopft ist, bevor Sie einen Schuss abgeben.
- Halten Sie den Abzug nicht gedrückt, wenn Sie nicht bereit sind zu schießen.
- Stellen Sie sicher, dass sich keine Personen oder Tiere im Schussfeld befinden.
- Tragen Sie immer geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille.

Anweisungen zur Installation und Nutzung

1. Montage der Zieloptik:

- Verwenden Sie die mitgelieferte WeaverSchiene zur Montage Ihrer Zieloptik.
- Stellen Sie sicher, dass die Optik sicher und fest montiert ist, bevor Sie die Waffe verwenden.

2. Laden des Magazins:

- Nehmen Sie das herausnehmbare Magazin und laden Sie es mit bis zu 4 Schuss .308 Win Munition.
- Stellen Sie sicher, dass das Magazin korrekt in die Waffe eingesetzt ist, bevor Sie die Waffe benutzen.

3. Sicherheitsmechanismus:

- Verwenden Sie die Schiebesicherung am Kolbenhals, um die Waffe in einem sicheren Zustand zu halten, wenn Sie nicht schießen.
- Überprüfen Sie immer die Position der Sicherung, bevor Sie die Waffe benutzen.

4. Abzugseinstellung:

- Der MarksmanAbzug ist verstellbar. Stellen Sie sicher, dass Sie ihn auf Ihre Vorlieben einstellen, um ein sauberes Schussgefühl zu gewährleisten.

Entsorgungsanweisungen

- Entsorgen Sie leere Munition und andere Abfälle gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Verwenden Sie geeignete Recycling und Entsorgungsmethoden für die Waffe, wenn sie nicht mehr benötigt wird.

Kontaktinformationen für weitere Unterstützung

Für weitere Informationen oder bei Fragen zu Sicherheitsanliegen, wenden Sie sich bitte an den Hersteller oder an autorisierte Händler. Achten Sie darauf, alle Sicherheitsrichtlinien zu befolgen und die Waffe verantwortungsbewusst zu nutzen.

Vielen Dank, dass Sie sich für die Ruger American Rifle Predator entschieden haben. Genießen Sie Ihr Schießen und bleiben Sie sicher!

Ruger American Rifle Predator Safety Instruction Guide

Introduction

Thank you for choosing the Ruger American Rifle Predator. This guide provides essential safety instructions to ensure the safe and effective use of your rifle. Please read this guide thoroughly before using the product. Your safety and the safety of others are our top priority.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep the muzzle pointed in a safe direction at all times.
- Ensure that your finger is off the trigger until you are ready to shoot.
- Be aware of your target and what lies beyond it.
- Use appropriate eye and ear protection when shooting.
- Store firearms securely and out of reach of children and unauthorized users.
- Regularly inspect your rifle for any signs of wear or damage.
- Follow all local laws and regulations regarding firearm ownership and use.

Specific Safety Precautions for Use

- **Handling:** Always handle your rifle with care. Avoid any sudden movements that could lead to accidental discharge.
- **Loading and Unloading:**
 - Ensure the rifle is pointed in a safe direction.
 - Keep the safety engaged until you are ready to fire.
 - Load and unload the rifle in a safe area, free from distractions.
- **Shooting:**
 - Use only the recommended ammunition for your rifle (.308 Winchester).
 - Be mindful of your surroundings and ensure a clear shooting area.
 - Do not shoot at hard surfaces or water, as this can cause ricochets.
- **Cleaning and Maintenance:**
 - Follow the manufacturer's instructions for cleaning and maintenance.
 - Always ensure the rifle is unloaded before cleaning.
 - Use appropriate cleaning materials and tools.

Instructions for Installation and Usage

- **Installation of Cheekriser:**
 - Ensure the rifle is unloaded before installation.
 - Align the cheekriser with the stock and secure it using the provided screws.
 - Check that the cheekriser is firmly attached before use.
- **Adjusting the Trigger:**
 - The Ruger Marksman Adjustable Trigger can be adjusted between 1.4 and 2.3 kg (3–5 lbs).
 - Use the adjustment key stored in the bolt to make adjustments.
 - Test the trigger after adjustments to ensure proper functionality.
- **Using the Rifle:**
 - Familiarize yourself with the safety features and controls of the rifle.
 - Practice loading and unloading in a safe environment.
 - Start with small targets to improve accuracy and confidence.

Disposal Instructions

- Dispose of your rifle in accordance with local laws and regulations.
- If the rifle is no longer usable, consider contacting a licensed firearms dealer for safe disposal.
- Do not dispose of ammunition in regular trash. Follow local guidelines for hazardous waste disposal.

Contact Information for Further Support

For any questions or concerns regarding the Ruger American Rifle Predator, please refer to your local Ruger dealer or visit the Ruger website for additional resources and support.

Conclusion

By following these safety instructions, you can ensure a safe and enjoyable experience with your Ruger American Rifle Predator. Always prioritize safety and seek assistance if you are unsure about any aspect of firearm handling or usage. Thank you for your commitment to responsible firearm ownership.