

# McMillan Fiberglass Sporter Stock, 10/22

## McMillan Fiberglass Sporter Stock, 10/22

A standard style hunting stock with a Monte Carlo comb and ambidextrous cheekpiece. This stock will fit right or left-handed shooters. Designed to accept 0.925" bull barrel. A forend pressure pad is also installed. Manufactured by McMillan Fiberglass Stocks for Volquartsen Firearms.

## Attributes

- Name: McMillan Fiberglass Sporter Stock, 10/22
- Manufacturer: VOLQUARTSEN
- Product no.: BRD231050
- Mfr. No.: VC10TS-10
- Color: Black
- Length Of Pull: 13.5"
- Make: Ruger
- Model: 10/22
- Delivery weight: 1.3kg
- UPC: 810162011666

# Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für den McMillan Fiberglass Sporter Stock, 10/22](#)
- [English: McMillan Fiberglass Sporter Stock, 10/22 Safety Instruction Guide](#)

# Sicherheitshinweise für den McMillan Fiberglass Sporter Stock, 10/22

## Einführung

Herzlichen Glückwunsch zu Ihrem Kauf des McMillan Fiberglass Sporter Stocks für die Ruger 10/22. Dieser Schaft wurde entwickelt, um eine komfortable und präzise Schießerfahrung zu bieten. Bitte lesen Sie diese Sicherheitshinweise sorgfältig durch, um sicherzustellen, dass Sie das Produkt sicher und effektiv verwenden.

## Allgemeine Sicherheitsrichtlinien

- Achten Sie darauf, dass das Produkt für den vorgesehenen Gebrauch geeignet ist.
- Verwenden Sie den Schaft nur mit der Ruger 10/22.
- Halten Sie den Schaft und alle damit verbundenen Teile außerhalb der Reichweite von Kindern.
- Überprüfen Sie regelmäßig auf Abnutzung oder Beschädigungen.
- Bei Unsicherheiten wenden Sie sich an einen Fachmann oder den Hersteller.

## Spezifische Sicherheitsvorkehrungen für die Nutzung

- Verwenden Sie den Schaft nur in einem sicheren und kontrollierten Umfeld.
- Tragen Sie stets geeignete Schutzausrüstung, einschließlich Gehörschutz und Augenschutz.
- Achten Sie darauf, dass der Schaft korrekt montiert ist, bevor Sie ihn verwenden.
- Überprüfen Sie regelmäßig die Schrauben und Verbindungen auf Festigkeit.
- Verwenden Sie den Schaft nicht, wenn Sie Anzeichen von Beschädigungen feststellen.

## Anweisungen zur Installation und Nutzung

### 1. Installation des Schaftes:

- Stellen Sie sicher, dass Sie alle Teile des Schaftes und der Waffe haben.
- Entfernen Sie die alte Schaftkappe von der Ruger 10/22.
- Setzen Sie die Waffe vorsichtig in den neuen Schaft ein.
- Befestigen Sie den Schaft mit den mitgelieferten Schrauben und stellen Sie sicher, dass alles fest sitzt.

### 2. Verwendung des Schaftes:

- Stellen Sie sicher, dass die Waffe entladen ist, bevor Sie den Schaft verwenden.
- Nehmen Sie eine bequeme Haltung ein, wenn Sie schießen.
- Achten Sie darauf, dass die Waffe immer in eine sichere Richtung zeigt.

## Entsorgungsanweisungen

- Entsorgen Sie den Schaft und alle Teile gemäß den örtlichen Vorschriften.
- Bringen Sie nicht mehr benötigte Teile zu einer autorisierten Sammelstelle für gefährliche Abfälle.
- Informieren Sie sich über lokale Recyclingmöglichkeiten für Kunststoffe und andere Materialien.

## Kontaktinformationen für weitere Unterstützung

Für Fragen oder weitere Informationen zu Ihrem Produkt, wenden Sie sich bitte an den Hersteller oder den Einzelhändler, bei dem Sie das Produkt erworben haben.

Bitte beachten Sie, dass Sie auch unsichere Produkte oder Vorfälle den zuständigen Behörden melden sollten. Überprüfen Sie regelmäßig die Rückrufupdates auf der EUSicherheitsplattform, um über mögliche Risiken informiert zu bleiben.

# McMillan Fiberglass Sporter Stock, 10/22 Safety Instruction Guide

## Introduction

Thank you for choosing the McMillan Fiberglass Sporter Stock for your Ruger 10/22. This product is designed to enhance your shooting experience while ensuring safety during use. Please read this safety instruction guide carefully to understand how to use, install, and dispose of the stock safely, in compliance with the EU General Product Safety Regulation (GPSR).

## General Safety Guidelines

- Always treat your firearm and accessories as if they are loaded.
- Ensure that you are in a safe environment when handling your firearm.
- Keep the stock and firearm out of reach of children and unauthorized persons.
- Regularly inspect the stock for any signs of damage or wear.
- Follow all local laws and regulations regarding firearms and accessories.
- Report any unsafe products or accidents to the relevant authorities.
- Check for recall updates on the EU's Safety Gate platform.

## Specific Safety Precautions for Use

- Ensure that the stock is properly installed before using your firearm.
- Use only compatible firearms with the McMillan Fiberglass Sporter Stock.
- Always wear appropriate safety gear, including eye and ear protection, when shooting.
- Avoid using the stock in extreme weather conditions, which may affect performance.
- Be cautious when adjusting the cheekpiece to avoid pinching or injury.
- Do not modify the stock in any way that may compromise its integrity or safety.

## Instructions for Installation and Usage

### Installation Instructions

1. **Prepare the Work Area:** Ensure you have a clean, dry workspace. Lay out all tools and components needed for installation.
2. **Remove the Existing Stock:**
  - Unload your firearm and ensure it is safe to handle.
  - Remove the action from the existing stock according to the manufacturer's instructions.
3. **Install the McMillan Fiberglass Sporter Stock:**
  - Position the action into the new stock.
  - Align the action with the stock's inlet and ensure it fits snugly.
  - Secure the action using the provided screws, ensuring they are tightened to the manufacturer's specifications.
4. **Adjust the Cheekpiece:**
  - If necessary, adjust the cheekpiece to fit your shooting style.
  - Ensure it is securely locked in place before use.
5. **Final Inspection:**
  - Check that all components are securely fastened and that there are no loose parts.
  - Inspect the stock for any visible damage.

### Usage Instructions

- Always ensure your firearm is unloaded before handling.
- When ready to shoot, assume a proper shooting stance.
- Use the stock to support your aim and maintain control of the firearm.
- After use, clean the stock with a damp cloth to remove dirt and moisture.

## Disposal Instructions

- Dispose of the McMillan Fiberglass Sporter Stock in accordance with local regulations.
- If the stock is damaged beyond repair, consider recycling the materials where possible.
- Do not dispose of the stock in regular household waste.

## **Contact Information for Further Support**

For any safety inquiries or additional support regarding the McMillan Fiberglass Sporter Stock, please refer to the product packaging or the manufacturer's website for contact details. It is essential to have access to support for any safety concerns or product issues.

By following these instructions and guidelines, you can ensure a safe and enjoyable experience with your McMillan Fiberglass Sporter Stock. Thank you for prioritizing safety and responsible firearm use.