

Summit Rifle, 22 LR Magpul Stock Black

The Volquartsen Summit bolt action is based on a concept originally developed by Primary Weapons Systems. The Volquartsen Summit represents the combination of their innovative design and 40+ years of our own rimfire experience,

Designed for both competition shooting as well as small game hunting, this unique rifle is a straight-pull bolt action inspired by the 10/22 style platform. The CNC-machined receiver features an integral 20 MOA Picatinny Rail, making it the perfect rifle for any rimfire long range shooting.

This innovative design is built for everyone from the junior just getting into shooting to the accomplished competitor. It features everything you could ask for.

Attributes

- Name: Summit Rifle, 22 LR Magpul Stock Black
- Manufacturer: VOLQUARTSEN
- Product no.: BRD231154
- Mfr. No.: VCB-LR-B
- Action Type: Bolt Action
- Barrel Finish: Carbon
- Caliber: .22lr
- Color: Black
- Length Of Pull: 12.5" - 14.5"
- Make: Ruger
- Model: Summit
- Muzzle Threads: 1/2-28
- Rounds: 10-Round
- Twist Rate: 1-16
- Delivery weight: 2.7kg
- UPC: 810162017330

Item details

EU Export Disabled

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die Volquartsen Summit Repetierbüchse](#)
- [English: Safety Instruction Guide for the Summit Rifle, 22 LR Magpul Stock](#)

Sicherheitshinweise für die Volquartsen Summit Repetierbüchse

Einleitung

Herzlichen Glückwunsch zu Ihrem Kauf der Volquartsen Summit Repetierbüchse! Dieses Gewehr wurde mit Blick auf höchste Sicherheit und Leistung entwickelt. Bitte lesen Sie diese Sicherheitshinweise sorgfältig durch, um sicherzustellen, dass Sie das Produkt sicher und verantwortungsbewusst verwenden.

Allgemeine Sicherheitsrichtlinien

- Verwenden Sie das Gewehr nur für den vorgesehenen Zweck, der im Benutzerhandbuch beschrieben ist.
- Halten Sie das Gewehr immer in einem sicheren Zustand, auch wenn es nicht verwendet wird.
- Bewahren Sie das Gewehr an einem sicheren Ort auf, der für Kinder und unbefugte Personen unzugänglich ist.
- Tragen Sie beim Schießen immer geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille.
- Überprüfen Sie vor jeder Verwendung, ob das Gewehr in einwandfreiem Zustand ist. Achten Sie auf Anzeichen von Abnutzung oder Beschädigung.
- Melden Sie unsichere Produkte oder Unfälle den zuständigen Behörden.

Besondere Sicherheitsvorkehrungen für die Verwendung

- Stellen Sie sicher, dass Sie mit dem Gewehr vertraut sind, bevor Sie es verwenden. Lesen Sie das Benutzerhandbuch gründlich.
- Verwenden Sie nur die empfohlenen Munitionstypen (.22 LR) für dieses Gewehr.
- Achten Sie darauf, dass sich keine Personen in der Schussbahn befinden, bevor Sie das Gewehr abfeuern.
- Halten Sie den Abzug nicht gedrückt, während Sie das Gewehr laden oder entladen.
- Verwenden Sie das Gewehr niemals unter dem Einfluss von Alkohol oder Drogen.
- Achten Sie darauf, dass das Mündungsgewinde (1/228) nicht beschädigt ist, bevor Sie Zubehör montieren.

Anweisungen für Installation und Verwendung

- **Installation der Schiene:**
 - Überprüfen Sie, ob die integrierte 20 MOA Picatinny-Schiene sauber und frei von Schmutz ist.
 - Montieren Sie die Schiene gemäß den Anweisungen im Benutzerhandbuch.
- **Laden des Gewehrs:**
 - Überprüfen Sie, ob das Gewehr entladen ist, bevor Sie Munition einlegen.
 - Führen Sie die Munition vorsichtig in das Magazin ein, bis es vollständig geladen ist.
- **Abfeuern des Gewehrs:**
 - Stellen Sie sicher, dass das Gewehr sicher auf das Ziel ausgerichtet ist.
 - Drücken Sie den Abzug sanft, um den Schuss abzugeben.
- **Entladen des Gewehrs:**
 - Entfernen Sie das Magazin und überprüfen Sie, ob sich eine Patrone im Lauf befindet.
 - Entladen Sie das Gewehr, indem Sie den Bolzen zurückziehen und die Patrone herausnehmen.

Entsorgungsanweisungen

- Entsorgen Sie leere Patronen und Munition gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Stellen Sie sicher, dass das Gewehr vor der Entsorgung entladen ist.
- Kontaktieren Sie lokale Behörden oder Entsorgungsdienste, um Informationen zur sicheren Entsorgung zu erhalten.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder Unterstützung im Zusammenhang mit der Volquartsen Summit Repetierbüchse wenden Sie sich bitte an den Hersteller oder einen autorisierten Händler. Es ist wichtig, dass Sie bei Sicherheitsanfragen immer einen Fachmann konsultieren.

Bitte beachten Sie, dass diese Sicherheitshinweise dazu dienen, Ihre Sicherheit und die Sicherheit anderer zu gewährleisten. Die Einhaltung dieser Richtlinien ist entscheidend für den sicheren und verantwortungsvollen Umgang mit Ihrem Gewehr.

Safety Instruction Guide for the Summit Rifle, 22 LR Magpul Stock

Introduction

Thank you for choosing the Summit Rifle, 22 LR Magpul Stock. This guide provides essential safety instructions to ensure the safe use of your rifle. Please read this document carefully before using the product, and keep it for future reference.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep the rifle pointed in a safe direction at all times.
- Ensure the rifle is not loaded when not in use.
- Store the rifle in a secure location, out of reach of children and unauthorized users.
- Use only the specified caliber of ammunition for your rifle (.22 LR).
- Wear appropriate eye and ear protection while shooting.
- Be aware of your surroundings and ensure that the shooting area is clear of people and obstacles.
- Do not modify the rifle or use any accessories not recommended by the manufacturer.
- Regularly inspect the rifle for signs of wear or damage before use.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- **Children and Vulnerable Users:**
 - Keep firearms and ammunition out of reach of children.
 - Ensure that inexperienced users are supervised by a knowledgeable adult.
- **Handling:**
 - Always keep your finger off the trigger until you are ready to shoot.
 - Do not engage the safety mechanism unless you are preparing to shoot.
- **Shooting Environment:**
 - Ensure that you are in a designated shooting area.
 - Be mindful of backstops and ensure that no one is downrange when shooting.
- **Ammunition:**
 - Only use highquality, factorymanufactured ammunition.
 - Avoid using damaged or corroded ammunition.

Instructions for Installation and Usage

1. Installation:

- Ensure that the rifle is unloaded before installation.
- Follow the manufacturer's instructions for attaching any accessories.
- Verify that all components are securely fastened before use.

2. Usage:

- Load the rifle by inserting the magazine into the receiver until it clicks into place.
- Ensure the safety is engaged before loading the ammunition.
- To fire, disengage the safety and gently squeeze the trigger while maintaining a firm grip on the rifle.
- After firing, keep the rifle pointed in a safe direction and engage the safety before unloading.

3. Maintenance:

- Clean the rifle regularly to ensure proper functioning.
- Use only recommended cleaning products and tools.
- Store the rifle in a cool, dry place when not in use.

Disposal Instructions

- Dispose of the rifle in accordance with local laws and regulations.
- If the rifle is no longer usable, consult with a local firearms dealer or law enforcement for safe disposal options.
- Dispose of ammunition responsibly by following local hazardous waste disposal guidelines.

Contact Information for Further Support

For any safety inquiries or concerns regarding your Summit Rifle, please contact your local authorized dealer or the manufacturer directly. Ensure that you have your product details ready for a more efficient response.

By following these guidelines, you can ensure a safe and enjoyable experience with your Summit Rifle. Always prioritize safety and responsibility when handling firearms.