

Summit Rifle, 22 LR Magpul Stock Flat Dark Earth

The Volquartsen Summit bolt action is based on a concept originally developed by Primary Weapons Systems. The Volquartsen Summit represents the combination of their innovative design and 40+ years of our own rimfire experience,

Designed for both competition shooting as well as small game hunting, this unique rifle is a straight-pull bolt action inspired by the 10/22 style platform. The CNC-machined receiver features an integral 20 MOA Picatinny Rail, making it the perfect rifle for any rimfire long range shooting.

This innovative design is built for everyone from the junior just getting into shooting to the accomplished competitor. It features everything you could ask for.

Attributes

- Name: Summit Rifle, 22 LR Magpul Stock Flat Dark Earth
- Manufacturer: VOLQUARTSEN
- Product no.: BRD231157
- Mfr. No.: VCB-LR-FDE
- Action Type: Bolt Action
- Barrel Finish: Carbon
- Caliber: .22lr
- Color: Flat Dark Earth, FDE
- Length Of Pull: 12.5" - 14.5"
- Make: Ruger
- Model: Summit
- Muzzle Threads: 1/2-28
- Rounds: 10-Round
- Twist Rate: 1-16
- Delivery weight: 2.7kg
- UPC: 810162017385

Item details

EU Export Disabled

Table of Contents

- Startpage
- Deutsch: Sicherheitsanweisungen für die Volquartsen Summit Repetierbüchse
- English: Consumer Safety Instruction Guide for the Summit Rifle, 22 LR Magpul Stock

Sicherheitsanweisungen für die Volquartsen Summit Repetierbüchse

Einführung

Herzlichen Glückwunsch zu Ihrem Kauf der Volquartsen Summit Repetierbüchse! Dieses Produkt wurde mit höchster Sorgfalt und unter Berücksichtigung der neuesten Sicherheitsstandards entwickelt. Bitte lesen Sie diese Sicherheitsanweisungen sorgfältig durch, um sicherzustellen, dass Sie das Gewehr sicher und verantwortungsvoll verwenden.

Allgemeine Sicherheitsrichtlinien

- Verwenden Sie das Gewehr nur für den vorgesehenen Zweck, d.h. für Wettkampfschießen und Niederwildjagd.
- Halten Sie das Gewehr immer in einem sicheren Zustand. Behandeln Sie es so, als ob es immer geladen wäre.
- Bewahren Sie das Gewehr in einem sicheren, verschlossenen Ort auf, wenn es nicht in Gebrauch ist.
- Halten Sie den Abzug nicht gedrückt, während Sie das Gewehr laden oder entladen.
- Verwenden Sie nur die vom Hersteller empfohlenen Munitionstypen.
- Achten Sie darauf, dass Sie in einem sicheren Bereich schießen, der von Menschen und Tieren ferngehalten wird.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Verwenden Sie immer Gehörschutz und Schutzbrillen, wenn Sie das Gewehr benutzen.
- Stellen Sie sicher, dass sich keine Personen im Schussfeld befinden, bevor Sie abdrücken.
- Überprüfen Sie vor jedem Schuss, ob sich Hindernisse oder andere Personen im Schussfeld befinden.
- Lassen Sie das Gewehr niemals unbeaufsichtigt, insbesondere nicht in der Nähe von Kindern.
- Informieren Sie sich über die Gesetze und Vorschriften in Ihrem Land oder Ihrer Region bezüglich des Schießens und des Besitzes von Feuerwaffen.

Anweisungen zur Installation und Nutzung

1. Vorbereitung:

- Überprüfen Sie, ob das Gewehr in einwandfreiem Zustand ist.
- Stellen Sie sicher, dass Sie alle Teile und Zubehörteile gemäß den Anweisungen des Herstellers haben.

2. Laden des Gewehrs:

- Stellen Sie sicher, dass der Sicherheitshebel in der „Sicher“Position ist.
- Fügen Sie die Munition in das Magazin ein und setzen Sie das Magazin in das Gewehr ein.
- Überprüfen Sie, ob das Gewehr sicher und korrekt geladen ist.

3. Abschuss:

- Richten Sie das Gewehr auf das Ziel, während Sie sich in einer stabilen Haltung befinden.
- Betätigen Sie den Abzug sanft, um einen Schuss abzugeben.
- Nach dem Schuss, überprüfen Sie das Gewehr und laden Sie gegebenenfalls nach.

4. Entladen des Gewehrs:

- Stellen Sie sicher, dass der Sicherheitshebel in der „Sicher“Position ist.
- Entfernen Sie das Magazin und lassen Sie die verbleibende Patrone im Lauf aus.
- Überprüfen Sie das Gewehr visuell, um sicherzustellen, dass es entladen ist.

Entsorgungsanweisungen

- Entsorgen Sie leere Patronen und Munition gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Entsorgen Sie das Gewehr nicht in den normalen Müll. Wenden Sie sich an autorisierte Rücknahmestellen oder Recyclingzentren.
- Halten Sie alle Teile des Gewehrs von Kindern und unbefugten Personen fern, bis sie sicher entsorgt sind.

Kontaktinformationen für weitere Unterstützung

Für weitere Informationen oder Unterstützung wenden Sie sich bitte an den Hersteller oder einen autorisierten Fachhändler. Achten Sie darauf, alle Sicherheitsvorkehrungen zu befolgen, wenn Sie Fragen oder Bedenken haben.

Schlussfolgerung

Die Sicherheit hat oberste Priorität. Durch die Beachtung dieser Sicherheitsanweisungen können Sie sicherstellen, dass Sie und andere sicher bleiben, während Sie die Volquartsen Summit Repetierbüchse verwenden. Denken Sie daran, dass verantwortungsbewusster Umgang mit Feuerwaffen sowohl eine persönliche als auch eine gesellschaftliche Verantwortung ist.

Consumer Safety Instruction Guide for the Summit Rifle, 22 LR Magpul Stock

Introduction

Thank you for choosing the Summit Rifle, 22 LR Magpul Stock. This guide provides essential safety instructions and guidelines to ensure the safe use of your rifle. It is important to read and understand these instructions before using the product to minimize risks and ensure compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always treat the rifle as if it is loaded, even if you believe it is not.
- Keep the rifle pointed in a safe direction at all times.
- Store the rifle in a secure location, out of reach of children and unauthorized users.
- Use appropriate eye and ear protection when shooting.
- Familiarize yourself with local laws and regulations regarding the use and ownership of firearms.
- Regularly inspect the rifle for any signs of damage or wear.
- Do not modify the rifle in any way that could compromise its safety or performance.
- Ensure that you are mentally and physically fit to handle a firearm.

Specific Safety Precautions for Use

- Ensure that the safety mechanism is engaged until you are ready to fire.
- Always check the chamber to confirm that it is clear before loading or unloading the rifle.
- Use only the recommended ammunition for your rifle (.22 LR).
- Avoid using the rifle under the influence of alcohol or drugs.
- Be aware of your surroundings and ensure a clear shooting area.
- Do not shoot at hard surfaces or water, as ricochets may occur.
- If a misfire occurs, wait at least 30 seconds before attempting to clear the chamber.

Instructions for Installation and Usage

Installation

- Ensure that you are in a safe and secure environment before handling the rifle.
- Follow the manufacturer's guidelines for attaching any accessories or modifications.
- Check that all components are securely fastened before use.

Usage

- To load the rifle:
 - Ensure the rifle is pointed in a safe direction.
 - Open the bolt and visually inspect the chamber to ensure it is clear.
 - Insert the magazine into the magazine well until it clicks into place.
 - Pull the bolt back and release it to chamber a round.
- To fire the rifle:
 - Ensure the safety is disengaged.
 - Aim at your target and gently squeeze the trigger.
- To unload the rifle:
 - Point the rifle in a safe direction.
 - Open the bolt to eject any chambered rounds.
 - Remove the magazine and ensure no rounds are left in the chamber.

Disposal Instructions

- Dispose of the rifle in accordance with local laws and regulations.
- Do not dispose of the rifle in regular household waste.
- Contact local authorities or a licensed firearms dealer for safe disposal options.

Contact Information for Further Support

For safety inquiries or concerns regarding your Summit Rifle, please refer to your local authorized dealer or manufacturer's website for assistance.

By following these safety guidelines and instructions, you can help ensure a safe and enjoyable experience with your Summit Rifle, 22 LR Magpul Stock. Always prioritize safety and responsibility when handling firearms.