

VF Mainspring for Ruger Pistols, 22/45 - Stainless - Ruger - MKII, MKIII

VF Mainspring for Ruger Pistols, 22/45

**Complete mainspring assembly designed for the Ruger MKII or MKIII.
Mainspring components are wire EDM-cut and CNC-machined.**

Our mainspring does not feature the lock feature found on the Ruger factory MKIII
Mainspring.

Attributes

- Name: VF Mainspring for Ruger Pistols, 22/45 - Stainless - Ruger - MKII, MKIII
- Manufacturer: VOLQUARTSEN
- Product no.: BRD231511
- Mfr. No.: VC3MSR-45-S
- Color: Stainless
- Make: Ruger
- Model: MKII, MKIII
- Delivery weight: 400g
- UPC: 810162013486

Table of Contents

- Startpage
- Deutsch: Sicherheitshinweise für den VF Mainspring für Ruger Pistolen, 22/45
- English: VF Mainspring for Ruger Pistols Safety Instruction Guide

Sicherheitshinweise für den VF Mainspring für Ruger Pistolen, 22/45

Einführung

Herzlichen Glückwunsch zu Ihrem Kauf des VF Mainspring für Ruger Pistolen, 22/45. Dieses Produkt wurde entwickelt, um die Leistung Ihrer Ruger MKII oder MKIII Pistole zu verbessern. Bitte lesen Sie diese Sicherheitshinweise sorgfältig durch, um sicherzustellen, dass Sie das Produkt sicher und effektiv nutzen.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass das Produkt für Ihre spezifische Pistole geeignet ist.
- Verwenden Sie das Produkt nur gemäß den Anweisungen.
- Halten Sie das Produkt außerhalb der Reichweite von Kindern.
- Überprüfen Sie regelmäßig auf Anzeichen von Verschleiß oder Beschädigung.
- Melden Sie unsichere Produkte oder Unfälle den zuständigen Behörden.
- Überprüfen Sie regelmäßig die Rückrufupdates auf der Safety Gate Plattform der EU.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Verwenden Sie nur die von Ruger empfohlenen Teile und Zubehörteile.
- Achten Sie darauf, dass die Feder korrekt installiert ist, um Verletzungen oder Schäden zu vermeiden.
- Tragen Sie beim Arbeiten an Ihrer Pistole geeignete Schutzausrüstung, wie z.B. Schutzbrille.
- Arbeiten Sie in einem gut beleuchteten und sicheren Bereich.
- Lassen Sie die Pistole immer entladen, bevor Sie Wartungsarbeiten durchführen.

Anweisungen zur Installation und Nutzung

1. Vorbereitung

- Stellen Sie sicher, dass die Pistole entladen ist.
- Legen Sie alle notwendigen Werkzeuge bereit.

2. Installation

- Entfernen Sie die alte Mainspring gemäß den Anweisungen Ihres Ruger Handbuchs.
- Setzen Sie die neue VF Mainspring in die Pistole ein und stellen Sie sicher, dass sie fest sitzt.
- Überprüfen Sie die Installation auf korrekte Ausrichtung.

3. Nutzung

- Nach der Installation sollten Sie die Pistole sicher testen, um sicherzustellen, dass alles ordnungsgemäß funktioniert.
- Führen Sie regelmäßige Wartungsprüfungen durch, um die Sicherheit und Leistung der Pistole zu gewährleisten.

Entsorgungsanweisungen

- Entsorgen Sie das Produkt gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Stellen Sie sicher, dass alle Teile sicher und verantwortungsbewusst entsorgt werden, um Umweltschäden zu vermeiden.

Kontaktinformationen für weitere Unterstützung

Für weitere Informationen oder Unterstützung zu Ihrem Produkt stehen Ihnen verschiedene Ressourcen zur Verfügung. Bitte beachten Sie die Informationen, die in der Produktverpackung oder auf der Website des Herstellers bereitgestellt werden.

Vielen Dank, dass Sie sich für den VF Mainspring für Ruger Pistolen, 22/45 entschieden haben. Ihre Sicherheit und Zufriedenheit sind uns wichtig!

VF Mainspring for Ruger Pistols Safety Instruction Guide

Introduction

Thank you for choosing the VF Mainspring for Ruger Pistols, 22/45. This guide provides essential safety instructions and information to ensure the safe use of your mainspring assembly designed for the Ruger MKII and MKIII models. Please read this guide carefully before installation and use.

General Safety Guidelines

- Ensure that all safety precautions are followed during installation and use.
- Always handle firearms responsibly and in accordance with local laws and regulations.
- Keep the mainspring and all firearm components out of reach of children and unauthorized users.
- Regularly check the mainspring for any signs of wear or damage before use.
- Report any unsafe product experiences to the appropriate authorities.

Specific Safety Precautions for Use

- Do not use the mainspring if it appears damaged or defective.
- Always wear appropriate safety gear, including eye protection, when handling firearms.
- Ensure that the firearm is unloaded before performing any maintenance or installation of the mainspring.
- Avoid using excessive force during installation to prevent damage to the mainspring or firearm.
- Do not modify the mainspring or any associated components; modifications can lead to unsafe conditions.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is completely unloaded.
- Gather all necessary tools for installation, including a screwdriver and any other required equipment.

2. Installation:

- Remove the grip panels of the Ruger MKII or MKIII to access the mainspring housing.
- Carefully remove the existing mainspring from the housing.
- Install the VF Mainspring by placing it into the housing in the correct orientation.
- Reassemble the grip panels, ensuring all screws are tightened securely.

3. Usage:

- After installation, perform a function check to ensure the firearm operates correctly.
- Follow the manufacturer's guidelines for the safe operation of your Ruger pistol.
- Regularly inspect the mainspring for any signs of wear or damage before each use.

Disposal Instructions

- Dispose of the mainspring responsibly at a designated recycling or hazardous waste facility.
- Do not dispose of the mainspring in regular household waste.
- Ensure that all components are disposed of in accordance with local regulations.

Contact Information for Further Support

For any questions regarding the VF Mainspring for Ruger Pistols or to report any safety concerns, please contact the manufacturer or your local dealer for assistance.

Thank you for prioritizing safety and responsible firearm handling.