

OFFSET SCOUT MOUNT M-LOK - MIDWEST INDUSTRIES M-LOK OFFSET SCOUT MOUNT

[Shooting Accessories](#) > [Flashlights & Accessories](#) > [Flashlight Mounts](#)

Offset Scout Mount for Surefire M300 and M600 series lights. Designed to offset mount for very comfortable use Constructed of 6061 aluminum hard coat anodized 100% Made in the U.S.A. Lifetime Warranty



Attributes

- Name: [MIDWEST INDUSTRIES M-LOK OFFSET SCOUT MOUNT](#)
- Manufacturer: [MIDWEST INDUSTRIES](#)
- Product no.: 100061581
- Mfr. No.: MI-MLSSLM
- Finish: Black Anodized
- Style: M-LOK
- Delivery weight: 0.026kg
- Shipping height: 6mm
- Shipping width: 76mm
- Shipping length: 203mm
- UPC: 816537015024

Item details

Made in USA

Table of Contents

- Startpage
- OFFSET SCOUT MOUNT MLOK Safety Instruction Guide
- About Us

OFFSET SCOUT MOUNT MLOK Safety Instruction Guide

Introduction

Thank you for choosing the OFFSET SCOUT MOUNT MLOK by MIDWEST INDUSTRIES. This guide provides essential safety instructions to ensure the safe and effective use of your product. Please read this guide carefully before installation and use.

General Safety Guidelines

- The OFFSET SCOUT MOUNT MLOK is designed for use with Surefire M300 and M600 series lights. Ensure compatibility before installation.
- Always inspect the mount and light for any damage before use. Do not use if any components are damaged.
- Keep this product out of reach of children and unauthorized users.
- Be aware of your surroundings when using mounted lights, as they can illuminate areas unexpectedly.
- Follow all local laws and regulations regarding the use of mounted lights.

Specific Safety Precautions for Use

- Ensure the mount is securely fastened to your firearm or equipment before use.
- Avoid using the mount in extreme conditions (e.g., heavy rain, extreme temperatures) unless specified by the manufacturer.
- Do not modify or alter the OFFSET SCOUT MOUNT MLOK in any way. Unauthorized modifications may compromise safety and functionality.
- When not in use, store the mount in a dry and safe location to prevent damage.
- Always use the mount as intended. Do not use it for applications other than those specified by the manufacturer.

Instructions for Installation and Usage

1. Installation:

- Ensure that your firearm is unloaded and pointed in a safe direction before installation.
- Identify the MLOK slots on your firearm where the OFFSET SCOUT MOUNT will be installed.
- Align the mount with the MLOK slots and insert the screws provided.
- Tighten the screws securely using the appropriate tool; do not overtighten.
- Confirm that the mount is stable and does not move when pulled or shaken.

2. Usage:

- Attach your Surefire M300 or M600 series light to the OFFSET SCOUT MOUNT according to the manufacturer's instructions.
- Test the light to ensure it operates correctly once installed.
- Adjust the angle of the light as needed for optimal illumination.

Disposal Instructions

- Dispose of the OFFSET SCOUT MOUNT MLOK according to local regulations regarding aluminum and electronic waste.
- Do not dispose of the product in regular household waste.
- Consider recycling the product if possible.

Contact Information for Further Support

For any safety inquiries or support regarding the OFFSET SCOUT MOUNT MLOK, please refer to the contact information provided by the manufacturer. Always ensure you have the latest updates and information regarding safety recalls and product advisories.

Conclusion

Your safety is our priority. By following these guidelines, you can ensure the safe use of the OFFSET SCOUT MOUNT MLOK. Stay informed about product safety and enjoy your experience with our product.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk