

LOCK-N-LOAD SONIC CLEANER 2L - BASKET ONLY

Lock-N-Load Sonic Cleaner 2L lets you clean up to three hundred .223 cases simultaneously with ultrasonic microjet action. Cleans outside and inside of cases, including primer pockets, and gets into tiny crevices on gun parts or other small metal objects. Featuring an 80-watt ceramic heater that for quick job turnaround. Extra baskets available separately. Intended for use only with Hornady Sonic Cleaner solutions.



Attributes

- Name: LOCK-N-LOAD SONIC CLEANER 2L - BASKET ONLY
- Manufacturer: HORNADY
- Product no.: 100010330
- Mfr. No.: 150206
- Delivery weight: 0.068kg
- Shipping height: 76mm
- Shipping width: 206mm
- Shipping length: 231mm
- UPC: 090255502060

Item details

EU Export Disabled

Table of Contents

- Startpage
- Deutsch: Sicherheitshinweise für den HORNADY LockNLoad Sonic Cleaner 2L
- English: LOCKNLOAD SONIC CLEANER SAFETY INSTRUCTIONS

Sicherheitshinweise für den HORNADY LockNLoad Sonic Cleaner 2L

Einführung

Herzlichen Glückwunsch zum Erwerb des HORNADY LockNLoad Sonic Cleaner 2L! Dieses Gerät ermöglicht eine effektive Reinigung von .223 Hülsen und anderen kleinen Metallobjekten. Bitte lesen Sie die folgenden Sicherheitshinweise sorgfältig durch, um eine sichere und effektive Nutzung zu gewährleisten.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass das Gerät nur für den vorgesehenen Zweck verwendet wird.
- Halten Sie das Gerät außerhalb der Reichweite von Kindern.
- Verwenden Sie das Gerät nicht, wenn es beschädigt oder defekt ist.
- Achten Sie darauf, dass das Gerät auf einer stabilen, ebenen Fläche steht.
- Lesen Sie alle Anweisungen und Warnungen vor der Verwendung sorgfältig durch.
- Verwenden Sie nur die empfohlenen Hornady Sonic Cleaner Lösungen.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Verwenden Sie das Gerät nicht in der Nähe von Wasser oder feuchten Umgebungen.
- Berühren Sie das Gerät nicht mit nassen Händen.
- Lassen Sie das Gerät niemals unbeaufsichtigt, während es in Betrieb ist.
- Verwenden Sie Schutzhandschuhe, wenn Sie mit Reinigungsflüssigkeiten umgehen.
- Achten Sie darauf, dass die Lüftungsöffnungen des Geräts nicht blockiert sind.
- Überprüfen Sie regelmäßig die Kabel und Stecker auf Beschädigungen.

Anweisungen für Installation und Nutzung

1. Aufstellung des Geräts

- Stellen Sie das Gerät auf eine stabile, trockene Oberfläche.
- Stellen Sie sicher, dass das Gerät in der Nähe einer Steckdose positioniert ist.

2. Vorbereitung der Reinigungslösung

- Füllen Sie den Behälter des Sonic Cleaners mit der empfohlenen Hornady Sonic Cleaner Lösung.
- Achten Sie darauf, die maximale Füllmenge nicht zu überschreiten.

3. Befüllen des Korbs

- Platzieren Sie die zu reinigenden Hülsen gleichmäßig im Korb.
- Vermeiden Sie eine Überfüllung, um eine optimale Reinigung zu gewährleisten.

4. Betrieb des Geräts

- Schließen Sie das Gerät an die Stromquelle an.
- Stellen Sie die gewünschte Reinigungszeit ein.
- Drücken Sie den Startknopf, um den Reinigungsprozess zu beginnen.

5. Nach der Reinigung

- Warten Sie, bis das Gerät vollständig abgekühlt ist, bevor Sie den Korb herausnehmen.
- Entleeren Sie die Reinigungsflüssigkeit gemäß den Entsorgungsanweisungen.

Entsorgungsanweisungen

- Entsorgen Sie die gebrauchte Reinigungsflüssigkeit gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Das Gerät selbst sollte am Ende seiner Lebensdauer in einer geeigneten Recyclingstelle für Elektrogeräte entsorgt werden.

Kontaktinformationen für weitere Unterstützung

Für weitere Informationen oder Unterstützung wenden Sie sich bitte an den Hersteller oder den Händler, bei dem Sie das Produkt erworben haben.

Bitte beachten Sie, dass die Sicherheit des Benutzers und die ordnungsgemäße Verwendung des Geräts höchste Priorität haben. Bei Fragen oder Bedenken zögern Sie nicht, Hilfe in Anspruch zu nehmen.

LOCKNLOAD SONIC CLEANER SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the LockNLoad Sonic Cleaner 2L. This device is designed to provide efficient cleaning for your firearm cases and small metal objects using ultrasonic microjet action. To ensure safe usage and optimal performance, please read this safety instruction guide carefully.

General Safety Guidelines

- Ensure the product is used only for its intended purpose.
- Keep the device out of reach of children and vulnerable individuals.
- Always follow the manufacturer's instructions and recommendations.
- Regularly check for updates on product recalls or safety alerts via the EU Safety Gate platform.
- Report any unsafe products or accidents to local authorities.

Specific Safety Precautions for Use

- Do not operate the cleaner without the appropriate Hornady Sonic Cleaner solutions.
- Avoid direct contact with the cleaning solutions; they may be harmful if ingested or if they come into contact with skin.
- Ensure the device is placed on a stable, flat surface during operation.
- Never immerse the device in water or other liquids.
- Do not use the cleaner in damp or wet conditions.
- Always unplug the device when not in use or before cleaning.
- If the device shows signs of damage or malfunction, discontinue use immediately and contact the manufacturer.

Instructions for Installation and Usage

1. Setup

- Place the LockNLoad Sonic Cleaner on a stable, flat surface away from water and direct sunlight.
- Ensure that the power cord is not damaged and is properly connected to a suitable power outlet.

2. Filling the Tank

- Pour the recommended Hornady Sonic Cleaner solution into the tank up to the indicated fill line.
- Do not exceed the maximum fill line to avoid overflow during operation.

3. Loading the Basket

- Place your cases or small metal objects into the basket, ensuring they are not overcrowded to allow for effective cleaning.
- Ensure that primer pockets and crevices are accessible for optimal cleaning.

4. Operating the Device

- Close the lid securely before starting the cleaning cycle.
- Plug in the device and turn it on using the designated power switch.
- Select the appropriate cleaning time based on the manufacturer's recommendations for the items being cleaned.
- Wait for the cleaning cycle to complete. The device will automatically turn off once the cycle is finished.

5. After Cleaning

- Carefully remove the basket from the tank, allowing any excess solution to drain back into the tank.
- Rinse the cleaned items with water, if required, and dry them thoroughly before use.
- Empty and clean the tank regularly to maintain performance.

Disposal Instructions

- Dispose of used cleaning solutions in accordance with local regulations.
- Do not pour cleaning solutions down the drain unless specified as safe by local authorities.
- Recycle the device and its components according to local electronic waste disposal guidelines.

Contact Information for Further Support

For additional support or inquiries, please refer to the manufacturer's contact details provided with your product. Always ensure that you have the product's model number and purchase details available when seeking assistance.

Thank you for your attention to these safety instructions. Enjoy using your LockNLoad Sonic Cleaner 2L responsibly and safely!