

LOCK-N-LOAD RIFLE BULLET FEEDER - 22 CALIBER BULLET FEEDER

The Hornady Lock-N-Load® Rifle Bullet Feeder is designed for the Lock-N-Load® AP™ reloading press. The Bullet Feeder Die is case activated; the bullet will only feed upon contact with the case. A single station is used to feed, seat and crimp the bullet. Sold as a complete unit for 22 caliber bullets, a conversion kit for 30 caliber bullets is also available, giving the reloader the versatility to load the two most popular calibers. The 30 caliber conversion kit will accommodate cartridge sizes from 300 Savage through 300 Rem Ultra Mag. Plus, it's compatible with other presses and uses the industry standard 7/8"-14 die threads.



Attributes

- Name: 22 CALIBER BULLET FEEDER
- Manufacturer: HORNADY
- Product no.: 100014810
- Mfr. No.: 095340
- Delivery weight: 7.416kg
- Shipping height: 401mm
- Shipping width: 305mm
- Shipping length: 495mm
- UPC: 090255953404

Item details

EU Export Disabled

Table of Contents

- Startpage
- Deutsch: Sicherheitshinweise für den LockNLoad Rifle Bullet Feeder Hornady
- English: LOCKNLOAD RIFLE BULLET FEEDER 22 CALIBER Safety Instruction Guide

Sicherheitshinweise für den LockNLoad Rifle Bullet Feeder Hornady

Einführung

Vielen Dank, dass Sie sich für den Hornady LockNLoad® Rifle Bullet Feeder entschieden haben. Dieses Produkt wurde entwickelt, um Ihnen beim Wiederladen von 22 Kaliber Kugeln zu helfen. Um die Sicherheit während der Verwendung zu gewährleisten, lesen Sie bitte diese Sicherheitshinweise sorgfältig durch.

Allgemeine Sicherheitsrichtlinien

- Verwenden Sie das Produkt nur für den vorgesehenen Zweck.
- Überprüfen Sie vor der Verwendung, ob das Produkt in einwandfreiem Zustand ist.
- Halten Sie das Produkt von Kindern und anderen unbefugten Personen fern.
- Tragen Sie beim Umgang mit Munition immer geeignete Schutzausrüstung, einschließlich Schutzbrille und Gehörschutz.
- Informieren Sie sich über die örtlichen Gesetze und Vorschriften zur Verwendung von Wiederladegeräten und Munition.

Besondere Sicherheitsvorkehrungen bei der Verwendung

- Stellen Sie sicher, dass der Bullet Feeder korrekt an der LockNLoad® AP™ Presse installiert ist, bevor Sie mit dem Laden beginnen.
- Vermeiden Sie es, den Bullet Feeder zu überlasten. Laden Sie nur die empfohlene Menge an Kugeln.
- Achten Sie darauf, dass sich keine Fremdkörper im Bullet Feeder befinden, die den Betrieb stören könnten.
- Verwenden Sie nur die empfohlenen Kaliber und Munitionstypen, um sicherzustellen, dass das Produkt ordnungsgemäß funktioniert.
- Überprüfen Sie regelmäßig den Bullet Feeder auf Abnutzung oder Beschädigungen.

Anweisungen zur Installation und Verwendung

Installation

1. Stellen Sie sicher, dass die LockNLoad® AP™ Presse ausgeschaltet und von der Stromquelle getrennt ist.
2. Montieren Sie den Bullet Feeder gemäß den beiliegenden Anweisungen.
3. Überprüfen Sie die Befestigungen und stellen Sie sicher, dass alles fest sitzt.
4. Schließen Sie den Bullet Feeder an die Presse an.

Verwendung

1. Füllen Sie den Bullet Feeder mit 22 Kaliber Kugeln.
2. Aktivieren Sie den Bullet Feeder, indem Sie eine Patrone in die Presse einführen.
3. Überwachen Sie den Ladevorgang und stellen Sie sicher, dass die Kugeln gleichmäßig zugeführt werden.
4. Beenden Sie den Ladevorgang, indem Sie die Presse ausschalten und den Bullet Feeder leeren.

Entsorgungsanweisungen

- Entsorgen Sie alle nicht mehr benötigten Teile und Verpackungen gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Achten Sie darauf, dass Sie keine gefährlichen Materialien in den regulären Müll werfen.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder Anliegen zu diesem Produkt wenden Sie sich bitte an den Hersteller oder den Händler, bei dem Sie das Produkt erworben haben. Sie sollten in der Lage sein, Ihnen die benötigte Unterstützung zu bieten.

Bitte beachten Sie, dass es wichtig ist, alle Sicherheitsrichtlinien und Anweisungen zu befolgen, um eine sichere und effektive Nutzung des Hornady LockNLoad® Rifle Bullet Feeders zu gewährleisten. Achten Sie darauf, regelmäßig auf Rückrufinformationen zu prüfen und melden Sie unsichere Produkte oder Vorfälle den zuständigen Behörden.

LOCKNLOAD RIFLE BULLET FEEDER 22 CALIBER

Safety Instruction Guide

Introduction

Thank you for choosing the Hornady LockNLoad® Rifle Bullet Feeder. This guide provides essential safety instructions and guidelines to ensure the safe and effective use of your bullet feeder. Please read this document carefully before using the product.

General Safety Guidelines

- Ensure you are familiar with the operation of the LockNLoad® AP™ reloading press before using the bullet feeder.
- Always follow the manufacturer's instructions for installation and use.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the bullet feeder for any signs of wear or damage.
- Use only Hornady approved components and accessories with this product.
- In case of malfunction or damage, discontinue use immediately and consult a qualified technician.
- Report any unsafe products or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Always wear appropriate eye protection when operating the bullet feeder.
- Ensure your work area is clean, well lit, and free from distractions.
- Do not attempt to modify or alter the bullet feeder in any way.
- Only load the bullet feeder with 22 caliber bullets or compatible components as specified.
- Be cautious when handling bullets and reloading materials, as they may pose risks if mishandled.
- Never leave the bullet feeder unattended while in use.
- Ensure that the bullet feeder is securely mounted to the reloading press before operation.
- Follow the manufacturer's guidelines for the use of the 30 caliber conversion kit.

Instructions for Installation and Usage

Installation

1. **Unboxing:** Carefully remove the bullet feeder from the packaging and inspect for any damage.
2. **Mounting:** Securely attach the bullet feeder to the LockNLoad® AP™ reloading press using the provided hardware. Ensure it is stable and properly aligned.
3. **Setup:** Follow the instructions provided with the bullet feeder die to set up the die in the press.
4. **Adjustment:** Adjust the bullet feeder die to ensure proper alignment with the cases being reloaded.

Usage

1. **Loading Bullets:** Load 22 caliber bullets into the feeder according to the manufacturer's instructions. Ensure they are seated correctly.
2. **Case Activation:** The bullet feeder die is case activated; ensure that the case is properly positioned for the bullet to feed.
3. **Feeding Process:** As you operate the reloading press, the bullet feeder will automatically feed bullets into the case upon contact.
4. **Seating and Crimping:** The same station will be used to seat and crimp the bullet securely.
5. **Conversion Kit:** If using the 30 caliber conversion kit, follow the specific instructions provided for its installation and use.

Disposal Instructions

- Dispose of any packaging materials in accordance with local regulations.
- If disposing of the bullet feeder or its components, ensure they are recycled or disposed of in a safe manner, following local waste disposal guidelines.
- Do not dispose of any hazardous materials in regular waste.

Contact Information for Further Support

For any inquiries regarding safety, operation, or support, please refer to the manufacturer's contact details provided with the product packaging. Ensure you have the product name and model ready for reference.

By following these safety instructions, you can ensure a safe and effective experience with your Hornady LockNLoad® Rifle Bullet Feeder. Always prioritize safety and adhere to best practices while reloading.