

STRIKER SPRING PACK FOR GLOCK™ - STRIKE INDUSTRIES

STRIKER SPRING PACK FOR GLOCK

[Handgun Parts](#) > [Action Parts](#) > [Firing Pin Parts](#) > [Firing Pin Springs](#)

New for 2016, the Strike Industries Striker Spring set for Glock allows users an economical way to be able to set their striker spring tension to the perfect level. Ranging from four to six pounds, this single package offers competition, standard, and duty rated springs. The lightest spring can be used for lightened trigger pull setups with aftermarket connectors, strikers, safeties, and spring sets. The heaviest spring is designed to be used with self defense or duty guns where heavier trigger pulls are not an issue, and harder primer strikes are a must. The two springs in the middle of the range allow the user to have a sliding scale of options if desired, where 4 lbs is too light but 6 lbs is too heavy for desired trigger characteristics or primer strike. Package include: 1x 4 lb Striker Spring 1x 4.5 lb Striker Spring 1x 5 lb Striker Spring 1x 6 lb Striker Spring Features: Competition, standard, and duty rated springs included. Four different springs allow user to fine tune their weapon's firing characteristics. A single pack could also potentially outfit four different Glocks. Note: Not for use with models G42 or G43 Factory Spring is 5.5lbs. Springs below 5.5lbs are NOT recommended for duty or self-defense use.



Attributes

- Name: [STRIKE INDUSTRIES STRIKER SPRING PACK FOR GLOCK](#)
- Manufacturer: [STRIKE INDUSTRIES](#)
- Product no.: 100023226
- Mfr. No.: SI-GLK-SPRING
- Weapon type: Glock
- Delivery weight: 0.136kg
- Shipping height: 13mm
- Shipping width: 102mm
- Shipping length: 127mm
- UPC: 708747544992

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for STRIKER SPRING PACK FOR GLOCK™](#)
- [About Us](#)

Safety Instruction Guide for STRIKER SPRING PACK FOR GLOCK™

Introduction

Thank you for purchasing the STRIKER SPRING PACK FOR GLOCK™ by Strike Industries. This product is designed to enhance the performance of your Glock by allowing you to adjust the striker spring tension to your preferred level. To ensure safe and effective use of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Ensure that you are familiar with the operation of your Glock firearm before using this product.
- Always handle firearms with care and treat them as if they are loaded.
- Keep this product and all firearms out of reach of children and unauthorized users.
- Regularly check for any wear or damage to your springs and replace them if necessary.
- Be aware of your local laws and regulations regarding firearm modifications and accessories.
- Report any unsafe products or incidents to the relevant authorities.

Specific Safety Precautions for Use

- Only use the STRIKER SPRING PACK FOR GLOCK™ with compatible Glock models, excluding G42 and G43.
- The factory spring is rated at 5.5 lbs. Springs rated below 5.5 lbs are NOT recommended for duty or selfdefense use.
- Ensure that you are using the correct spring for your intended application (competition, standard, or duty).
- Avoid using lighter springs for selfdefense scenarios where heavier trigger pulls are necessary.
- Be cautious when making adjustments to your firearm, as improper installation may lead to malfunctions or accidents.

Instructions for Installation and Usage

1. Preparation

- Ensure your Glock is unloaded and pointed in a safe direction.
- Gather the necessary tools for installation, such as a punch tool and a hammer.

2. Installation

- Remove the slide from your Glock according to the manufacturer's instructions.
- Carefully remove the factory striker spring by using a punch tool to push the retaining pin.
- Select the desired striker spring from the STRIKER SPRING PACK. The pack includes:
 - 1x 4 lb Striker Spring
 - 1x 4.5 lb Striker Spring
 - 1x 5 lb Striker Spring
 - 1x 6 lb Striker Spring
- Install the selected spring by aligning it with the striker assembly and securing it with the retaining pin.
- Reassemble the slide and ensure all parts are securely in place.

3. Testing

- After installation, conduct a function check to ensure the firearm operates correctly.

- Test the trigger pull to confirm it meets your preferences. Make adjustments as necessary.

4. Maintenance

- Regularly inspect the springs for wear or damage.
- Replace any springs that show signs of fatigue or failure.

Disposal Instructions

- Dispose of any old or unused springs in accordance with local regulations.
- Avoid disposing of springs in a manner that could pose a risk to the environment or public safety.

Contact Information for Further Support

For safety inquiries or support related to the STRIKER SPRING PACK FOR GLOCK™, please refer to the manufacturer's contact points and resources available online.

By following these safety guidelines and instructions, you can ensure a safe and effective experience with your STRIKER SPRING PACK FOR GLOCK™. Thank you for prioritizing safety and responsible firearm handling.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk