

A-MAX/ELD-M CUSTOM BULLET SEATING STEMS - 6.5MM 130/140GR A-MAX/ELD-M SEATING STEM

[Reloading](#) > [Reloading Dies](#) > [Replacement Parts & Upgrades](#)

Hornady's Custom Bullet Seating Stems are designed to fit Hornady® Custom Grade™ Dies, and are machined to fit the profile of the A-MAX and ELD-M bullets to seat them as precisely as possible without damaging bullets. (Not compatible with other manufacturers' dies.)



Attributes

- Name: [6.5MM 130/140GR A-MAX/ELD-M SEATING STEM](#)
- Manufacturer: [HORNADY](#)
- Product no.: 100031795
- Mfr. No.: 397106
- Náboje: 6.5mm
- Delivery weight: 0.014kg
- Shipping height: 25mm
- Shipping width: 51mm
- Shipping length: 95mm
- UPC: 090255971064

Item details

Made in USA

Table of Contents

- Startpage
- AMAX/ELDM CUSTOM BULLET SEATING STEMS SAFETY INSTRUCTIONS
- About Us

AMAX/ELDM CUSTOM BULLET SEATING STEMS SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the AMAX/ELDM Custom Bullet Seating Stems. These precisionengineered components are designed to provide optimal performance when reloading ammunition with Hornady® Custom Grade™ Dies. To ensure safe and effective use, please read this safety instruction guide carefully.

General Safety Guidelines

- Always ensure that the product is used in accordance with the manufacturer's instructions.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the product regularly for signs of wear or damage before use.
- Report any unsafe conditions or accidents to the appropriate authorities.
- Stay informed about product recalls and safety updates via the EU Safety Gate platform.

Specific Safety Precautions for Use

- Use only with Hornady® Custom Grade™ Dies; not compatible with other manufacturers' dies.
- Avoid using excessive force when seating bullets to prevent damage.
- Ensure that the workspace is clean and free from distractions while reloading.
- Wear appropriate personal protective equipment (PPE), such as safety glasses, when handling components.
- Always follow safe reloading practices, including proper storage of powders and primers.

Instructions for Installation and Usage

1. Installation:

- Ensure that your Hornady® Custom Grade™ Die is securely mounted in your reloading press.
- Carefully remove the existing seating stem from the die, if applicable.
- Insert the AMAX/ELDM Custom Bullet Seating Stem into the die and tighten securely.

2. Usage:

- Prepare your cases and bullets according to the reloading manual.
- Adjust the seating depth using the die adjustment feature to achieve the desired bullet seating depth.
- Place a case in the reloading press and insert a bullet into the case mouth.
- Operate the press smoothly to seat the bullet. Avoid excessive force.
- Inspect the seated bullet to ensure proper seating and alignment.

Disposal Instructions

- Dispose of any unused or damaged components in accordance with local regulations.
- Ensure that all materials are disposed of in a safe and environmentally friendly manner.
- Do not dispose of hazardous materials in regular waste.

Contact Information for Further Support

For any inquiries or further assistance regarding the AMAX/ELDM Custom Bullet Seating Stems, please refer to

the manufacturer's website or customer service for support.

Your safety is our priority. Thank you for following these guidelines to ensure a safe and effective reloading experience.

About Us

Brownells Česká republika

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.cz