

AP POWDER THRU EXPANDERS (PTX) - 50 CALIBER (0.500-0.501") POWDER THROUGH EXPANDER

[Reloading](#) > [Reloading Presses](#) > [Progressive Presses](#)

A component of Hornady Lock-N-Load Auto Progressive Press (AP) accessories that enables you to have the fastest cartridge conversion on the market.

Image disclaimer: Expanders may vary in diameter size as shown in the image.



Attributes

- Name: [50 CALIBER \(0.500-0.501"\) POWDER THROUGH EXPANDER](#)
- Manufacturer: [HORNADY](#)
- Product no.: 100031875
- Mfr. No.: 290038
- Delivery weight: 0.05kg
- Shipping height: 25mm
- Shipping width: 51mm
- Shipping length: 140mm
- UPC: 090255699890

Item details

Made in USA
EU Export Disabled

Table of Contents

- Startpage
- AP Powder Thru Expanders (PTX) 50 Caliber Safety Instruction Guide
- About Us

AP Powder Thru Expanders (PTX) 50 Caliber Safety Instruction Guide

Introduction

Thank you for choosing the AP Powder Thru Expanders (PTX) 50 Caliber (0.5000.501"). This product is designed to enhance your experience with the Hornady LockNLoad Auto Progressive Press (AP). To ensure your safety and the proper use of this product, please read this guide carefully before installation and usage.

General Safety Guidelines

- Ensure that you are familiar with the operation of the Hornady LockNLoad Auto Progressive Press (AP) before using the expanders.
- Always wear appropriate personal protective equipment, such as safety glasses and gloves, when handling reloading equipment.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage. Do not use if damaged.
- Follow all local laws and regulations regarding the use of reloading equipment.

Specific Safety Precautions for Use

- Only use the AP Powder Thru Expanders with compatible cartridges as specified by the manufacturer.
- Do not exceed the recommended load specifications when using the expanders.
- Ensure that the expander is securely attached to the press before use.
- Avoid using excessive force when operating the press, as this may lead to equipment failure.
- If you experience any unusual resistance or malfunction during operation, immediately stop use and inspect the equipment.
- Never leave the press unattended while in operation.

Instructions for Installation and Usage

1. Installation:

- Ensure that the Hornady LockNLoad Auto Progressive Press (AP) is turned off and unplugged before installation.
- Locate the expander and the press's mounting area.
- Align the expander with the mounting hole and securely tighten it according to the manufacturer's specifications.
- Doublecheck that the expander is firmly in place before proceeding.

2. Usage:

- Prepare your reloading workspace by ensuring it is clean and welllit.
- Place the cartridge case in the designated area of the press.
- Engage the press handle smoothly and steadily to operate the expander.
- Monitor the operation closely to ensure that the expander is functioning correctly.
- Once the reloading process is complete, safely remove the cartridge case from the press.

Disposal Instructions

- Dispose of any unused or damaged expanders in accordance with local waste disposal regulations.
- Do not dispose of the product in regular household waste. Check for recycling programs in your area that accept metal components.

Contact Information for Further Support

For any safety inquiries or concerns regarding the AP Powder Thru Expanders, please refer to the manufacturer's official contact channels for assistance.

By following these guidelines, you can ensure a safe and effective experience with your AP Powder Thru Expanders. Always prioritize safety and stay informed about best practices in reloading. Thank you for your attention to these important safety instructions.

About Us

Brownells Deutschland

**Brownells Deutschland - Einer der größten Lieferanten für Waffenteile,
Büchsenmacherwerkzeug & Schießsportzubehör**

Lahnstraße 1
24539 Neumünster
Deutschland

www.brownells-deutschland.de