

# SIDEGATE 30-30 WINCHESTER - SIDEgate 30-30 BRASS FRAME 20"

[Firearms](#) > [Rifles](#) > [Lever Action](#)

## A Classic Sidegate Lever-Action in a Classic Caliber

Henry Repeating Arms made a big move in its lineup of classic lever-action rifles with the introduction of its Side Gate model, offering another way to load its lineup of iconic lever guns. As an added bonus, this traditional design has also been paired with a traditional cartridge, since this rifle comes chambered in the time-honored .30-30 Winchester. Each Henry Side Gate Lever Action rifle offers users two ways to load their guns. They can use the removable magazine tube to top off the gun just like all of Henry's classic models, or they can feed rounds in one at a time through the gate located on the side of the receiver. Or any combination of the two! Barrel length: 20 inches Overall length: 38.3 inches Weight: 7.5 pounds Magazine capacity: 5 rounds Each Henry Side Gate Lever Action Rifle is built on a hardened-brass receiver, and the rifle is outfitted with brass accents and beautiful walnut-wood furniture. The steel barrel features a deep-blued finish and is topped by a buckhorn rear sight and an ivory-bead front sight.



## Attributes

- Name: [SIDEgate 30-30 BRASS FRAME 20"](#)
- Manufacturer: [HENRY REPEATING ARMS](#)
- Product no.: 100039209
- Mfr. No.: H024-3030
- Action Type: Lever Action
- Barrel Length: 20"
- Capacity: 5+1-Round
- Cartridge: 30-30 Winchester
- Finish: Blued
- Front Sight: Adjustable
- Length: 38.3"
- Magazine Included: Tubular Magazine
- Magazine Type: Fixed
- Make: Henry
- Model: Sidegate
- Muzzle: Plain
- Rear Sight: Adjustable
- Stock Material: Wood
- Weight: 7.5 lbs
- Delivery weight: 3.402kg
- Shipping height: 51mm
- Shipping width: 178mm
- Shipping length: 1,016mm
- UPC: 619835060457

## Item details

Made in USA

US export classification: 0A501.a

# Table of Contents

- Startpage
- Safety Instruction Guide for the Henry Sidegate 3030 Winchester Lever Action Rifle
- About Us

# **Safety Instruction Guide for the Henry Sidegate 3030 Winchester Lever Action Rifle**

## **Introduction**

Thank you for choosing the Henry Sidegate 3030 Winchester Lever Action Rifle. This guide provides important safety instructions and guidelines to ensure the safe use and handling of your firearm. Please read this manual carefully and keep it for future reference.

## **General Safety Guidelines**

- Always treat every firearm as if it is loaded.
- Keep the muzzle pointed in a safe direction at all times.
- Keep your finger off the trigger until you are ready to shoot.
- Be aware of your target and what is beyond it.
- Store the firearm in a secure location, out of reach of children and unauthorized users.
- Regularly inspect your firearm for signs of wear or damage.
- Ensure that you are familiar with local laws and regulations regarding firearm ownership and use.

## **Specific Safety Precautions for Use**

- Always wear appropriate eye and ear protection when shooting.
- Do not use this firearm under the influence of drugs or alcohol.
- Ensure that the firearm is unloaded when not in use or when being cleaned.
- Use only the specified ammunition for this firearm (.3030 Winchester).
- Do not modify the firearm in any way that could affect its safety or performance.
- Be aware of the potential for ricochet when shooting in areas with hard surfaces.

## **Instructions for Installation and Usage**

### **Loading the Firearm**

- To load the firearm, you can use the removable magazine tube or the side gate:
- To load through the magazine tube:
  - Ensure the firearm is pointed in a safe direction.
  - Remove the magazine tube cap and insert rounds into the tube.
  - Replace the magazine tube cap securely.
- To load through the side gate:
  - Open the side gate on the receiver.
  - Insert one round at a time into the chamber.
  - Close the side gate securely before firing.

### **Firing the Firearm**

- Ensure that you have a proper shooting stance and a firm grip on the rifle.
- Aim at your target and ensure that the area is clear.
- Pull the trigger smoothly to fire the rifle.
- After firing, keep the firearm pointed downrange until you are ready to reload or unload.

### **Unloading the Firearm**

- To unload the firearm, ensure that the muzzle is pointed in a safe direction.
- If using the magazine tube, remove the magazine tube cap and empty the rounds.
- If using the side gate, open the side gate and remove any remaining rounds from the chamber.

## Disposal Instructions

- Dispose of the firearm in accordance with local laws and regulations.
- Do not dispose of the firearm in regular trash.
- Contact local authorities or a licensed firearms dealer for guidance on proper disposal methods.

## Contact Information for Further Support

For any questions or concerns regarding the safety and use of your Henry Sidegate 3030 Winchester Lever Action Rifle, please refer to the manufacturer's contact information provided with your product documentation.

## Conclusion

Safety is paramount when handling firearms. By following the guidelines and precautions outlined in this manual, you can ensure a safe and enjoyable experience with your Henry Sidegate 3030 Winchester Lever Action Rifle. Always stay informed about safety practices and local regulations to protect yourself and others.

# About Us

## Brownells Austria

**Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

[www.brownells.at](http://www.brownells.at)