

AR-15 FIRING PIN - BRN AR-15 FIRING PIN, STAINLESS STEEL

[Rifle Parts](#) > [Bolt Parts](#) > [Firing Pin Parts](#) > [Firing Pins](#)

OEM replacement AR-15/M16 Firing Pin.



Attributes

- Name: [BRN AR-15 FIRING PIN, STAINLESS STEEL](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 100040947
- Mfr. No.: AZT-M4-556FS001
- Make: AR-15
- Delivery weight: 0.011kg
- Shipping height: 10mm
- Shipping width: 76mm
- Shipping length: 152mm
- UPC: 050806029538

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- [Startpage](#)
- [AR15 Firing Pin Safety Instruction Guide](#)
- [About Us](#)

AR15 Firing Pin Safety Instruction Guide

Introduction

Thank you for choosing the AR15 Firing Pin from BROWNELLS. This guide provides essential safety instructions to ensure the safe use and handling of your product. Please read this document carefully before installation and use.

General Safety Guidelines

- Ensure that you are familiar with the operation of your AR15 firearm before installing or using the firing pin.
- Always handle firearms with care and treat them as if they are loaded.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the firing pin and other firearm components for wear and damage.
- Store the product in a secure location when not in use.
- Follow all local laws and regulations regarding firearm ownership and use.

Specific Safety Precautions for Use

• Potential Hazards:

- Improper installation may lead to malfunction or accidental discharge.
- Using incompatible parts can compromise firearm safety.

• Avoiding Hazards:

- Ensure the firearm is unloaded before attempting any installation.
- Use only OEM replacement parts designed for the AR15/M16 platform.
- Consult a qualified gunsmith if you are unsure about the installation process.

• Age Specific Warnings:

- This product is not intended for individuals under the age of 18.
- Ensure that only trained and responsible individuals handle firearms and related components.

Instructions for Installation and Usage

1. Preparation:

- Ensure you have the necessary tools for installation, including a punch tool and a hammer.
- Confirm that the firearm is unloaded and pointed in a safe direction.

2. Installation Steps:

- Remove the bolt carrier group from the firearm.
- Locate the firing pin retaining pin and remove it using a punch tool.
- Carefully remove the old firing pin from the bolt carrier group.
- Insert the new AR15 firing pin into the bolt carrier group.
- Replace the firing pin retaining pin to secure the firing pin in place.
- Reassemble the bolt carrier group and reinstall it into the firearm.

3. Usage Instructions:

- After installation, perform a function check to ensure proper operation.
- Always follow the manufacturer's guidelines for loading and firing your AR15.
- Regularly clean and maintain your firearm to ensure optimal performance.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the firing pin in regular household waste.
- Contact your local waste management facility for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or concerns regarding the AR15 firing pin, please reach out to your local authorized dealer or manufacturer representative.

By following these safety instructions, you can ensure the safe and effective use of your AR15 firing pin. Thank you for prioritizing safety and responsibility in your firearm practices.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at