

SUPER BLACK EAGLE 3 12 GAUGE SHOTGUN - SBE3 12 GAUGE 3" CHAMBER 28" BBL 3+1 ROUND BLACK

SBE 3 – the full redesign of our venerable Super Black Eagle platform. With carefully considered insights from our pro-staff and veteran hunters, Benelli design engineers have spent nearly 10 years in development with a focus on three areas of critical importance to the serious waterfowler: Improved ergonomics, intuitive, flawless functionality and an updated design, style and feel for the latest in modern waterfowling reliability that's all about the end game: Absolute superiority in the most unforgiving conditions. All the amazing attributes that made the Super Black Eagle 3 America's favorite 3 1/2-inch chamber shotgun are now also available for southpaws in a firearm specifically engineered for those who shoulder firearms on the left side. Choose either a Realtree® Max-5™ camo pattern or a black synthetic stock.



Attributes

- Name: SBE3 12 GAUGE 3" CHAMBER 28" BBL 3+1 ROUND BLACK
- Manufacturer: BENELLI U.S.A.
- Product no.: 430101576
- Mfr. No.: 10317
- Action Type: Semi-Auto
- Barrel Length: 28"
- Capacity: 30+1-Round
- Finish: Black
- Front Sight: Fiber Optic
- Gauge: 12 Gauge
- Length: 49.5"
- Magazine Included: None
- Magazine Type: Fixed
- Make: Benelli
- Model: Super Black Eagle III
- Muzzle: Choke Tubes
- Rear Sight: None
- Stock Material: Polymer
- Weight: 6.9 lbs
- Shipping height: 76mm
- Shipping width: 330mm
- Shipping length: 991mm
- UPC: 650350103175

Item details

EU Export Disabled

US export classification: 0A502

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die SUPER BLACK EAGLE 3 12 GAUGE SHOTGUN](#)
- [English: SUPER BLACK EAGLE 3 12 GAUGE SHOTGUN SAFETY INSTRUCTIONS](#)

Sicherheitshinweise für die SUPER BLACK EAGLE 3 12 GAUGE SHOTGUN

Einführung

Herzlichen Glückwunsch zum Kauf der SUPER BLACK EAGLE 3 12 GAUGE SHOTGUN von Benelli U.S.A. Dieses Produkt wurde mit dem Ziel entwickelt, Ihnen ein sicheres und angenehmes Erlebnis beim Wasserjagen zu bieten. Bitte lesen Sie diese Sicherheitshinweise sorgfältig durch, um sicherzustellen, dass Sie das Produkt sicher verwenden.

Allgemeine Sicherheitsrichtlinien

- Achten Sie darauf, dass das Produkt nur von Personen verwendet wird, die mit der sicheren Handhabung von Schusswaffen vertraut sind.
- Halten Sie die Schusswaffe immer in einem sicheren Zustand, bis Sie bereit sind, zu schießen.
- Beachten Sie die örtlichen Gesetze und Vorschriften zur Verwendung von Schusswaffen.
- Verwenden Sie die Schusswaffe niemals unter dem Einfluss von Alkohol oder Drogen.
- Lagern Sie die Schusswaffe in einem sicheren und gesicherten Bereich, der für Kinder unzugänglich ist.

Spezifische Sicherheitsvorkehrungen für die Verwendung

- Verwenden Sie nur die vom Hersteller empfohlenen Munitionstypen.
- Überprüfen Sie vor jedem Gebrauch die Schusswaffe auf Anzeichen von Beschädigungen oder Abnutzung.
- Halten Sie den Finger immer vom Abzug, bis Sie bereit sind, zu schießen.
- Richten Sie die Waffe niemals auf etwas, was Sie nicht beabsichtigen zu treffen.
- Verwenden Sie beim Schießen geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille.

Anweisungen zur Installation und Verwendung

- Stellen Sie sicher, dass die Schusswaffe vor der Montage entladen ist.
- Folgen Sie diesen Schritten zur Montage:
 1. Entfernen Sie die Schutzabdeckung von der Schusswaffe.
 2. Installieren Sie den Schaft gemäß den Anweisungen im Benutzerhandbuch.
 3. Überprüfen Sie, ob alle Teile fest sitzen und korrekt montiert sind.
- Um die Schusswaffe zu laden:
 1. Ziehen Sie den Verschluss zurück, um die Kammer zu öffnen.
 2. Legen Sie die Munition in das Magazin.
 3. Lassen Sie den Verschluss langsam zurückgleiten, um die Kammer zu schließen.
- Um die Schusswaffe zu entladen:
 1. Ziehen Sie den Verschluss zurück, um die Kammer zu öffnen.
 2. Entfernen Sie alle Patronen aus dem Magazin und der Kammer.
 3. Überprüfen Sie, dass die Waffe vollständig entladen ist, bevor Sie sie ablegen.

Entsorgungsanweisungen

- Entsorgen Sie leere Patronen und andere Abfälle gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Lagern Sie nicht mehr benötigte Munition sicher und geben Sie diese an autorisierte Rücknahmestellen zurück.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder weitere Informationen zu Ihrer SUPER BLACK EAGLE 3 12 GAUGE SHOTGUN wenden Sie sich bitte an den Hersteller oder den Händler, bei dem Sie das Produkt erworben haben. Achten Sie darauf, alle Sicherheitsanweisungen zu befolgen und bei Bedarf professionelle Unterstützung in Anspruch zu nehmen.

Diese Sicherheitshinweise sind in Übereinstimmung mit den EU-Richtlinien für Produktsicherheit erstellt worden. Achten Sie darauf, alle Anweisungen zu befolgen, um ein sicheres und verantwortungsvolles Schießen zu gewährleisten.

SUPER BLACK EAGLE 3 12 GAUGE SHOTGUN

SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the SUPER BLACK EAGLE 3 12 GAUGE SHOTGUN. This guide provides essential safety instructions to ensure the safe and proper use of your shotgun. It is important to read and understand these guidelines before using the firearm.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep the muzzle pointed in a safe direction at all times.
- Keep your finger off the trigger until you are ready to shoot.
- Be aware of your target and what lies beyond it.
- Never use alcohol or drugs before or while handling firearms.
- Ensure the shotgun is stored securely and out of reach of children.
- Regularly inspect the shotgun for any signs of damage or wear.
- Always use appropriate ammunition for your shotgun.
- Follow all local laws and regulations regarding firearm usage.

Specific Safety Precautions for Use

- Ensure that the shotgun is fully assembled and in good working condition before use.
- Always wear appropriate eye and ear protection when shooting.
- Avoid shooting in conditions that may impair your vision or judgment.
- Do not shoot at hard surfaces or water as this may cause ricochets.
- Be mindful of the environment and ensure that you have permission to shoot in the area.
- If you experience a misfire, keep the shotgun pointed downrange for at least 30 seconds before attempting to clear the chamber.
- Only use the shotgun for its intended purpose: hunting or sport shooting.

Instructions for Installation and Usage

1. Unboxing and Inspection

- Carefully remove the shotgun from its packaging.
- Inspect all components to ensure they are present and undamaged.

2. Assembly

- If not already assembled, attach the stock to the receiver according to the manufacturer's instructions.
- Ensure all parts are securely fastened.

3. Loading the Shotgun

- Open the action and ensure the chamber is empty.
- Insert the appropriate ammunition into the magazine tube.
- Close the action, ensuring it is locked securely.

4. Firing the Shotgun

- Assume a stable shooting position.
- Aim at your target while keeping your finger off the trigger.
- When ready, place your finger on the trigger and squeeze gently to fire.

5. After Use

- Always unload the shotgun after use.
- Clean the shotgun according to the manufacturer's maintenance guidelines.
- Store the shotgun in a secure location, preferably in a locked cabinet.

Disposal Instructions

- Dispose of any unused or expired ammunition according to local regulations.
- If the shotgun is no longer in use, contact a licensed firearms dealer for proper disposal.
- Do not dispose of firearms in regular trash or recycling.

Contact Information for Further Support

For any questions or concerns regarding the SUPER BLACK EAGLE 3 12 GAUGE SHOTGUN, please refer to the manufacturer's website or customer service for assistance.

Conclusion

By following these safety instructions, you can help ensure a safe and enjoyable experience with your SUPER BLACK EAGLE 3 12 GAUGE SHOTGUN. Always prioritize safety and responsibility when handling firearms. Thank you for your attention to these important guidelines.