

## 1873 CATTLEMAN II 357 MAGNUM REVOLVER - 1873 CATTLEMAN II NEW MODEL BRASS 357 MAG 4.75" BBL BLUED

The Uberti Cattleman II with retractable firing pin is a breakthrough for those seeking enhanced safety with regard to original Old West revolvers without sacrificing the visual authenticity of a 1st-generation Colt. As any cowboy knows, the safest way to carry a single-action is with the hammer resting on an unloaded chamber. This is true even for the Uberti retractable firing pin design. But in the case of the Uberti design, the risk of accidental discharge is reduced: the firing pin is not locked into the firing position unless the trigger is pulled. This enhanced safety feature is available without a visible transfer bar safety, which those who insist on visual authenticity might not want. In other words, from the outside this revolver's looks and operation are identical to those of an original.



### Attributes

- Name: 1873 CATTLEMAN II NEW MODEL BRASS 357 MAG 4.75" BBL BLUED
- Manufacturer: UBERTI
- Product no.: 430101615
- Mfr. No.: 356200
- Action Type: Single Action
- Barrel Length: 4.75"
- Capacity: 6-Round
- Cartridge: 357 Magnum
- Finish: Polished
- Front Sight: Blade
- Length: 11"
- Magazine Included: NA
- Magazine Type: NA
- Make: Uberti
- Model: 1873 Cattleman
- Muzzle: Non-Threaded
- Rear Sight: None
- Stock Material: Walnut
- Weight: 2.3 lbs
- Shipping height: 51mm
- Shipping width: 152mm
- Shipping length: 305mm
- UPC: 037084997391

### Item details

US export classification: 0A501.a

# Table of Contents

- Startpage
- Deutsch: Sicherheitshinweise für den 1873 CATTLEMAN II 357 MAGNUM REVOLVER
- English: Safety Instruction Guide for the 1873 Cattleman II 357 Magnum Revolver

# Sicherheitshinweise für den 1873 CATTLEMAN II 357 MAGNUM REVOLVER

## Einführung

Herzlichen Glückwunsch zum Erwerb des 1873 CATTLEMAN II 357 MAGNUM REVOLVER von Uberti. Dieses Produkt wurde mit dem Ziel entwickelt, ein authentisches Erlebnis im Stil des Wilden Westens zu bieten, während gleichzeitig moderne Sicherheitsmerkmale integriert sind. Um sicherzustellen, dass Sie dieses Produkt sicher und effektiv nutzen, beachten Sie bitte die folgenden Sicherheitshinweise.

## Allgemeine Sicherheitsrichtlinien

- Verwenden Sie den Revolver niemals, wenn Sie müde, unter dem Einfluss von Drogen oder Alkohol stehen.
- Halten Sie den Revolver immer in einem sicheren Zustand, wenn er nicht verwendet wird.
- Bewahren Sie den Revolver außerhalb der Reichweite von Kindern und unbefugten Personen auf.
- Überprüfen Sie regelmäßig, ob der Revolver in einem einwandfreien Zustand ist.
- Informieren Sie sich über die gesetzlichen Bestimmungen zur Waffenbesitz und Nutzung in Ihrem Land oder Ihrer Region.

## Spezifische Sicherheitsvorkehrungen für die Verwendung

- Stellen Sie sicher, dass der Hahn auf einer ungeladenen Kammer ruht, wenn Sie den Revolver tragen.
- Vermeiden Sie es, den Abzug zu betätigen, wenn Sie nicht beabsichtigen zu schießen.
- Verwenden Sie nur die vom Hersteller empfohlenen Munitionstypen.
- Achten Sie darauf, dass sich keine Hindernisse im Lauf befinden, bevor Sie schießen.
- Tragen Sie immer Gehörschutz und Schutzbrille beim Schießen.

## Anweisungen zur Installation und Nutzung

### 1. Überprüfung des Revolvers:

- Stellen Sie sicher, dass der Revolver entladen ist, bevor Sie ihn handhaben.
- Überprüfen Sie den Zustand des Revolvers auf Anzeichen von Abnutzung oder Beschädigung.

### 2. Laden des Revolvers:

- Laden Sie den Revolver gemäß den Anweisungen im Benutzerhandbuch.
- Achten Sie darauf, dass der Hahn auf einer ungeladenen Kammer ruht, wenn Sie den Revolver tragen.

### 3. Shooting:

- Zielen Sie immer in eine sichere Richtung.
- Betätigen Sie den Abzug nur, wenn Sie bereit sind zu schießen.

### 4. Reinigung und Wartung:

- Reinigen Sie den Revolver regelmäßig, um seine Funktionsfähigkeit zu gewährleisten.
- Verwenden Sie nur empfohlene Reinigungsmittel und werkzeuge.

## Entsorgungsanweisungen

- Entsorgen Sie alle nicht mehr benötigten Teile des Revolvers gemäß den örtlichen Gesetzen und Vorschriften.
- Bringen Sie den Revolver zur Entsorgung zu einem autorisierten Händler oder einer Sammelstelle für gefährliche Abfälle.

## Kontaktinformationen für weitere Unterstützung

Für Unterstützung und weitere Informationen zu Sicherheitsfragen oder Produktanfragen wenden Sie sich bitte an den Hersteller oder Ihren Händler. Alle Produkte sollten eine Kontaktstelle in der EU für Sicherheitsanfragen haben.

## **Wichtige Hinweise**

- Melden Sie unsichere Produkte oder Unfälle den zuständigen Behörden.
- Überprüfen Sie regelmäßig die Rückrufupdates auf der EUSicherheitsplattform.

Bitte beachten Sie diese Sicherheitsrichtlinien, um eine sichere Nutzung Ihres 1873 CATTLEMAN II 357 MAGNUM REVOLVER zu gewährleisten. Ihre Sicherheit hat oberste Priorität!

# Safety Instruction Guide for the 1873 Cattleman II 357 Magnum Revolver

## Introduction

Congratulations on your purchase of the 1873 Cattleman II 357 Magnum Revolver. This guide provides essential safety instructions to ensure the safe use and handling of your revolver. Please read this manual thoroughly before using the product.

## General Safety Guidelines

- Always treat your revolver as if it is loaded, even when you believe it is not.
- Keep your finger off the trigger until you are ready to shoot.
- Never point the revolver at anything you do not intend to shoot.
- Store your revolver in a secure location, out of reach of children and unauthorized users.
- Regularly inspect your revolver for any signs of wear or damage.
- Use only the correct ammunition specified for this revolver.
- Follow all local laws and regulations regarding the ownership and use of firearms.

## Specific Safety Precautions for Use

- Ensure the revolver is pointed in a safe direction before loading or unloading.
- Always use safety glasses when shooting.
- Be aware of your surroundings and what is beyond your target.
- Do not attempt to modify or alter the revolver in any way.
- Use proper shooting techniques and stance to maintain control.
- If you experience a misfire, wait at least 30 seconds before attempting to open the cylinder.
- Do not consume alcohol or drugs before or while handling the revolver.

## Instructions for Installation and Usage

### • Loading the Revolver:

1. Ensure the revolver is pointed in a safe direction.
2. Open the cylinder by pressing the release latch.
3. Insert the cartridges into the chambers, ensuring they are seated properly.
4. Close the cylinder securely.

### • Firing the Revolver:

1. Grip the revolver firmly with your dominant hand.
2. Place your finger on the trigger only when ready to fire.
3. Aim at your target and squeeze the trigger smoothly.
4. After firing, keep the revolver pointed downrange until you are ready to reload or unload.

### • Unloading the Revolver:

1. Ensure the revolver is pointed in a safe direction.
2. Open the cylinder by pressing the release latch.
3. Eject the spent cartridges using the ejector rod.
4. Inspect the chambers to ensure they are empty before closing the cylinder.

## Disposal Instructions

When disposing of your revolver, follow these guidelines: \* Contact your local law enforcement agency for guidance on safe disposal methods. \* Ensure that the revolver is unloaded before disposal. \* Do not dispose of firearms in regular trash or recycling bins.

## Contact Information for Further Support

For safety inquiries or concerns regarding your 1873 Cattleman II 357 Magnum Revolver, please reach out to the manufacturer or authorized dealer. Ensure you have your product details handy for a quicker response.

## Conclusion

Your safety and the safety of those around you are paramount. By following these guidelines and instructions, you can ensure a safe and enjoyable experience with your 1873 Cattleman II 357 Magnum Revolver. Always prioritize safety and responsible use.