

1873 CATTLEMAN II 357 MAGNUM REVOLVER - 1873 CATTLEMAN II NEW MODEL BRASS 357 MAG 5.5" BBL BLUED

The Uberti Cattleman II with retractable firing pin is a breakthrough for those seeking enhanced safety with regard to original Old West revolvers without sacrificing the visual authenticity of a 1st-generation Colt. As any cowboy knows, the safest way to carry a single-action is with the hammer resting on an unloaded chamber. This is true even for the Uberti retractable firing pin design. But in the case of the Uberti design, the risk of accidental discharge is reduced: the firing pin is not locked into the firing position unless the trigger is pulled. This enhanced safety feature is available without a visible transfer bar safety, which those who insist on visual authenticity might not want. In other words, from the outside this revolver's looks and operation are identical to those of an original.



Attributes

- Name: 1873 CATTLEMAN II NEW MODEL BRASS 357 MAG 5.5" BBL BLUED
- Manufacturer: UBERTI
- Product no.: 430101616
- Mfr. No.: 356210
- Action Type: Single Action
- Barrel Length: 5.5"
- Capacity: 6-Round
- Cartridge: 357 Magnum
- Finish: Polished
- Front Sight: Blade
- Length: 11"
- Magazine Included: NA
- Magazine Type: NA
- Make: Uberti
- Model: 1873 Cattleman
- Muzzle: Non-Threaded
- Rear Sight: None
- Stock Material: Walnut
- Weight: 2.3 lbs
- Delivery weight: 1.488kg
- Shipping height: 51mm
- Shipping width: 152mm
- Shipping length: 305mm
- UPC: 037084997407

Item details

US export classification: 0A501.a

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für den 1873 CATTLEMAN II 357 MAGNUM REVOLVER](#)
- [English: Safety Instruction Guide for the 1873 CATTLEMAN II 357 MAGNUM REVOLVER](#)

Sicherheitshinweise für den 1873 CATTLEMAN II 357 MAGNUM REVOLVER

Einführung

Herzlichen Glückwunsch zum Kauf Ihres 1873 CATTLEMAN II 357 MAGNUM REVOLVER von Uberti. Dieses Produkt ist ein hochwertiger Revolver, der Sicherheit und Authentizität vereint. Um sicherzustellen, dass Sie das Produkt sicher verwenden, beachten Sie bitte die folgenden Sicherheitshinweise und Anweisungen.

Allgemeine Sicherheitsrichtlinien

- Verwenden Sie den Revolver nur für den vorgesehenen Zweck.
- Halten Sie den Revolver stets in einem sicheren Zustand, wenn er nicht verwendet wird.
- Bewahren Sie den Revolver an einem sicheren Ort auf, fern von Kindern und unbefugten Personen.
- Überprüfen Sie regelmäßig den Zustand des Revolvers auf mögliche Mängel oder Beschädigungen.
- Melden Sie unsichere Produkte oder Vorfälle sofort den zuständigen Behörden.
- Informieren Sie sich über Rückrufaktionen auf der EU Safety Gate Plattform.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Vergewissern Sie sich, dass der Revolver nicht geladen ist, bevor Sie ihn handhaben.
- Halten Sie den Finger vom Abzug, bis Sie bereit sind zu schießen.
- Richten Sie den Revolver niemals auf jemanden, auch nicht, wenn er nicht geladen ist.
- Seien Sie sich der Umgebung bewusst und schießen Sie nur in sicheren, dafür vorgesehenen Bereichen.
- Verwenden Sie nur die empfohlenen Munitionstypen für den Revolver.
- Tragen Sie beim Schießen geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille.

Anweisungen für Installation und Nutzung

- **Vorbereitung:**
 - Überprüfen Sie den Revolver vor der Verwendung auf Beschädigungen.
 - Stellen Sie sicher, dass der rückziehbare Schlagbolzen ordnungsgemäß funktioniert.
- **Laden des Revolvers:**
 - Öffnen Sie die Trommel und laden Sie die Munition in die Kammern.
 - Stellen Sie sicher, dass der Hahn auf einer ungeladenen Kammer ruht, wenn der Revolver nicht verwendet wird.
- **Abfeuern des Revolvers:**
 - Richten Sie den Revolver auf das Ziel und drücken Sie den Abzug vorsichtig.
 - Nach dem Schießen den Revolver sofort wieder in einen sicheren Zustand versetzen.
- **Reinigung und Wartung:**
 - Reinigen Sie den Revolver regelmäßig gemäß den Herstelleranweisungen.
 - Verwenden Sie nur empfohlene Reinigungsmittel und Werkzeuge.

Entsorgungsanweisungen

- Entsorgen Sie alte oder beschädigte Munition gemäß den örtlichen Vorschriften.
- Bei der Entsorgung des Revolvers beachten Sie bitte die geltenden Gesetze und Vorschriften in Ihrer Region.
- Bringen Sie den Revolver zu einem autorisierten Händler oder einer entsprechenden Sammelstelle, wenn er nicht mehr verwendet werden kann.

Kontaktinformationen für weitere Unterstützung

Für weitere Informationen und Unterstützung zu Ihrem 1873 CATTLEMAN II 357 MAGNUM REVOLVER, wenden Sie sich bitte an den Hersteller oder einen autorisierten Händler.

Vielen Dank, dass Sie sich die Zeit genommen haben, diese Sicherheitshinweise zu lesen. Ihre Sicherheit hat oberste Priorität!

Safety Instruction Guide for the 1873 CATTLEMAN II 357 MAGNUM REVOLVER

Introduction

Thank you for choosing the Uberti 1873 Cattleman II 357 Magnum Revolver. This guide provides essential safety instructions and guidelines to ensure safe and responsible use of your revolver. Please read this document carefully before using the product.

General Safety Guidelines

- Always treat the revolver as if it is loaded.
- Keep the revolver pointed in a safe direction at all times.
- Do not place your finger on the trigger until you are ready to fire.
- Store the revolver in a secure location, out of reach of children and unauthorized users.
- Regularly check for any signs of wear or damage before use.
- Ensure that you are familiar with local laws and regulations regarding firearm ownership and use.
- Use only the recommended ammunition as specified in the product specifications.

Specific Safety Precautions for Use

- **Firing Pin Safety:** The retractable firing pin design enhances safety by preventing accidental discharge. The firing pin is only locked in the firing position when the trigger is pulled.
- **Carrying the Revolver:** When carrying the revolver, ensure the hammer is resting on an unloaded chamber to minimize risk.
- **Loading and Unloading:** Always load and unload the revolver with the muzzle pointed in a safe direction. Verify that the chamber is empty before loading.
- **Shooting Environment:** Ensure you are in a safe and appropriate location when firing the revolver. Be aware of your surroundings and ensure there is a proper backstop.
- **Maintenance:** Regularly clean and maintain your revolver according to the manufacturer's instructions to ensure optimal performance and safety.

Instructions for Installation and Usage

1. Loading the Revolver:

- Ensure the revolver is pointed in a safe direction.
- Open the loading gate and insert the cartridges into the chambers.
- Close the loading gate securely.
- Pull the hammer back to the first notch to rest it on an empty chamber.

2. Firing the Revolver:

- Ensure the area is clear and safe for shooting.
- Grip the revolver firmly with both hands.
- Aim at the target and ensure your finger is off the trigger.
- When ready to shoot, pull the trigger smoothly to fire.

3. Unloading the Revolver:

- Open the loading gate and pull the hammer back to the first notch.
- Eject the spent cartridges by pressing the ejector rod.
- Inspect the chambers to ensure they are empty.

4. Cleaning and Maintenance:

- After each use, clean the revolver to prevent buildup of residue.
- Use a soft cloth and appropriate cleaning solutions designed for firearms.
- Regularly inspect all parts for wear and replace any damaged components.

Disposal Instructions

When it is time to dispose of the revolver or any associated materials:

- Follow local laws and regulations regarding the disposal of firearms.
- Contact local authorities or licensed dealers for proper disposal methods.
- Ensure that the revolver is made inoperable before disposal to prevent any accidents.

Contact Information for Further Support

For any safety inquiries or concerns regarding your Uberti 1873 Cattleman II 357 Magnum Revolver, please refer to the manufacturer's website or contact their customer service for assistance.

By following these safety instructions, you can ensure a safer experience with your revolver. Remember that responsible ownership and use are key to enjoying your product safely.