

DISCONNECTOR FOR REMINGTON 750/7400 STEEL UNFINISHED

REMINGTON DISCONNECTOR FOR REMINGTON 750/7400 Factory-spec replacement disconnecter designed for the Remington 7400 and Remington 750. This component is a critical part of the trigger assembly, responsible for proper trigger reset during the rifle's cycling operation. Ideal for repairing worn, damaged, or non-functioning trigger components. FEATURES Direct replacement for Remington Part #F91431 Compatible with Remington 750 and 7400 models Precision-machined steel construction Unfinished surface – suitable for fitting or refinishing Maintains proper trigger reset and engagement Factory-dimensioned for reliable performance SPECS Product Type: Disconnector Manufacturer Reference: Remington F91431 Compatible Models: Remington 750, Remington 7400 Material: Steel Finish: Unfinished Installation: Professional gunsmith installation recommended NOTE: These items are a new, authentic products acquired directly from Remington's OEM inventory. This item is guaranteed to be unused and fully functional.

NO IMAGE
AVAILABLE

Attributes

- Name: DISCONNECTOR FOR REMINGTON 750/7400 STEEL UNFINISHED
- Manufacturer: REMINGTON
- Product no.: 430116575
- Mfr. No.: F91431
- Model: 7400,750
- Weapon type: Remington
- Delivery weight: 0.12kg

Item details

Made in USA

US export classification: 0A501.c

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Remington 750/7400 Disconnecter](#)

Safety Instruction Guide for Remington 750/7400 Disconnecter

Introduction

Thank you for choosing the Remington Disconnecter for the Remington 750/7400. This product is a critical component of your rifle's trigger assembly, designed to ensure proper trigger reset during operation. It is essential to follow safety guidelines and installation instructions to ensure the safe and effective use of this product.

General Safety Guidelines

- Always handle firearms and firearm components with care and in accordance with local laws and regulations.
- Ensure that the disconnecter is installed by a professional gunsmith to avoid any potential hazards.
- Regularly inspect the disconnecter and other trigger components for wear or damage.
- Store all firearm components securely and out of reach of children and unauthorized users.
- Report any unsafe products or accidents to the relevant authorities.
- Check for recall updates on the EU's Safety Gate platform to stay informed about product safety.

Specific Safety Precautions for Use

- Ensure that the firearm is unloaded before attempting any installation or maintenance.
- Wear appropriate personal protective equipment (PPE) such as safety glasses and gloves during installation.
- Keep hands and tools clear of moving parts during installation to prevent injury.
- Avoid using the disconnecter if it shows signs of damage or wear.
- Do not modify the disconnecter or other trigger components, as this may compromise safety and functionality.
- Be aware that this product is not suitable for individuals under the age of 18 unless supervised by a responsible adult.

Instructions for Installation and Usage

1. Preparation:

- Ensure that the firearm is completely unloaded.
- Gather necessary tools, including a screwdriver and any other tools recommended by your gunsmith.

2. Installation:

- Remove the trigger assembly from the firearm according to the manufacturer's instructions.
- Carefully remove the old disconnecter, taking note of its orientation and placement.
- Install the new disconnecter in the same orientation as the old one.
- Reassemble the trigger assembly, ensuring all components are properly secured.

3. Testing:

- Once installed, conduct a function check to ensure the trigger resets properly.
- If any issues are detected during testing, consult a professional gunsmith immediately.

4. Usage:

- Regularly check the functionality of the disconnecter and other trigger components during routine firearm maintenance.
- If the firearm experiences any malfunctions, cease use immediately and have it inspected by a qualified professional.

Disposal Instructions

- Dispose of any damaged or worn components in accordance with local regulations.
- Do not dispose of firearm components in regular household waste. Instead, contact your local waste management authority for proper disposal methods.
- Ensure that all components are rendered unusable before disposal to prevent unauthorized use.

Contact Information for Further Support

For any questions or concerns regarding the Remington Disconnecter for the Remington 750/7400, please consult a qualified gunsmith or refer to the manufacturer's documentation for further assistance.

Thank you for prioritizing safety while using this product. Your careful adherence to these guidelines helps ensure a safe and enjoyable shooting experience.