

ACHRO™ 10L EDC SLING BAG WITH LASER CUT MOLLE - MISSION FIRST TACTICAL, LLC ACHRO 10L EDC SLING BAG W/LASER CUT MOLLE DARK LAGOON

MISSION FIRST TACTICAL ACHRO™ 10L EDC SLING BAG WITH LASER CUT MOLLE “Achro™ derived from “Achromatic” is defined as “without color”... The Gray Man. Achro™ Bags embrace the art of blending in with a low-vis, everyday-carry bag featuring a dedicated, discreet firearm storage system. Inspired to keep this functional as a great everyday commuter bag, daily essentials are organized and secure while on the go, offering a vast array of organizational options in a very comfortable platform. The Achro™ 10L EDC Sling Bag is a perfect daily commuter or versatile carry-on travel companion. Designed to meet the needs of modern commuters and travelers seeking both functionality and security, the Achro™ 10L Sling Bag offers an array of organizational options in a comfortable platform. Whether you're a daily commuter, law enforcement professional or a weekend warrior, this sling bag caters to your lifestyle with utmost precision. The dedicated, discreet concealed firearm compartment is ambidextrous with quick access. An MFT Multi-Mount Platform is included, offering the ability to mount a holstered firearm or other 1.5” belt clip accessories, with custom orientation, utilizing a hook & loop system. A padded strap is removable and adjustable, worn on either shoulder, making the bag ambidextrous. There is a padded tablet compartment, with separate access, and a front admin/organizer panel. Cooling, quilted back padding increases comfort for extended use. The Achro™ Series is constructed from durable materials that are designed to withstand the elements and rugged environments. FEATURES: Low-Vis (Gray Man) design aesthetic Dedicated and discreet firearm pocket MFT Multi-Mount Platform included Smart storage for vast array of EDC organizational options Lighter colored WR (water resistant) ripstop liner to aid in interior visibility Aluminum key clip Weather and abrasion-resistant construction Rear compartment designed for tablet Cooling premium padded back panel Premium padded and ambidextrous shoulder harness – Easily adjustable Adjustable and removable waist strap Laser-cut MOLLE for additional gear attachment Panel zip allows full access to main compartment Internal zippered storage pockets Front admin & cable storage Fleece-lined sunglass pocket 10L Capacity (16”L x 10”H x 4”D), 1.95 lbs



Attributes

- Name: MISSION FIRST TACTICAL, LLC ACHRO 10L EDC SLING BAG W/LASER CUT MOLLE DARK LAGOON
- Manufacturer: MISSION FIRST TACTICAL, LLC
- Product no.: 430117682
- Mfr. No.: B2-SL-DL
- Colour: Dark Lagoon
- Delivery weight: 0.862kg
- UPC: 810099434187

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die ACHRO™ 10L EDC Sling Bag](#)
- [English: Safety Instruction Guide for ACHRO™ 10L EDC Sling Bag](#)
- [Italiano: Guida alle Istruzioni di Sicurezza del Prodotto](#)

Sicherheitshinweise für die ACHRO™ 10L EDC Sling Bag

Einführung

Herzlich willkommen! Die ACHRO™ 10L EDC Sling Bag ist dein perfekter Begleiter für den Alltag. Um sicherzustellen, dass du das Beste aus deiner Tasche herausholst und gleichzeitig sicher bleibst, haben wir diese Sicherheitshinweise zusammengestellt. Bitte lies sie sorgfältig durch.

Allgemeine Sicherheitsrichtlinien

- Stelle sicher, dass die Tasche für den vorgesehenen Zweck verwendet wird.
- Überprüfe regelmäßig auf Beschädigungen oder Abnutzung, um sicherzustellen, dass die Tasche sicher bleibt.
- Halte die Tasche von Kindern fern, wenn sie nicht unter Aufsicht sind.
- Verwende die Tasche nicht, wenn sie beschädigt ist.
- Achte darauf, dass die Tasche nicht überladen wird, um das Risiko von Verletzungen oder Schäden zu minimieren.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Verwende die dedizierte Waffentasche nur für zugelassene und sichere Gegenstände.
- Achte darauf, dass alle Reißverschlüsse und Schnallen ordnungsgemäß geschlossen sind, bevor du die Tasche trägst.
- Trage die Tasche so, dass sie sicher am Körper anliegt, um ein Verrutschen zu vermeiden.
- Vermeide es, die Tasche in überfüllten oder unsicheren Umgebungen unaufmerksam zu lassen.
- Überprüfe die Wetterbedingungen, bevor du die Tasche im Freien verwendest, um sicherzustellen, dass sie nicht beschädigt wird.

Anweisungen zur Installation und Nutzung

- Stelle sicher, dass die Schultergurte richtig eingestellt sind, um maximalen Komfort zu gewährleisten.
- Um den Hüftgurt zu verwenden, stelle ihn auf die gewünschte Länge ein und befestige ihn sicher.
- Nutze die Lasercut MOLLE für die Anbringung zusätzlicher Ausrüstungsgegenstände.
- Wenn du die Tasche für den Transport von Tablets verwendest, achte darauf, dass sie sicher in der Rückentasche verstaut sind.
- Halte die Tasche sauber, indem du sie mit einem feuchten Tuch abwischst. Verwende keine scharfen Reinigungsmittel.

Entsorgungsanweisungen

- Entsorge die Tasche gemäß den örtlichen Vorschriften für Kunststoff und Textilabfälle.
- Überprüfe, ob die Tasche noch funktionsfähig ist, bevor du sie entsorgst. Wenn sie beschädigt ist, entsorge sie sicher, um Umweltverschmutzung zu vermeiden.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder Bedenken zu deiner ACHRO™ 10L EDC Sling Bag, wende dich bitte an den Hersteller oder deinen Händler. Sie stehen dir gerne zur Verfügung, um dir bei allen Anliegen zu helfen.

Vielen Dank, dass du die ACHRO™ 10L EDC Sling Bag gewählt hast! Wir wünschen dir viel Freude und Sicherheit beim Gebrauch.

Safety Instruction Guide for ACHRO™ 10L EDC Sling Bag

Introduction

Thank you for choosing the ACHRO™ 10L EDC Sling Bag with Laser Cut MOLLE. This product is designed to provide functionality, comfort, and security for everyday carry and travel. To ensure safe usage and compliance with the EU General Product Safety Regulation (GPSR), please read this safety instruction guide carefully.

General Safety Guidelines

- **Product Safety:** Ensure safe use of the ACHRO™ Sling Bag by following all safety instructions. This product is designed for nonfood use and is compliant with EU safety standards.
- **Enhanced Recalls:** Stay informed about any recalls or safety notices related to this product. If a recall occurs, remedies will be provided at no charge.
- **Online Shopping:** When purchasing online, ensure that the seller meets all safety requirements similar to physical stores.
- **Special Consumer Focus:** This product is not intended for use by children under the age of 14. Always supervise children if they are in possession of this bag.
- **EU Contact Point:** For safety inquiries, please refer to the contact information provided by your retailer or manufacturer.
- **Rapid Alerts:** Stay updated on product safety through the EU's Safety Gate platform, which provides information on unsafe products.

Specific Safety Precautions for Use

- **Avoid Overloading:** Do not exceed the bag's capacity of 10L. Overloading can cause strain on the bag's seams and zippers.
- **Secure Firearm Storage:** If using the dedicated firearm compartment, ensure that the firearm is unloaded and securely stored to prevent accidental discharge.
- **Check for Damage:** Before each use, inspect the bag for any signs of wear or damage. Do not use if any part is compromised.
- **Use the Adjustable Strap Properly:** Ensure that the strap is adjusted to fit securely on your shoulder to prevent slipping or discomfort during use.
- **Avoid Moisture:** While the bag features a waterresistant liner, prolonged exposure to moisture can still damage contents. Store in a dry place when not in use.
- **Keep Away from Heat Sources:** Avoid exposing the bag to direct heat sources, which could damage materials and compromise safety.

Instructions for Installation and Usage

- **Adjusting the Strap:**
 - To adjust the padded shoulder strap, pull the adjustment buckle to tighten or loosen as needed.
 - The strap can be worn on either shoulder for ambidextrous use.
- **Using the Dedicated Firearm Compartment:**
 - Access the concealed firearm compartment by unzipping the designated pocket.
 - Ensure that the firearm is unloaded and securely stored in the compartment.
 - Close the compartment zipper completely to ensure safety and concealment.
- **Organizing Your Essentials:**

- Use the internal zippered storage pockets for smaller items to prevent them from moving around.
- Utilize the front admin/organizer panel to keep daily essentials organized and easily accessible.
- **Tablet Storage:**
 - Place your tablet in the designated padded compartment to protect it from damage.
 - Access the tablet compartment separately to avoid unnecessary exposure to other contents.
- **MOLLE System:**
 - Use the lasercut MOLLE system to attach additional gear securely.
 - Ensure that all attachments are properly secured to prevent loss during use.
- **Cleaning and Maintenance:**
 - Wipe the exterior with a damp cloth to remove dirt and stains.
 - Allow the bag to air dry completely before storing it.

Disposal Instructions

- **Recycling:** When the ACHRO™ Sling Bag reaches the end of its life, please dispose of it responsibly. Check local regulations for recycling options for textile products.
- **NonRecyclable Parts:** Any nonrecyclable components, such as zippers or plastic clips, should be disposed of in accordance with local waste management guidelines.

Contact Information for Further Support

For any questions or concerns regarding the ACHRO™ 10L EDC Sling Bag, please refer to the contact information provided by your retailer or manufacturer.

By following these safety instructions, you can ensure a safe and enjoyable experience with your ACHRO™ 10L EDC Sling Bag. Thank you for your attention to safety!

Guida alle Istruzioni di Sicurezza del Prodotto

Introduzione

Grazie per aver scelto la borsa ACHRO™ 10L EDC Sling Bag. Questo prodotto è progettato per offrire funzionalità e discrezione nella vita quotidiana. Per garantire un uso sicuro e responsabile, si prega di seguire attentamente le istruzioni di sicurezza e le linee guida contenute in questo documento.

Linee Guida Generali di Sicurezza

- Assicurarsi che la borsa non sia utilizzata da bambini senza supervisione.
- Verificare che la borsa non presenti danni visibili prima dell'uso.
- Non sovraccaricare la borsa oltre il peso massimo consigliato di 1.95 lbs.
- Non utilizzare la borsa in condizioni meteorologiche estreme senza protezione aggiuntiva.
- Controllare regolarmente le cerniere, le cuciture e le fibbie per segni di usura.
- In caso di utilizzo di accessori aggiuntivi, assicurarsi che siano compatibili e sicuri.

Precauzioni di Sicurezza Specifiche per l'Uso

- **Uso della Fodera per Armi:** Assicurarsi che qualsiasi arma o oggetto pericoloso sia riposto nella fodera dedicata e che sia ben fissato.
- **Imbracatura:** Regolare l'imbracatura spalla in modo da garantire una vestibilità sicura e confortevole. Assicurarsi che non ci siano parti della borsa che possano impigliarsi.
- **Accesso al Comparto Principale:** Utilizzare la zip del pannello con attenzione per evitare di danneggiare il tessuto o le cerniere.
- **Tasche Interni:** Assicurarsi che gli oggetti riposti nelle tasche interne siano ben organizzati e non creino ingombro.

Istruzioni per l'Installazione e l'Uso

- **Regolazione dell'Imbracatura:**
 1. Indossare la borsa sulla spalla desiderata.
 2. Regolare le cinghie dell'imbracatura fino a raggiungere una vestibilità comoda.
- **Utilizzo della Piattaforma MultiMontaggio:**
 1. Assicurarsi che la piattaforma sia fissata correttamente alla borsa.
 2. Attaccare gli accessori compatibili secondo le istruzioni fornite con gli accessori stessi.
- **Accesso ai Compartimenti:**
 1. Utilizzare le zip per accedere ai compartimenti interni e assicurarsi che siano completamente chiusi dopo l'uso.
 2. Per accedere al comparto posteriore destinato al tablet, aprire la zip con attenzione.
- **Pulizia della Borsa:**
 1. Per la pulizia, utilizzare un panno umido e detergenti delicati.
 2. Non immergere la borsa in acqua e non utilizzare candeggina.

Istruzioni per lo Smaltimento

- Smaltire la borsa secondo le normative locali per i rifiuti.

- Se il prodotto è danneggiato e non può più essere utilizzato, assicurarsi di smaltirlo in modo responsabile per ridurre l'impatto ambientale.
- Rimuovere eventuali accessori o componenti non biodegradabili prima dello smaltimento.

Informazioni di Contatto per Ulteriore Supporto

Per domande o chiarimenti sulla sicurezza del prodotto, contattare il punto di contatto locale dell'Unione Europea per la sicurezza dei prodotti.

Conclusione

Seguire queste istruzioni di sicurezza contribuirà a garantire un'esperienza d'uso positiva e sicura con la borsa ACHRO™ 10L EDC Sling Bag. Si raccomanda di conservare questa guida per riferimento futuro e di rimanere informati su eventuali aggiornamenti o richiami relativi al prodotto.