

CAM-LOCK® CASE TRIMMER PILOTS - CAM-LOCK CASE TRIMMER PILOT .41 CALIBER(0.416")

[Reloading](#) > [Case Preparation](#) > [Case Trimming](#) > [Case Trimmer Pilots](#)

CAM-LOCK CASE TRIMMER PILOTS Hornady® trimmer pilots are interchangeable in the Hornady Cam Lock Trimmer. SPECIFICATIONS:
Hardened Steel Available From .17 Caliber to .50 Caliber



Attributes

- Name: [CAM-LOCK CASE TRIMMER PILOT .41 CALIBER\(0.416"\)](#)
- Manufacturer: [HORNADY](#)
- Product no.: 749000350
- Mfr. No.: 390959
- Caliber: 41 Caliber (.410-.412)
- Delivery weight: 0.045kg
- Shipping height: 13mm
- Shipping width: 51mm
- Shipping length: 79mm
- UPC: 090255909593

Item details

Made in USA
EU Export Disabled

Table of Contents

- Startpage
- CAMLOCK® Case Trimmer Pilots Safety Instructions
- About Us

CAMLOCK® Case Trimmer Pilots Safety Instructions

Introduction

Thank you for choosing the CAMLOCK® Case Trimmer Pilots. This product is designed for use with Hornady® Cam Lock Trimmers and is suitable for trimming cases of various calibers. To ensure safe and effective use of this product, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always read the product manual before use.
- Ensure that all safety precautions are followed to prevent accidents and injuries.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the product for any damage before use. Do not use if damaged.
- Use the product only for its intended purpose.
- Report any unsafe products or incidents to the relevant authorities.

Specific Safety Precautions for Use

- Use eye protection when operating the trimmer to prevent injury from flying debris.
- Keep hands and loose clothing away from moving parts during operation.
- Do not exceed the recommended caliber specifications for the trimmer pilots.
- Ensure the trimmer is securely mounted before use to prevent movement.
- Do not attempt to modify or repair the product yourself. Seek professional assistance if needed.

Instructions for Installation and Usage

1. Installation

- Ensure that your Hornady® Cam Lock Trimmer is unplugged before installation.
- Select the appropriate CAMLOCK® Case Trimmer Pilot for your caliber.
- Insert the pilot into the trimmer according to the manufacturer's instructions.
- Secure the pilot in place to ensure proper operation.

2. Usage

- Plug in the trimmer and ensure it is properly set up.
- Place the case to be trimmed onto the trimmer.
- Activate the trimmer according to the manufacturer's instructions.
- Monitor the trimming process closely to ensure safety and accuracy.
- Once trimming is complete, turn off and unplug the trimmer before removing the case.

Disposal Instructions

- Dispose of the CAMLOCK® Case Trimmer Pilots in accordance with local regulations.
- Do not dispose of the product in household waste. Check for recycling options.
- If the product is damaged beyond repair, contact your local waste management service for proper disposal.

Contact Information for Further Support

For any inquiries regarding safety or product support, please refer to the manufacturer's contact details provided with the product packaging or on the official website.

Thank you for prioritizing safety while using the CAMLOCK® Case Trimmer Pilots. Your adherence to these guidelines helps ensure a safe and enjoyable experience.

About Us

Brownells Deutschland

**Brownells Deutschland - Einer der größten Lieferanten für Waffenteile,
Büchsenmacherwerkzeug & Schießsportzubehör**

Lahnstraße 1
24539 Neumünster
Deutschland

www.brownells-deutschland.de