

PRESS TYPE SHELLHOLDERS - #10 PRESS TYPE SHELLHOLDER

Hornady Shell Holders are precision machined from solid steel then heat treated to perform flawlessly for the life of the press. They fit all other Hornady accessories (Case Trimmer, Hand-Held Priming Tool, etc.). Hornady steel shell holders also fit most other brands of reloading presses. View Hornady Shellholder Chart.



Attributes

- Name: #10 PRESS TYPE SHELLHOLDER
- Manufacturer: HORNADY
- Product no.: 749000492
- Mfr. No.: 390550
- Cartridge: 40 S&W,10 mm Auto
- Style: Press Type
- Delivery weight: 0.002kg
- Shipping height: 16mm
- Shipping width: 46mm
- Shipping length: 76mm
- UPC: 090255905502

Item details

Made in USA
EU Export Disabled

Table of Contents

- Startpage
- Deutsch: Sicherheitshinweise für Hornady Press Type Shellholder #10
- English: Safety Instructions for Hornady Press Type Shellholders #10

Sicherheitshinweise für Hornady Press Type Shellholder #10

Einführung

Vielen Dank, dass Sie sich für den Hornady Press Type Shellholder #10 entschieden haben. Um sicherzustellen, dass Sie das Produkt sicher und effektiv nutzen, haben wir diese Sicherheitsanweisungen erstellt. Bitte lesen Sie diese sorgfältig durch, bevor Sie das Produkt verwenden.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass der Shellholder nur mit kompatiblen HornadyWiederladepressen verwendet wird.
- Überprüfen Sie vor der Verwendung regelmäßig auf Anzeichen von Beschädigungen oder Abnutzung.
- Lagern Sie den Shellholder an einem trockenen, sicheren Ort, der für Kinder unzugänglich ist.
- Verwenden Sie den Shellholder nur für den vorgesehenen Zweck.

Spezifische Sicherheitsvorkehrungen für die Verwendung

- Tragen Sie immer geeignete Schutzausrüstung, wie z.B. Schutzbrille und Handschuhe, während der Verwendung.
- Halten Sie den Arbeitsbereich sauber und frei von unnötigen Materialien, um Unfälle zu vermeiden.
- Vermeiden Sie es, den Shellholder zu verwenden, wenn Sie müde oder abgelenkt sind.
- Verwenden Sie keine übermäßige Kraft beim Einsetzen oder Entfernen des Shellholders.

Anweisungen zur Installation und Nutzung

1. Installation:

- Stellen Sie sicher, dass die Presse ausgeschaltet und von der Stromquelle getrennt ist.
- Wählen Sie den richtigen Shellholder für die verwendete Patrone (10 mm Auto, 40 S&W).
- Setzen Sie den Shellholder vorsichtig in die Presse ein, bis er einrastet.

2. Nutzung:

- Überprüfen Sie vor der Verwendung, ob der Shellholder sicher in der Presse sitzt.
- Laden Sie die Patrone gemäß den Anweisungen des Wiederladehandbuchs.
- Achten Sie darauf, dass keine Finger oder andere Körperteile in den Arbeitsbereich der Presse gelangen.
- Nach der Verwendung reinigen Sie den Shellholder und lagern Sie ihn sicher.

Entsorgungsanweisungen

- Entsorgen Sie beschädigte oder nicht mehr benötigte Shellholder gemäß den örtlichen Vorschriften für Metallabfälle.
- Stellen Sie sicher, dass alle Teile ordnungsgemäß entsorgt werden, um Umweltschäden zu vermeiden.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder weitere Informationen zu Sicherheitsanfragen wenden Sie sich bitte an den Kundendienst von Hornady oder besuchen Sie die offizielle Website.

Schlussfolgerung

Die Sicherheit hat oberste Priorität. Indem Sie diese Anweisungen befolgen, tragen Sie dazu bei, Unfälle zu vermeiden und die Lebensdauer Ihres Hornady Press Type Shellholder #10 zu maximieren. Vielen Dank für Ihre Aufmerksamkeit und viel Erfolg beim Wiederladen!

Safety Instructions for Hornady Press Type Shellholders #10

Introduction

Thank you for choosing the Hornady Press Type Shellholders #10. This product is designed for precision reloading, ensuring optimal performance and compatibility with various reloading presses. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Always follow the manufacturer's instructions and guidelines when using the product.
- Ensure that the work area is clean, welllit, and free of distractions.
- Keep the product out of reach of children and unauthorized persons.
- Regularly inspect the shellholder for wear or damage before each use.
- Report any unsafe products or incidents to the relevant authorities.
- Stay informed about product recalls by checking the EU Safety Gate platform.

Specific Safety Precautions for Use

- Use the Hornady Press Type Shellholders only with compatible cartridges: 10 mm Auto and 40 S&W.
- Do not exceed the recommended load limits for your reloading press.
- Always wear appropriate eye and ear protection while reloading.
- Ensure that the shellholder is securely attached to the press before use.
- Avoid using excessive force when inserting or removing the shellholder.
- Do not modify the shellholder in any way, as this may compromise safety and functionality.
- If you experience any issues during use, stop immediately and consult the product manual or contact support.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and unplugged.
- Locate the shellholder slot on your press.
- Align the Hornady Press Type Shellholder with the slot and insert it gently until it is fully seated.
- Check to ensure the shellholder is securely in place before proceeding.

2. Usage:

- Load the appropriate cartridge (10 mm Auto or 40 S&W) into the shellholder.
- Follow the reloading process as outlined in your press's manual.
- Monitor the reloading process closely to ensure safety and accuracy.
- After use, remove the shellholder from the press and store it in a safe place.

Disposal Instructions

- Dispose of any damaged or worn shellholders according to local regulations.
- Do not dispose of shellholders in regular household waste.
- Contact your local waste management facility for guidance on proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the Hornady Press Type Shellholders #10, please refer to the product manual or contact the manufacturer directly for assistance.

Thank you for your attention to these safety instructions. Enjoy safe and effective reloading with your Hornady Press Type Shellholders.