

LOCK-N-LOAD RIMFIRE THICKNESS GAUGE

Hornady Rimfire Thickness Gauge allows shooters to sort their ammo by rim thickness. Sorting ammo by thickness has been proven to aid accuracy. The gauge attaches to the blade of a 6 inch caliper and includes bushings to use for all .17 and .22 caliber rimfire ammo including the new 17 HMR, HM2, and 22 Magnum ammo. Easy to use and enables you to sort through ammo quickly.



Attributes

- Name: LOCK-N-LOAD RIMFIRE THICKNESS GAUGE
- Manufacturer: HORNADY
- Product no.: 749004358
- Mfr. No.: RF17
- Delivery weight: 0.045kg
- Shipping height: 36mm
- Shipping width: 94mm
- Shipping length: 155mm
- UPC: 090255704150

Item details

Made in USA
EU Export Disabled

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für den HORNADY LOCKNLOAD RIMFIRE THICKNESS GAUGE](#)
- [English: LOCKNLOAD RIMFIRE THICKNESS GAUGE Safety Instruction Guide](#)

Sicherheitshinweise für den HORNADY LOCKNLOAD RIMFIRE THICKNESS GAUGE

Einführung

Herzlichen Glückwunsch zu Ihrem Kauf des HORNADY LOCKNLOAD RIMFIRE THICKNESS GAUGE! Dieses Produkt wurde entwickelt, um Ihnen beim Sortieren Ihrer RandfeuerMunition nach Randdicke zu helfen. Um die Sicherheit und die bestmögliche Nutzung Ihres Geräts zu gewährleisten, lesen Sie bitte die folgenden Sicherheitshinweise sorgfältig durch.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass das Produkt nur in Übereinstimmung mit den Anweisungen verwendet wird.
- Halten Sie das Produkt außerhalb der Reichweite von Kindern und schutzbedürftigen Personen.
- Verwenden Sie das Gerät nur für den vorgesehenen Zweck.
- Überprüfen Sie das Produkt regelmäßig auf Beschädigungen oder Abnutzungserscheinungen.
- Melden Sie unsichere Produkte oder Vorfälle den zuständigen Behörden.

Spezifische Sicherheitsvorkehrungen für die Verwendung

- Verwenden Sie das Messgerät nur mit einem 6ZollCaliper.
- Vergewissern Sie sich, dass die Buchsen korrekt für die jeweiligen Kaliber eingesetzt sind.
- Achten Sie darauf, dass die Klinge des Calipers nicht beschädigt ist, um genaue Messungen zu gewährleisten.
- Tragen Sie geeignete Schutzausrüstung, wenn Sie mit Munition arbeiten.
- Verwenden Sie das Gerät nicht, wenn Sie müde oder abgelenkt sind.

Anweisungen zur Installation und Nutzung

1. Installation

- Befestigen Sie das Messgerät an der Klinge eines 6ZollCalipers.
- Stellen Sie sicher, dass das Gerät fest sitzt und nicht wackelt.

2. Nutzung

- Wählen Sie die passende Buchse für das Kaliber Ihrer Munition (.17 oder .22).
- Führen Sie die Munition in die Buchse ein und messen Sie die Randdicke.
- Notieren Sie die Ergebnisse zur späteren Verwendung.
- Sortieren Sie die Munition entsprechend der gemessenen Dicke.

Entsorgungsanweisungen

- Entsorgen Sie das Produkt gemäß den örtlichen Vorschriften für Elektro und Elektronikgeräte.
- Bringen Sie das Gerät nicht in den Hausmüll.
- Informieren Sie sich über spezielle Sammelstellen in Ihrer Nähe.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder Unterstützung bezüglich des HORNADY LOCKNLOAD RIMFIRE THICKNESS GAUGE wenden Sie sich bitte an den entsprechenden Kundenservice oder den Händler, bei dem Sie das Produkt erworben haben.

LOCKNLOAD RIMFIRE THICKNESS GAUGE Safety Instruction Guide

Introduction

Thank you for choosing the Hornady LockNLoad Rimfire Thickness Gauge. This product is designed to help shooters sort their ammunition by rim thickness, which can improve accuracy. Please read this safety instruction guide carefully to ensure the safe and effective use of the product.

General Safety Guidelines

- Always read and understand the user manual before using the product.
- Ensure that the gauge is in good condition before each use. Inspect for any signs of damage or wear.
- Keep the gauge out of reach of children and vulnerable individuals to prevent misuse.
- Use the gauge only for its intended purpose, which is sorting rimfire ammunition by thickness.
- Follow all local laws and regulations regarding the handling and use of ammunition.

Specific Safety Precautions for Use

- Do not use the gauge if it is damaged or malfunctioning.
- Always handle ammunition with care and ensure that firearms are unloaded when sorting ammunition.
- Avoid using the gauge in wet or damp conditions to prevent damage.
- Do not exceed the recommended rim thickness measurements specified in the user manual.
- Store the gauge in a safe and dry location when not in use.

Instructions for Installation and Usage

1. Attaching the Gauge:

- Attach the gauge to the blade of a 6inch caliper according to the instructions provided in the user manual.
- Ensure that the gauge is securely fastened to avoid any movement during use.

2. Using the Gauge:

- Select the appropriate bushing for the caliber of rimfire ammunition you are sorting (e.g., .17, .22, 17 HMR, HM2, or 22 Magnum).
- Insert the rim of the ammunition into the bushing and read the thickness measurement on the caliper.
- Record the measurements as needed for sorting purposes.

3. Cleaning and Maintenance:

- Clean the gauge regularly with a soft cloth to remove any debris or residue.
- Store the gauge in its original packaging or a protective case to prevent damage.

Disposal Instructions

- When the gauge is no longer in use or is beyond repair, dispose of it according to local regulations for electronic waste and nonfood products.
- Ensure that all components are properly recycled or discarded to minimize environmental impact.

Contact Information for Further Support

For any safety inquiries or further assistance, please refer to the contact information provided in the product documentation or visit the manufacturer's website.

By following these guidelines, you can ensure the safe and effective use of your Hornady LockNLoad Rimfire Thickness Gauge. Thank you for your attention to safety and for choosing our product.