

# **LOCK-N-LOAD AP SHELLPLATE - #32 LOCK-N-LOAD AP PROGRESSIVE PRESS SHELLPLATE**

[Reloading](#) > [Shellholders & Shellplates](#)

Shell plates for Lock-N-Load AP and Pro-Jector are available to fit most calibers. Each shell plate will also hold additional calibers with the same case head dimensions. Current shell plates are designed to fit Lock-N-Load AP (both EZ-Ject and wire ejector models) and Pro-Jector presses. These shell plates require the purchase of the 749-012-552 Hornady Auto press retrofit kit if your press still has the OLD STYLE SPRING TYPE CARTRIDGE CASE EJECTOR SYSTEM. If you have any questions please contact your Sinclair tech 800-717-8211. View Hornady Shellplate Chart.



## **Attributes**

- Name: [#32 LOCK-N-LOAD AP PROGRESSIVE PRESS SHELLPLATE](#)
- Manufacturer: [HORNADY](#)
- Product no.: 749004983
- Mfr. No.: 392632
- Náboje: 45 (Long) Colt
- Style: Press Type
- Delivery weight: 0.249kg
- Shipping height: 18mm
- Shipping width: 99mm
- Shipping length: 112mm
- UPC: 090255926323

## **Item details**

Made in USA

# Table of Contents

- Startpage
- LOCKNLOAD AP SHELLPLATE #32 Safety Instruction Guide
- About Us

# LOCKNLOAD AP SHELLPLATE #32 Safety Instruction Guide

## Introduction

Thank you for choosing the LOCKNLOAD AP SHELLPLATE #32. This product is designed to enhance your reloading experience with the LockNLoad AP and Projector presses. It is essential to follow safety guidelines to ensure safe and effective use of this product. This guide provides important safety information, installation instructions, and contact details for further support.

## General Safety Guidelines

- Ensure that you read and understand all instructions before using the shellplate.
- Always use the shellplate in accordance with the manufacturer's specifications.
- Keep the shellplate out of reach of children and vulnerable individuals.
- Regularly inspect the shellplate for any signs of wear or damage before use.
- Do not attempt to modify or repair the shellplate yourself.
- Report any unsafe conditions or accidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform.

## Specific Safety Precautions for Use

- Use the shellplate only with LockNLoad AP (both EZject and wire ejector models) and Projector presses.
- Ensure that your press is equipped with the correct ejector system. If your press has the OLD STYLE SPRING TYPE CARTRIDGE CASE EJECTOR SYSTEM, purchase the 749012552 Hornady Auto press retrofit kit.
- Avoid using the shellplate with cartridges that do not match the specified case head dimensions.
- Always wear appropriate personal protective equipment (PPE), such as safety glasses, when operating the press.
- Do not overload the shellplate beyond its intended capacity.
- Follow all local regulations regarding the handling and storage of ammunition components.

## Instructions for Installation and Usage

### 1. Installation:

- Ensure that the press is turned off and unplugged before installation.
- Remove any existing shellplate from the press.
- Align the LOCKNLOAD AP SHELLPLATE #32 with the press mount.
- Secure the shellplate in place according to the manufacturer's instructions.

### 2. Usage:

- Confirm that the shellplate is properly installed and secured before use.
- Load the appropriate cartridge into the shellplate, ensuring that it fits snugly.
- Operate the press according to the manufacturer's instructions for reloading.
- Regularly check the shellplate during operation for any signs of malfunction or wear.

### 3. PostUse:

- After reloading, remove the shellplate from the press if not in use.
- Clean the shellplate with a dry cloth to remove any debris or residues.
- Store the shellplate in a cool, dry place away from direct sunlight.

## **Disposal Instructions**

- Dispose of the shellplate in accordance with local waste management regulations.
- If the shellplate is damaged beyond repair, do not attempt to reuse it.
- Recycle materials where applicable and ensure environmentally friendly disposal.

## **Contact Information for Further Support**

For any questions or concerns regarding the LOCKNLOAD AP SHELLPLATE #32, please contact your local Sinclair tech support. They are available to assist you with any technical inquiries or product issues.

By following these safety instructions, you can ensure a safe and effective reloading experience with your LOCKNLOAD AP SHELLPLATE #32. Thank you for your attention to these important guidelines.

# About Us

## **Brownells Česká republika**

**Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

[www.brownells.cz](http://www.brownells.cz)