

LOCK-N-LOAD AP SHELLPLATE - #45 LOCK-N-LOAD AP PROGRESSIVE PRESS SHELLPLATE

[Reloading](#) > [Shellholders & Shellplates](#)

Shell plates for Lock-N-Load AP and Pro-Jector are available to fit most calibers. Each shell plate will also hold additional calibers with the same case head dimensions. Current shell plates are designed to fit Lock-N-Load AP (both EZ-Ject and wire ejector models) and Pro-Jector presses. These shell plates require the purchase of the 749-012-552 Hornady Auto press retrofit kit if your press still has the OLD STYLE SPRING TYPE CARTRIDGE CASE EJECTOR SYSTEM. If you have any questions please contact your Sinclair tech 800-717-8211. View Hornady Shellplate Chart.



Attributes

- Name: [#45 LOCK-N-LOAD AP PROGRESSIVE PRESS SHELLPLATE](#)
- Manufacturer: [HORNADY](#)
- Product no.: 749004987
- Mfr. No.: 392645
- Náboje: 400 Corbon,45 Auto (ACP)
- Style: Press Type
- Delivery weight: 0.249kg
- Shipping height: 18mm
- Shipping width: 104mm
- Shipping length: 118mm
- UPC: 090255926453

Item details

Made in USA

Table of Contents

- Startpage
- LOCKNLOAD AP SHELLPLATE #45 Safety Instruction Guide
- About Us

LOCKNLOAD AP SHELLPLATE #45 Safety Instruction Guide

Introduction

Thank you for choosing the LOCKNLOAD AP SHELLPLATE #45. This guide provides essential safety instructions and information to ensure the safe and effective use of this product. Please read this manual carefully before using the shell plate.

General Safety Guidelines

- Ensure that you are familiar with the operation of your LockNLoad AP or Projector press before using the shell plate.
- Always follow the manufacturer's instructions for your reloading equipment.
- Store the shell plate in a dry, cool place away from direct sunlight and moisture.
- Regularly inspect the shell plate for any signs of wear or damage. Replace if necessary.
- Keep the shell plate out of reach of children and pets to prevent accidents.
- If you experience any issues while using the shell plate, stop using it immediately and consult a qualified technician.

Specific Safety Precautions for Use

- Always wear appropriate eye protection while reloading.
- Ensure that the press is securely mounted and stable before use.
- Do not attempt to modify or alter the shell plate or press in any way.
- Use only the recommended cartridge types specified for this shell plate.
- Be aware of the potential hazards associated with reloading ammunition, including handling of gunpowder and primers.
- Do not leave the press unattended while in operation.
- Follow all local laws and regulations regarding ammunition reloading and storage.

Instructions for Installation and Usage

1. Compatibility Check:

- Ensure that your press is compatible with the LOCKNLOAD AP SHELLPLATE #45. This shell plate is designed for use with LockNLoad AP (both EZJect and wire ejector models) and Projector presses.

2. Installation:

- Remove the existing shell plate from your press if applicable.
- Align the LOCKNLOAD AP SHELLPLATE #45 with the mounting points on your press.
- Securely fasten the shell plate to the press according to the manufacturer's instructions.

3. Using the Shell Plate:

- Insert the cartridge cases into the shell plate ensuring they are seated correctly.
- Follow your press's operation manual to cycle the press and begin reloading.
- Monitor the reloading process closely for any irregularities.

4. Retrofitting:

- If your press is equipped with an OLD STYLE SPRING TYPE CARTRIDGE CASE EJECTOR SYSTEM, you

must purchase the 749012552 Hornady Auto press retrofit kit before using this shell plate.

Disposal Instructions

- Dispose of any damaged or worn shell plates in accordance with local regulations.
- Do not dispose of the shell plate in regular household waste. Check for recycling options in your area.
- Follow local laws regarding the disposal of ammunition components.

Contact Information for Further Support

For any safety inquiries or technical support regarding the LOCKNLOAD AP SHELLPLATE #45, please reach out to the appropriate customer service or technical support channels provided by the manufacturer.

We hope this guide helps you use your LOCKNLOAD AP SHELLPLATE #45 safely and effectively. Always prioritize safety and compliance with local regulations while reloading ammunition.

About Us

Brownells Česká republika

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.cz