

TRIM PRO 3-WAY CUTTERS - 270 CALIBER TRIM PRO 3-WAY CUTTER

[Reloading](#) > [Case Preparation](#) > [Case Trimming](#) > [Replacement Cutters](#)

The RCBS 3-Way Cutter is designed for use on Trim Pro Case Trimmers and reduces the trimming /deburring chore. The 3-Way Cutter not only trims cases to lengths but an inside blade chamfers the case while an outside blade deburrs it. Install on all Trim Pro Case Trimmers. Order one 3-Way Cutter by caliber and then simply order additional chamfer/pilots for other calibers.



Attributes

- Name: [270 CALIBER TRIM PRO 3-WAY CUTTER](#)
- Manufacturer: [RCBS](#)
- Product no.: 749005900
- Mfr. No.: 90282
- Caliber: 270/6.8 mm (.277)
- Delivery weight: 0.045kg
- Shipping height: 48mm
- Shipping width: 56mm
- Shipping length: 99mm
- UPC: 076683902825

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for TRIM PRO 3WAY CUTTERS 270 CALIBER
- About Us

Safety Instruction Guide for TRIM PRO 3WAY CUTTERS 270 CALIBER

Introduction

Thank you for choosing the TRIM PRO 3WAY CUTTERS 270 CALIBER. This product is designed to efficiently trim and deburr cases, making your reloading process easier and more effective. To ensure your safety and the proper use of this product, please read this safety instruction guide carefully.

General Safety Guidelines

- Always read and follow the manufacturer's instructions before using the product.
- Ensure that the product is used for its intended purpose only.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage before use.
- In case of any malfunction or if you suspect the product is unsafe, stop using it immediately and report it to the appropriate authorities.
- Stay informed about any recall updates via the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE), such as safety glasses, when using the cutter.
- Ensure that the work area is clean and welllit to avoid accidents.
- Keep hands and other body parts clear of the cutting blades during operation.
- Do not force the cutter; if it does not operate smoothly, stop and check for obstructions or damage.
- Use caution when changing blades or performing maintenance on the cutter.
- Never leave the cutter unattended while in use.

Instructions for Installation and Usage

1. Installation:

- Ensure that the Trim Pro Case Trimmer is unplugged before installation.
- Remove any existing cutter from the trimmer.
- Align the 3Way Cutter with the mounting hole on the Trim Pro Case Trimmer.
- Secure the cutter in place according to the manufacturer's instructions.
- Doublecheck that the cutter is tightly secured before plugging in the trimmer.

2. Usage:

- Plug in the Trim Pro Case Trimmer and turn it on.
- Insert the case into the cutter, ensuring it is properly aligned.
- Gently push the case into the cutter until the desired length is reached.
- After trimming, remove the case and check for any burrs.
- If necessary, use the inside blade to chamfer and the outside blade to deburr the case.
- Turn off the trimmer and unplug it after use.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- Check with local authorities for specific disposal guidelines for tools and blades.

Contact Information for Further Support

For any inquiries regarding safety or product performance, please contact the manufacturer or refer to the product packaging for additional support resources.

Thank you for your attention to these safety guidelines. By following these instructions, you can ensure a safer and more effective experience with your TRIM PRO 3WAY CUTTERS 270 CALIBER.

About Us

Brownells Switzerland

Brownells Switzerland

www.brownells.ch