

AP POWDER THRU EXPANDERS (PTX) - 45 CALIBER (0.452-0.454") POWDER THROUGH EXPANDER

[Reloading](#) > [Reloading Presses](#) > [Progressive Presses](#)

A component of Hornady Lock-N-Load Auto Progressive Press (AP) accessories that enables you to have the fastest cartridge conversion on the market.

Image disclaimer: Expanders may vary in diameter size as shown in the image.



Attributes

- Name: [45 CALIBER \(0.452-0.454"\) POWDER THROUGH EXPANDER](#)
- Manufacturer: [HORNADY](#)
- Product no.: 749012176
- Mfr. No.: 290036
- Delivery weight: 0.045kg
- Shipping height: 23mm
- Shipping width: 43mm
- Shipping length: 117mm
- UPC: 090255900361

Item details

Made in USA
EU Export Disabled

Table of Contents

- Startpage
- Safety Instruction Guide for AP Powder Thru Expanders (PTX) 45 Caliber
- About Us

Safety Instruction Guide for AP Powder Thru Expanders (PTX) 45 Caliber

Introduction

Thank you for choosing the AP Powder Thru Expanders (PTX) 45 Caliber (0.4520.454") Powder Through Expander. This product is designed to enhance the efficiency of your Hornady LockNLoad Auto Progressive Press (AP). To ensure safe and effective use of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Always store the product in a dry, cool place away from direct sunlight.
- Keep the product out of reach of children and pets.
- Regularly inspect the product for any signs of wear or damage before use.
- Follow all local laws and regulations regarding the use of reloading equipment and components.

Specific Safety Precautions for Use

- Use appropriate personal protective equipment (PPE) such as safety glasses and gloves when handling components.
- Do not exceed the recommended load data provided by the manufacturer.
- Ensure that the work area is wellventilated to avoid inhalation of any dust or particles.
- Do not use the expander if it appears to be damaged or malfunctioning.
- Always read the instructions and safety guidelines provided with your Hornady LockNLoad Auto Progressive Press (AP) before use.

Instructions for Installation and Usage

1. Installation:

- Ensure that the Hornady LockNLoad Auto Progressive Press (AP) is turned off and unplugged before installation.
- Remove any existing expanders from the press.
- Carefully insert the AP Powder Thru Expander into the appropriate station on the press.
- Secure the expander in place according to the manufacturer's instructions.

2. Usage:

- Once installed, adjust the expander to the desired height for proper cartridge conversion.
- Load the press with the appropriate components as specified in the reloading manual.
- Monitor the operation of the expander during use to ensure consistent performance.
- After completing the reloading process, clean the expander to remove any residue.

Disposal Instructions

- Dispose of any packaging materials in accordance with local recycling regulations.
- If the expander becomes damaged beyond repair, dispose of it in accordance with local waste management guidelines.
- Do not dispose of any hazardous materials in regular trash.

Contact Information for Further Support

For any safety inquiries or support related to the AP Powder Thru Expanders (PTX) 45 Caliber, please refer to the manufacturer's website or customer service for assistance.

About Us

Brownells Deutschland

**Brownells Deutschland - Einer der größten Lieferanten für Waffenteile,
Büchsenmacherwerkzeug & Schießsportzubehör**

Lahnstraße 1
24539 Neumünster
Deutschland

www.brownells-deutschland.de