

BULLET FEEDER PISTOL DIES - 40/10MM BULLET FEEDER DIE

[Reloading](#) > [Reloading Presses](#) > [Progressive Presses](#)

Use these Lock-N-Load Bullet Feeder Pistol Dies with the Lock-N-Load Bullet Feeder to speed your reloading process so you can spend more time at the range or in the field. Tube and collet design holds the bullet securely in the die until a fresh case contacts the collet for a smooth work flow. Solid steel construction ensures years of reloading. No special tools required, and each die is threaded in the 7/8"-14 industry standard. Lock-N-Load Bullet Feeder and Bullet Tubes available separately.



Attributes

- Name: [40/10MM BULLET FEEDER DIE](#)
- Manufacturer: [HORNADY](#)
- Product no.: 749012342
- Mfr. No.: 095332
- Delivery weight: 0.363kg
- Shipping height: 23mm
- Shipping width: 33mm
- Shipping length: 147mm
- UPC: 090255953329

Item details

Made in USA
EU Export Disabled

Table of Contents

- [Startpage](#)
- [BULLET FEEDER PISTOL DIES 40/10MM SAFETY INSTRUCTION GUIDE](#)
- [About Us](#)

BULLET FEEDER PISTOL DIES 40/10MM SAFETY INSTRUCTION GUIDE

Introduction

Thank you for choosing the BULLET FEEDER PISTOL DIES 40/10MM. This guide provides essential safety instructions to ensure the safe use of this product. Please read this document carefully before using the product and keep it for future reference.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Always handle the dies with care to prevent injury.
- Keep the dies out of reach of children and unauthorized users.
- Use personal protective equipment, such as safety glasses and gloves, when reloading ammunition.
- Regularly inspect the product for any signs of wear or damage before use.
- Follow local laws and regulations regarding ammunition reloading and firearm use.

Specific Safety Precautions for Use

- Do not exceed the recommended load limits specified for your reloading equipment.
- Always ensure that the work area is clean and free of obstructions.
- Avoid distractions while reloading; focus on the task at hand.
- Never point the die or any loaded ammunition towards yourself or others.
- Store the dies and ammunition in a secure location when not in use.
- Be aware of the potential risks associated with reloading, including the handling of gunpowder and primers.

Instructions for Installation and Usage

Installation

1. Ensure that your LockNLoad Bullet Feeder is properly installed and functioning.
2. Thread the BULLET FEEDER PISTOL DIE into the press using the 7/8"14 industry standard thread.
3. Secure the die firmly, ensuring there is no movement during operation.

Usage

1. Load the bullet feeder tubes with the appropriate bullets.
2. Adjust the collet to hold the bullet securely.
3. Place an empty case in the press and activate the feeder to ensure a smooth workflow.
4. Monitor the reloading process continuously, ensuring that the die is functioning correctly.
5. If a jam occurs, stop the operation immediately and clear the obstruction before continuing.

Disposal Instructions

- Dispose of any broken or wornout parts in accordance with local regulations.
- Ensure that all materials used in the reloading process, including spent primers and gunpowder, are disposed of safely and responsibly.
- Check local guidelines for the disposal of hazardous materials.

Contact Information for Further Support

For any inquiries or support regarding the BULLET FEEDER PISTOL DIES 40/10MM, please consult your retailer or manufacturer's website for assistance. Always refer to the latest safety information and updates.

By following these safety instructions, you can ensure a safe and efficient reloading experience with your BULLET FEEDER PISTOL DIES 40/10MM. Thank you for your attention to safety and for choosing our product.

About Us

Brownells Deutschland

**Brownells Deutschland - Einer der größten Lieferanten für Waffenteile,
Büchsenmacherwerkzeug & Schießsportzubehör**

Lahnstraße 1
24539 Neumünster
Deutschland

www.brownells-deutschland.de