

REM™ BORE LIGHT EXTENDED FLEX - REMINGTON REM BORE LIGHT EXTENDED FLEX

[Gun Cleaning & Chemicals](#) > [Solvents & Degreasers](#) > [Degreasers](#)

Rem Bore Light with extended flexible light is ideal for inspecting firearms for cleanliness, imperfections, and fouling. Also useful for inspecting used firearms prior to purchasing for barrel imperfections, bulges, tooling marks, scratches, and residue. Flexible shaft for precise light positioning. High intensity LED light beam. Illuminates entire bore. Exposes nicks, scratches, pitting & fouling. Convenient Click on/off button. Applicable for all calibers & gauges. *Requires 2 AA batteries NOT INCLUDED



Attributes

- Name: [REMINGTON REM BORE LIGHT EXTENDED FLEX](#)
- Manufacturer: [REMINGTON](#)
- Product no.: 768001875
- Mfr. No.: 19531
- Delivery weight: 0.067kg
- Shipping height: 32mm
- Shipping width: 108mm
- Shipping length: 229mm
- UPC: 047700195315

Table of Contents

- Startpage
- REM™ BORE LIGHT EXTENDED FLEX Safety Instruction Guide
- About Us

REM™ BORE LIGHT EXTENDED FLEX Safety Instruction Guide

Introduction

Thank you for choosing the REM™ Bore Light Extended Flex. This product is designed to assist in the inspection of firearms, ensuring cleanliness and identifying imperfections. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Always use the product in accordance with the instructions provided in this guide.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the product regularly for any signs of damage or wear.
- Do not use the product if it is damaged or malfunctioning.
- Report any unsafe conditions or accidents to the relevant authorities.
- Stay informed about product recalls through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Avoid direct eye exposure to the LED light beam.
- Do not use the bore light in wet or damp conditions.
- Ensure that the bore light is turned off when not in use to conserve battery life.
- Do not attempt to disassemble or modify the bore light.
- Use only 2 AA batteries as specified; do not mix old and new batteries or different battery types.
- Keep the flexible shaft away from moving parts and machinery.

Instructions for Installation and Usage

1. Battery Installation:

- Open the battery compartment located at the base of the bore light.
- Insert 2 AA batteries, ensuring the correct polarity is observed (+/-).
- Close the battery compartment securely.

2. Using the Bore Light:

- Extend the flexible shaft to the desired length for optimal positioning.
- Position the bore light into the firearm's bore.
- Press the click on/off button to activate the LED light.
- Inspect the bore for cleanliness, imperfections, and fouling.
- After use, turn off the light and retract the flexible shaft.

3. Storage:

- Store the bore light in a cool, dry place away from direct sunlight.
- Ensure the product is clean and free from debris before storage.

Disposal Instructions

- Dispose of the bore light in accordance with local regulations regarding electronic waste.
- Remove the batteries before disposal and recycle them according to local battery recycling guidelines.
- Do not dispose of the bore light in regular household waste.

Contact Information for Further Support

For any inquiries or concerns regarding the REM™ Bore Light Extended Flex, please refer to the manufacturer's contact information provided on the product packaging or user manual.

Thank you for your attention to these safety instructions. Enjoy using your REM™ Bore Light Extended Flex responsibly and safely.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk