


BERETTA 92/96 CALIBRATION PAK - WOLFF CALIBRATION PAK

[Handgun Parts](#) > [Recoil Parts](#) > [Recoil Springs](#)

BERETTA 92/96 CALIBRATION PAK



Attributes

- Name: [WOLFF CALIBRATION PAK](#)
- Manufacturer: [WOLFF](#)
- Product no.: 969131900
- Mfr. No.: 13190
- Model: 92,96
- Pounds: 15 lbs,16 lbs,18 lbs,20 lbs
- Weapon type: Beretta
- Delivery weight: 0.045kg
- Shipping height: 15mm
- Shipping width: 114mm
- Shipping length: 142mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [BERETTA 92/96 CALIBRATION PAK SAFETY INSTRUCTIONS](#)
- [About Us](#)

BERETTA 92/96 CALIBRATION PAK SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the Beretta 92/96 Calibration Pak by Wolff. This product is designed to enhance the performance of your firearm by providing reliable recoil spring options. It is crucial to use this product safely and correctly to ensure optimal performance and user safety.

General Safety Guidelines

- Always treat your firearm as if it is loaded.
- Follow all local laws and regulations regarding firearm usage and modifications.
- Ensure that the area where you are using the firearm is safe and free from unauthorized personnel.
- Store the Calibration Pak and any firearm components in a secure location, out of reach of children and unauthorized users.
- Regularly inspect your firearm and its components for wear and damage.
- Report any unsafe products or incidents to the relevant authorities.

Specific Safety Precautions for Use

- Only use the Beretta 92/96 Calibration Pak with compatible models: Beretta 92 and Beretta 96.
- Ensure that the firearm is unloaded before installing or replacing any components.
- Wear appropriate protective gear, including safety glasses and hearing protection, when using your firearm.
- Do not attempt to modify or alter the recoil springs in any way.
- Keep hands and body away from the muzzle at all times.
- Be aware of your surroundings and ensure a clear shooting lane when using your firearm.

Instructions for Installation and Usage

1. Preparation

- Ensure the firearm is unloaded and pointed in a safe direction.
- Gather necessary tools for installation, if required.

2. Installation of the Calibration Pak

- Remove the existing recoil spring from your Beretta 92 or 96 by following the manufacturer's instructions.
- Carefully unpack the Beretta 92/96 Calibration Pak.
- Select the appropriate recoil spring based on your desired weight (18 lbs, 20 lbs, 16 lbs, or 15 lbs).
- Install the new recoil spring by reversing the removal process. Ensure it is securely in place.

3. Testing

- After installation, perform a function check of the firearm to ensure proper operation.
- If any issues arise, consult a qualified gunsmith before use.

4. Usage

- Once the Calibration Pak is installed correctly, you may proceed to use the firearm as intended.
- Always follow safe handling practices during shooting sessions.

Disposal Instructions

- Dispose of any used recoil springs and packaging materials in accordance with local regulations.
- Do not dispose of firearm components in regular household waste. Check for local recycling or hazardous waste disposal options.

Contact Information for Further Support

For any inquiries regarding the Beretta 92/96 Calibration Pak, please refer to the manufacturer's contact information provided in the product packaging or on their official website.

By following these safety instructions, you can ensure a safe and enjoyable experience while using the Beretta 92/96 Calibration Pak. Thank you for prioritizing safety and compliance with the EU General Product Safety Regulation.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk