

# American Rifle Predator - w/ Cheekriser - .308 Win.

[Firearms](#) > [Rifles](#) > [Bolt Action](#)

## Ruger American Rifle Predator



The Ruger American Rifle Predator combines cutting-edge innovation with Ruger's renowned reliability. Manufactured 100% in the USA, this bolt-action rifle offers exceptional precision and handling.

- **Ergonomic Stock:** Lightweight synthetic stock with a classic design, modern forend styling, and textured grip areas for superior control.
- **Adjustable Trigger:** The Ruger Marksman Adjustable Trigger is externally adjustable between 1.4 and 2.3 kg (3-5 lbs), with the adjustment key securely stored in the bolt.
- **Versatile Performance:** Ideal for hunting and precision shooting under various conditions.

## Attributes

- Name: [RUGER - American Rifle Predator - w/ Cheekriser - .308 Win.](#)
- Manufacturer: [RUGER](#)
- Product no.: BRD113084
- Mfr. No.: 17903528
- Barrel Finish: Matte Black
- Barrel Length: 18"
- Caliber: .308 Winchester
- Capacity: 4-Round
- Color: Moss Green
- Length: 38"
- Make: Ruger
- Material: Alloy Steel
- Model: American Predator
- Muzzle Threads: 5/8-24
- Side: Right
- Twist Rate: 1-10
- Weight: 6.23 lbs
- Delivery weight: 2.8kg
- Shipping height: 200mm
- Shipping width: 25mm
- Shipping length: 965mm

# Table of Contents

- [Startpage](#)
- [Ruger American Rifle Predator Safety Instruction Guide](#)
- [About Us](#)

# Ruger American Rifle Predator Safety Instruction Guide

## Introduction

Thank you for choosing the Ruger American Rifle Predator. This guide provides essential safety instructions to ensure the safe and effective use of your rifle. Please read this guide thoroughly before using the product. Your safety and the safety of others are our top priority.

## General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep the muzzle pointed in a safe direction at all times.
- Ensure that your finger is off the trigger until you are ready to shoot.
- Be aware of your target and what lies beyond it.
- Use appropriate eye and ear protection when shooting.
- Store firearms securely and out of reach of children and unauthorized users.
- Regularly inspect your rifle for any signs of wear or damage.
- Follow all local laws and regulations regarding firearm ownership and use.

## Specific Safety Precautions for Use

- **Handling:** Always handle your rifle with care. Avoid any sudden movements that could lead to accidental discharge.
- **Loading and Unloading:**
  - Ensure the rifle is pointed in a safe direction.
  - Keep the safety engaged until you are ready to fire.
  - Load and unload the rifle in a safe area, free from distractions.
- **Shooting:**
  - Use only the recommended ammunition for your rifle (.308 Winchester).
  - Be mindful of your surroundings and ensure a clear shooting area.
  - Do not shoot at hard surfaces or water, as this can cause ricochets.
- **Cleaning and Maintenance:**
  - Follow the manufacturer's instructions for cleaning and maintenance.
  - Always ensure the rifle is unloaded before cleaning.
  - Use appropriate cleaning materials and tools.

## Instructions for Installation and Usage

- **Installation of Cheekriser:**
  - Ensure the rifle is unloaded before installation.
  - Align the cheekriser with the stock and secure it using the provided screws.
  - Check that the cheekriser is firmly attached before use.
- **Adjusting the Trigger:**
  - The Ruger Marksman Adjustable Trigger can be adjusted between 1.4 and 2.3 kg (3-5 lbs).
  - Use the adjustment key stored in the bolt to make adjustments.
  - Test the trigger after adjustments to ensure proper functionality.
- **Using the Rifle:**
  - Familiarize yourself with the safety features and controls of the rifle.
  - Practice loading and unloading in a safe environment.
  - Start with small targets to improve accuracy and confidence.

## **Disposal Instructions**

- Dispose of your rifle in accordance with local laws and regulations.
- If the rifle is no longer usable, consider contacting a licensed firearms dealer for safe disposal.
- Do not dispose of ammunition in regular trash. Follow local guidelines for hazardous waste disposal.

## **Contact Information for Further Support**

For any questions or concerns regarding the Ruger American Rifle Predator, please refer to your local Ruger dealer or visit the Ruger website for additional resources and support.

## **Conclusion**

By following these safety instructions, you can ensure a safe and enjoyable experience with your Ruger American Rifle Predator. Always prioritize safety and seek assistance if you are unsure about any aspect of firearm handling or usage. Thank you for your commitment to responsible firearm ownership.

# About Us

## Brownells Deutschland

**Brownells Deutschland - Einer der größten Lieferanten für Waffenteile,  
Büchsenmacherwerkzeug & Schießsportzubehör**

Lahnstraße 1  
24539 Neumünster  
Deutschland

[www.brownells-deutschland.de](http://www.brownells-deutschland.de)