

American Rifle Predator - 6.5 Creedmoor 3Rd

Ruger American Rifle Predator

The Ruger American Rifle Predator combines cutting-edge innovation with Ruger's renowned reliability. Manufactured 100% in the USA, this bolt-action rifle offers exceptional precision and handling.

- **Ergonomic Stock:** Lightweight synthetic stock with a classic design, modern forend styling, and textured grip areas for superior control.
- **Adjustable Trigger:** The Ruger Marksman Adjustable Trigger is externally adjustable between 1.4 and 2.3 kg (3–5 lbs), with the adjustment key securely stored in the bolt.
- **Versatile Performance:** Ideal for hunting and precision shooting under various conditions.

Attributes

- Name: RUGER - American Rifle Predator - 6.5 Creedmoor 3Rd
- Manufacturer: RUGER
- Product no.: BRD113086
- Mfr. No.: 17904186
- Barrel Finish: Matte Black
- Barrel Length: 22"
- Caliber: 6.5 Creedmoor
- Capacity: 3-Round
- Color: Moss Green
- Length: 42"
- Make: Ruger
- Material: Alloy Steel
- Model: American Predator
- Muzzle Threads: 5/8-24
- Side: Right
- Twist Rate: 1-8
- Weight: 6.6 lbs
- Delivery weight: 3kg
- Shipping height: 200mm
- Shipping width: 25mm
- Shipping length: 1,067mm
- UPC: 736676269730

Table of Contents

- Startpage
- Deutsch: Sicherheitshinweise für das Ruger American Rifle Predator
- English: Ruger American Rifle Predator Safety Instruction Guide

Sicherheitshinweise für das Ruger American Rifle Predator

Einführung

Vielen Dank, dass Sie sich für das Ruger American Rifle Predator entschieden haben. Dieses Produkt wurde entwickelt, um höchste Präzision und Leistung zu bieten. Es ist jedoch wichtig, die Sicherheitshinweise zu beachten, um eine sichere Verwendung zu gewährleisten.

Allgemeine Sicherheitsrichtlinien

- Achten Sie darauf, dass das Produkt nur von Personen verwendet wird, die mit den Sicherheitsvorschriften für Feuerwaffen vertraut sind.
- Lagern Sie das Gewehr an einem sicheren Ort, der für Kinder unzugänglich ist.
- Verwenden Sie das Gewehr niemals unter dem Einfluss von Alkohol oder Drogen.
- Überprüfen Sie vor jeder Verwendung, ob das Gewehr in einwandfreiem Zustand ist.
- Halten Sie immer den Finger vom Abzug, bis Sie bereit sind zu schießen.

Spezifische Sicherheitsvorkehrungen für die Verwendung

- Verwenden Sie ausschließlich die empfohlenen Munitionstypen (6,5 mm Creedmoor), um Schäden am Gewehr zu vermeiden.
- Vergewissern Sie sich, dass der Lauf frei von Obstruktionen ist, bevor Sie schießen.
- Richten Sie das Gewehr niemals auf etwas, was Sie nicht treffen möchten.
- Tragen Sie immer geeignete Augen und Gehörschutzmittel beim Schießen.
- Verwenden Sie das Gewehr nicht in der Nähe von Personen oder Tieren.

Anleitung zur Installation und Nutzung

- **Installation der Zielvorrichtung:**
 - Montieren Sie die PicatinnySchiene gemäß den Anweisungen des Herstellers.
 - Stellen Sie sicher, dass alle Schrauben fest angezogen sind.
- **Laden des Gewehrs:**
 - Überprüfen Sie, ob das Gewehr entladen ist, bevor Sie das Magazin einsetzen.
 - Führen Sie das Magazin in den Schacht ein, bis es einrastet.
- **Abfeuern des Gewehrs:**
 - Stellen Sie sicher, dass Sie in eine sichere Richtung zielen.
 - Betätigen Sie den Ruger Marksman Adjustable™ Abzug sanft, um den Schuss abzugeben.
- **Reinigung des Gewehrs:**
 - Reinigen Sie das Gewehr regelmäßig, um eine optimale Leistung zu gewährleisten.
 - Verwenden Sie nur empfohlene Reinigungsmittel und werkzeuge.

Entsorgungsanweisungen

- Entsorgen Sie das Gewehr niemals im normalen Hausmüll.
- Geben Sie das Gewehr bei einer autorisierten Sammelstelle oder einem Fachhändler ab, der für die Entsorgung von Feuerwaffen zuständig ist.
- Achten Sie darauf, alle Sicherheitsvorkehrungen zu beachten, wenn Sie das Gewehr zur Entsorgung transportieren.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder Unterstützung bezüglich des Ruger American Rifle Predator wenden Sie sich bitte an den Hersteller oder einen autorisierten Händler. Es ist wichtig, dass Sie bei Sicherheitsanfragen einen Ansprechpartner haben.

Schlussfolgerung

Die Sicherheit bei der Verwendung des Ruger American Rifle Predator hat oberste Priorität. Indem Sie diese Sicherheitsrichtlinien befolgen, tragen Sie dazu bei, ein sicheres und verantwortungsvolles Schießen zu gewährleisten. Verwenden Sie das Gewehr mit Bedacht und genießen Sie die Präzision und Leistung, die es bietet.

Ruger American Rifle Predator Safety Instruction Guide

Introduction

Thank you for choosing the Ruger American Rifle Predator. This guide provides essential safety instructions and guidelines to ensure the safe and effective use of your rifle. It is important to familiarize yourself with these instructions to promote safe handling and usage.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep the rifle pointed in a safe direction at all times.
- Keep your finger off the trigger until you are ready to shoot.
- Be sure of your target and what is beyond it before firing.
- Store the rifle in a secure location, out of reach of children and unauthorized users.
- Regularly inspect your firearm for any signs of wear or damage.
- Use only the appropriate ammunition specified for your rifle.
- Always wear appropriate eye and ear protection when shooting.
- Be aware of your surroundings and the potential for ricochets.

Specific Safety Precautions for Use

- **Handling:**
 - Always ensure the rifle is unloaded when not in use.
 - Use the safety mechanism when the rifle is not being fired.
- **Loading and Unloading:**
 - Follow the manufacturer's instructions for loading and unloading.
 - Keep the muzzle pointed in a safe direction while loading and unloading.
- **Shooting:**
 - Only shoot at authorized ranges or in areas where shooting is permitted.
 - Avoid shooting in conditions that may pose a risk to safety, such as high winds or poor visibility.
- **Maintenance:**
 - Clean the rifle regularly according to the manufacturer's instructions.
 - Ensure that all parts are functioning correctly before use.

Instructions for Installation and Usage

1. Installation:

- Ensure the rifle is unloaded before installation.
- Attach any accessories according to the manufacturer's guidelines.
- Verify that all components are securely fastened.

2. Usage:

- Load the rifle by following these steps:
 - Open the bolt and visually inspect the chamber to ensure it is clear.
 - Insert the magazine into the rifle until it clicks into place.
 - Pull the bolt back and release it to chamber a round.
- To fire:
 - Aim at your target, ensuring a safe backstop is present.
 - Gently squeeze the trigger to fire.
- After firing, keep the rifle pointed downrange and wait for a safe moment to unload.

Disposal Instructions

- Dispose of your rifle in accordance with local regulations.
- If the rifle is no longer usable, consider contacting a licensed firearms dealer for disposal options.
- Do not dispose of ammunition in regular trash. Follow local hazardous waste disposal guidelines.

Contact Information for Further Support

For safety inquiries or additional support regarding your Ruger American Rifle Predator, please refer to the manufacturer's website or contact your local authorized dealer.

This safety instruction guide is designed to ensure the safe and responsible use of your Ruger American Rifle Predator. Always prioritize safety and adhere to local laws and regulations related to firearm ownership and usage.