

American Rifle Predator - .308 Win. - Left-Handed

Ruger American Rifle Predator

The Ruger American Rifle Predator combines cutting-edge innovation with Ruger's renowned reliability. Manufactured 100% in the USA, this bolt-action rifle offers exceptional precision and handling.

- **Ergonomic Stock:** Lightweight synthetic stock with a classic design, modern forend styling, and textured grip areas for superior control.
- **Adjustable Trigger:** The Ruger Marksman Adjustable Trigger is externally adjustable between 1.4 and 2.3 kg (3–5 lbs), with the adjustment key securely stored in the bolt.
- **Versatile Performance:** Ideal for hunting and precision shooting under various conditions.

Attributes

- Name: RUGER - American Rifle Predator - .308 Win. - Left-Handed
- Manufacturer: RUGER
- Product no.: BRD113087
- Mfr. No.: 17904186
- Barrel Finish: Matte Black
- Barrel Length: 22"
- Caliber: 6.5 Creedmoor
- Capacity: 4-Round
- Color: Moss Green
- Length: 42"
- Make: Ruger
- Material: Alloy Steel
- Model: American Predator
- Muzzle Threads: 5/8-24
- Side: Left
- Twist Rate: 1-10
- Weight: 6.6 lbs
- Delivery weight: 3kg
- Shipping height: 200mm
- Shipping width: 25mm
- Shipping length: 1,067mm
- UPC: 736676269730

Table of Contents

- Startpage
- Deutsch: Sicherheitshinweise für die Ruger American Rifle Predator
- English: Ruger American Rifle Predator Safety Instruction Guide

Sicherheitshinweise für die Ruger American Rifle Predator

Einleitung

Herzlichen Glückwunsch zum Kauf Ihrer Ruger American Rifle Predator! Diese Anleitung bietet wichtige Sicherheitshinweise und Anweisungen zur sicheren Verwendung Ihres Produkts. Bitte lesen Sie alle Informationen sorgfältig durch, um eine sichere und effektive Nutzung zu gewährleisten.

Allgemeine Sicherheitsrichtlinien

- Achten Sie darauf, dass Sie die Waffe nur in einem sicheren und kontrollierten Umfeld verwenden.
- Halten Sie die Waffe immer in einem sicheren Zustand und behandeln Sie sie so, als wäre sie geladen.
- Bewahren Sie die Waffe außerhalb der Reichweite von Kindern und unbefugten Personen auf.
- Verwenden Sie die Waffe nur für den vorgesehenen Zweck und gemäß den gesetzlichen Bestimmungen.
- Überprüfen Sie regelmäßig den Zustand der Waffe und der Munition.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Tragen Sie immer geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille.
- Stellen Sie sicher, dass Sie mit der Bedienung der Waffe vertraut sind, bevor Sie sie verwenden.
- Verwenden Sie nur die empfohlene Munition für Ihr Modell (.308 Win.).
- Achten Sie darauf, dass sich beim Laden der Waffe keine Personen im Schussfeld befinden.
- Vermeiden Sie es, die Waffe auf eine unbekannte oder unsichere Zielrichtung zu richten.

Anweisungen zur Installation und Nutzung

1. Vorbereitung

- Lesen Sie die Bedienungsanleitung vollständig durch, bevor Sie die Waffe verwenden.
- Überprüfen Sie alle Teile auf Beschädigungen und stellen Sie sicher, dass die Waffe sauber und gut gewartet ist.

2. Laden der Waffe

- Stellen Sie sicher, dass der Sicherheitshebel in der "Sicher"Position ist.
- Führen Sie das Magazin in die Waffe ein, bis es einrastet.
- Ziehen Sie den Verschluss zurück, um eine Patrone in die Kammer zu laden.

3. Zielen und Schießen

- Nehmen Sie eine stabile Schießposition ein.
- Richten Sie die Waffe auf das Ziel und überprüfen Sie den Abzug.
- Drücken Sie den Abzug sanft und gleichmäßig, um den Schuss abzugeben.

4. Entladen der Waffe

- Stellen Sie sicher, dass der Sicherheitshebel in der "Sicher"Position ist.
- Ziehen Sie den Verschluss zurück, um die Patrone aus der Kammer zu entfernen.
- Entfernen Sie das Magazin und überprüfen Sie, dass die Waffe leer ist.

Entsorgungsanweisungen

- Entsorgen Sie leere Patronen und Munition gemäß den örtlichen Vorschriften.
- Bringen Sie die Waffe und ihre Teile nur zu autorisierten Stellen zur Wartung oder Entsorgung.
- Achten Sie darauf, dass alle Teile der Waffe umweltgerecht entsorgt werden.

Kontaktinformationen für weitere Unterstützung

Für weitere Informationen oder Unterstützung zu Ihrer Ruger American Rifle Predator wenden Sie sich bitte an den Hersteller oder einen autorisierten Händler. Es ist wichtig, dass Sie bei Fragen oder Bedenken zur Sicherheit immer auf professionelle Hilfe zurückgreifen.

Schlussfolgerung

Die Ruger American Rifle Predator ist ein hochwertiges Produkt, das für Präzision und Benutzerfreundlichkeit entwickelt wurde. Durch die Beachtung dieser Sicherheitsanweisungen können Sie dazu beitragen, eine sichere Nutzung zu gewährleisten. Vielen Dank, dass Sie sich für Ruger entschieden haben!

Ruger American Rifle Predator Safety Instruction Guide

Introduction

Thank you for choosing the Ruger American Rifle Predator. This guide provides essential safety instructions and guidelines to ensure the safe use of your rifle. It is crucial to follow these instructions to prevent accidents and injuries while using this product.

General Safety Guidelines

- Always treat the rifle as if it is loaded.
- Keep the rifle pointed in a safe direction at all times.
- Keep your finger off the trigger until you are ready to shoot.
- Be aware of your target and what lies beyond it.
- Store the rifle unloaded and in a secure location, away from children and unauthorized users.
- Use only the ammunition specified in the product specifications.
- Wear appropriate eye and ear protection when shooting.
- Regularly inspect the rifle for signs of wear or damage.
- Follow all local laws and regulations regarding firearm ownership and use.

Specific Safety Precautions for Use

- **Handling:** Always handle the rifle with care. Ensure that the safety is engaged until you are ready to fire.
- **Shooting Environment:** Only shoot in designated areas where it is legal and safe to do so. Be aware of your surroundings and ensure that no one is in the vicinity of your shooting range.
- **Children and Vulnerable Groups:** Keep the rifle out of reach of children and educate them about firearm safety. Do not allow inexperienced users to handle the rifle without supervision.
- **Maintenance:** Follow the manufacturer's guidelines for cleaning and maintaining the rifle. Use only recommended cleaning supplies.

Instructions for Installation and Usage

1. **Unboxing:** Carefully remove the rifle from its packaging. Check for any visible damage or missing parts.
2. **Assembly:** If any assembly is required, refer to the manufacturer's instructions included in the packaging.
3. **Loading the Rifle:**
 - Ensure the rifle is pointed in a safe direction.
 - Open the bolt and visually inspect the chamber to confirm it is empty.
 - Load the magazine with the appropriate ammunition.
 - Insert the magazine into the rifle until it clicks into place.
4. **Firing the Rifle:**
 - Ensure the safety is in the "off" position.
 - Aim at your target and ensure the area is clear.
 - Squeeze the trigger smoothly to fire.
5. **PostUse:**
 - After use, unload the rifle by removing the magazine and visually inspecting the chamber.
 - Store the rifle in a secure location.

Disposal Instructions

- Dispose of the rifle in accordance with local laws and regulations.
- If the rifle is no longer functional, consult with a qualified gunsmith or local law enforcement for proper disposal methods.
- Dispose of ammunition according to local hazardous waste guidelines.

Contact Information for Further Support

For any questions or concerns regarding safety, maintenance, or use of the Ruger American Rifle Predator, please refer to the official Ruger website or contact your local authorized dealer for assistance.

Conclusion

By following these safety instructions and guidelines, you can ensure a safer experience while using your Ruger American Rifle Predator. Always prioritize safety and responsibility when handling firearms. Thank you for your commitment to safe shooting practices.