

Sig Sauer CROSS PRS Rifle 24" - 6.5 Creedmoor - 10-Round

[Firearms](#) > [Rifles](#) > [Bolt Action](#)

Brief Description: The Sig Sauer CROSS PRS Rifle 24" in 6.5 Creedmoor is purpose-built for long-range precision shooters. Featuring a 24" stainless steel barrel, free-floating M-LOK handguard, adjustable folding stock, and the exclusive Concrete Grey Elite Cerakote coating, it delivers immediate readiness for the most demanding requirements.



Technical Specifications:

- Caliber: 6.5 Creedmoor
- Barrel: 24" Stainless Steel
- Handguard: 2-Piece 18" Free-Floating M-LOK
- Stock: Infinitely Adjustable Precision Folding Stock
- Trigger: Adjustable SIG MATCHLITE 2-Stage Trigger
- Coating: Elite Cerakote in Concrete Grey
- Magazine: AICS-Magazine Compatible, includes 10-Round Magazine

Conclusion: The Sig Sauer CROSS PRS Rifle excels in precision with its high-quality components. The unique combination of a precise trigger, free-floating handguard, and customizable folding stock makes it an outstanding choice for shooters demanding top-tier performance and adaptability. Its Elite Cerakote coating not only sets new visual standards but also elevates protection levels.



Attributes

- Name: [Sig Sauer CROSS PRS Rifle 24" - 6.5 Creedmoor - 10-Round](#)
- Manufacturer: [SIG SAUER, INC.](#)
- Product no.: BRD141010
- Mfr. No.: CROSS-65-24B
- Barrel Length: 24"
- Caliber: 6.5 Creedmoor
- Length: 44.5"
- Magazine Included: 1 x 10-Round
- Model: Cross PRS
- Twist: 1-8
- Weight: 14 lbs.
- Delivery weight: 10kg
- Shipping height: 300mm
- Shipping width: 450mm
- Shipping length: 1,300mm

Item details

EU Export Disabled

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for Sig Sauer CROSS PRS Rifle 24"](#)
- [About Us](#)

Safety Instruction Guide for Sig Sauer CROSS PRS Rifle 24"

Introduction

Thank you for choosing the Sig Sauer CROSS PRS Rifle 24" in 6.5 Creedmoor. This guide provides essential safety instructions to ensure safe and effective use of your rifle. Please read this document carefully and follow all safety guidelines to prevent accidents and ensure compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always treat the rifle as if it is loaded.
- Keep the rifle pointed in a safe direction at all times.
- Keep your finger off the trigger until you are ready to shoot.
- Always be aware of your target and what is beyond it.
- Use appropriate eye and ear protection when shooting.
- Ensure the rifle is unloaded when not in use or when being transported.
- Store the rifle in a secure location, out of reach of children and unauthorized users.
- Regularly inspect the rifle for any signs of damage or wear before use.

Specific Safety Precautions for Use

- Ensure that you are familiar with the rifle's operation before use.
- Use only the recommended ammunition type (6.5 Creedmoor) for your rifle.
- Avoid using damaged or improperly stored ammunition.
- Do not modify the rifle in any way that could affect its safety or performance.
- Be cautious of environmental factors such as wind and lighting when shooting.
- If you experience a misfire, keep the rifle pointed in a safe direction for at least 30 seconds before attempting to clear the malfunction.
- Follow all local laws and regulations regarding firearm ownership and usage.

Instructions for Installation and Usage

1. Installation of Accessories:

- Ensure that any accessories, such as scopes or bipods, are compatible with the rifle.
- Follow the manufacturer's instructions for installing any accessories.
- Tighten all screws and mounts securely to prevent any movement during use.

2. Loading the Magazine:

- Ensure the rifle is pointed in a safe direction.
- Insert the 10round magazine into the rifle until it clicks into place.
- Load ammunition into the magazine according to the manufacturer's instructions.

3. Firing the Rifle:

- Ensure the rifle is on a stable surface or held securely.
- Set the safety to "fire" mode.
- Aim at the target, ensuring a clear line of sight.
- Gently squeeze the trigger to fire the rifle.

4. Unloading the Rifle:

- Point the rifle in a safe direction.
- Remove the magazine by pressing the magazine release button.
- Pull back the bolt to eject any chambered round.
- Visually and physically inspect the chamber to ensure it is clear.

Disposal Instructions

- When disposing of the rifle, ensure that it is unloaded and rendered inoperable.
- Follow local regulations for the disposal of firearms.
- Do not dispose of ammunition in regular trash. Contact local authorities for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or concerns regarding your Sig Sauer CROSS PRS Rifle, please refer to the manufacturer's contact information provided in the product packaging or user manual.

Conclusion

By following the guidelines and precautions outlined in this safety instruction guide, you can ensure a safe and enjoyable experience with your Sig Sauer CROSS PRS Rifle. Always prioritize safety and responsibility when handling firearms. Thank you for your commitment to safe shooting practices.

About Us

Brownells Deutschland

**Brownells Deutschland - Einer der größten Lieferanten für Waffenteile,
Büchsenmacherwerkzeug & Schießsportzubehör**

Lahnstraße 1
24539 Neumünster
Deutschland

www.brownells-deutschland.de