

Sig Sauer CROSS PRS Rifle 24" - 30 Caliber (.308) - 10-Round

Brief Description: Sig Sauer CROSS PRS Rifle in .308 WIN is a pinnacle of precision for competitive shooting. Designed for long-range precision, it boasts a 24" stainless steel barrel, an adjustable folding stock, and elite Cerakote coating, meeting the demands of precision shooters right from the start.



Technical Specifications:

- Caliber: .308 WIN
- Barrel: 24" Stainless Steel
- Handguard: 2-Piece Free-Floating 18" M-LOK
- Stock: Infinitely Adjustable Folding Stock
- Trigger: Adjustable SIG MATCHLITE 2-Stage
- Coating: Elite Cerakote in Concrete Grey
- Magazine: AICS-Magazine Compatible, 10-Round Included

Conclusion: The Sig Sauer CROSS PRS in .308 WIN is a long-range precision powerhouse. With advanced features like the adjustable folding stock and elite Cerakote coating, it delivers exceptional performance tailored for precision shooters. The CROSS-PRS stands as a top choice for those seeking unparalleled accuracy and adaptability in a precision rifle.



Attributes

- Name: Sig Sauer CROSS PRS Rifle 24" - 30 Caliber (.308) - 10-Round
- Manufacturer: SIG SAUER, INC.
- Product no.: BRD141011
- Mfr. No.: CROSS-308-24B
- Barrel Length: 24"
- Caliber: 30 Caliber (.308)
- Length: 44.5"
- Magazine Included: 1 x 10-Round
- Model: Cross PRS
- Twist: 1-10
- Weight: 14 lbs.
- Delivery weight: 10kg
- Shipping height: 300mm
- Shipping width: 450mm
- Shipping length: 1,300mm

Item details

EU Export Disabled

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die Sig Sauer CROSS Präzisionswaffe 24"](#)
- [English: Safety Instruction Guide for Sig Sauer CROSS PRS Rifle 24"](#)

Sicherheitshinweise für die Sig Sauer CROSS Präzisionswaffe 24"

Einführung

Herzlichen Glückwunsch zum Kauf der Sig Sauer CROSS Präzisionswaffe im Kaliber .308 WIN. Diese Anleitung bietet wichtige Sicherheitsinformationen, um die sichere Nutzung des Produkts zu gewährleisten. Bitte lesen Sie diese Hinweise sorgfältig durch und bewahren Sie sie für zukünftige Referenz auf.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass Sie mit den grundlegenden Sicherheitspraktiken beim Umgang mit Feuerwaffen vertraut sind.
- Verwenden Sie die Waffe nur für den vorgesehenen Zweck und in Übereinstimmung mit den geltenden Gesetzen.
- Halten Sie die Waffe immer in einem sicheren Zustand, bis Sie bereit sind, sie zu verwenden.
- Bewahren Sie die Waffe in einem sicheren, verschlossenen Bereich auf, der für Kinder und unbefugte Personen unzugänglich ist.
- Melden Sie unsichere Produkte und Unfälle umgehend den zuständigen Behörden.
- Überprüfen Sie regelmäßig die Rückrufupdates auf der EU Safety GatePlattform.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Verwenden Sie nur Munition, die für das Kaliber .308 WIN geeignet ist.
- Überprüfen Sie vor jedem Gebrauch die Waffe auf Beschädigungen oder Verschleiß.
- Achten Sie darauf, dass der Abzug nicht versehentlich betätigt wird, wenn Sie die Waffe nicht verwenden.
- Tragen Sie immer geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille.
- Verwenden Sie die Waffe niemals unter dem Einfluss von Alkohol, Drogen oder anderen Substanzen, die Ihre Urteilsfähigkeit beeinträchtigen könnten.
- Halten Sie den Lauf der Waffe von sich und anderen Personen weg, wenn Sie sie laden oder entladen.

Anweisungen für Installation und Nutzung

• Installation:

- Stellen Sie sicher, dass die Waffe vor der Installation sicher und entladen ist.
- Befolgen Sie die Anweisungen im Benutzerhandbuch für die Montage und Anpassung des Klappschafts und des Handschutzes.

• Nutzung:

- Laden Sie die Waffe gemäß den Anweisungen im Handbuch.
- Überprüfen Sie, ob das Magazin korrekt eingesetzt ist, bevor Sie die Waffe verwenden.
- Führen Sie vor dem Schießen immer eine Sicherheitsüberprüfung durch, um sicherzustellen, dass sich keine Hindernisse im Lauf befinden.
- Üben Sie verantwortungsbewusstes Schießen und respektieren Sie die Umgebung und andere Personen in der Nähe.

Entsorgungsanweisungen

- Entsorgen Sie die Waffe gemäß den örtlichen Gesetzen und Vorschriften für gefährliche Abfälle.
- Informieren Sie sich über spezielle Programme oder Einrichtungen in Ihrer Nähe, die die Rücknahme von Feuerwaffen und Munition anbieten.

- Halten Sie sich an alle geltenden Gesetze zur Entsorgung von Munition.

Kontaktinformationen für weitere Unterstützung

Für weitere Informationen oder Unterstützung wenden Sie sich bitte an den Hersteller oder an die zuständigen Behörden in Ihrer Region. Achten Sie darauf, alle Sicherheitsrichtlinien zu befolgen und das Produkt verantwortungsbewusst zu nutzen.

Safety Instruction Guide for Sig Sauer CROSS PRS Rifle 24"

Introduction

Thank you for choosing the Sig Sauer CROSS PRS Rifle 24". This guide provides important safety instructions and guidelines to ensure the safe and effective use of your rifle. Please read this guide carefully before using the product.

General Safety Guidelines

- Always treat the rifle as if it is loaded, even if you believe it is not.
- Keep the rifle pointed in a safe direction at all times.
- Store the rifle in a secure location, out of reach of children and unauthorized users.
- Use only the recommended ammunition specified in the product specifications.
- Always wear appropriate eye and ear protection when using the rifle.
- Be aware of your surroundings and ensure a safe shooting environment.
- Do not use the rifle under the influence of drugs or alcohol.
- Regularly inspect the rifle for any signs of wear or damage before use.
- Follow all local laws and regulations regarding firearm ownership and use.

Specific Safety Precautions for Use

- Ensure that the safety mechanism is engaged until you are ready to fire.
- Do not place your finger on the trigger until you are prepared to shoot.
- Avoid using the rifle in adverse weather conditions that could affect handling and visibility.
- Be cautious of ricochet and ensure that your shooting area is clear of obstructions.
- Always check the chamber and magazine to ensure they are clear of ammunition when not in use.
- Do not attempt to modify or alter the rifle in any way that could compromise its safety or functionality.

Instructions for Installation and Usage

1. Unboxing and Inspection

- Carefully remove the rifle from the packaging.
- Inspect all components for any signs of damage or missing parts.
- Ensure that the rifle is unloaded before handling.

2. Adjusting the Stock

- To adjust the folding stock, release the adjustment lever and slide the stock to the desired position.
- Ensure the stock is securely locked in place before use.

3. Loading the Magazine

- Use only AICS-compatible magazines.
- Insert the ammunition into the magazine, ensuring that it is seated properly.
- Insert the loaded magazine into the rifle until it clicks into place.

4. Firing the Rifle

- Ensure that the rifle is pointed downrange and that the safety is disengaged.

- Place your finger on the trigger only when ready to fire.
- After firing, keep the rifle pointed downrange and engage the safety before reloading or adjusting.

5. Cleaning and Maintenance

- After each use, clean the rifle according to the manufacturer's instructions.
- Store the rifle in a dry and secure location.

Disposal Instructions

- Dispose of any used ammunition and packaging materials in accordance with local regulations.
- If the rifle is no longer in use, consider turning it in to a licensed dealer or local law enforcement for safe disposal.

Contact Information for Further Support

For any safety inquiries or additional support, please refer to the manufacturer's official website or customer service resources.

By following these guidelines, you can ensure a safe and enjoyable experience with your Sig Sauer CROSS PRS Rifle 24". Always prioritize safety and responsibility when handling firearms.