

Schließfeder für P220/P226 - Schließfeder für P220/P226 - Sig Sauer, SIG - P226, P220 - 1 - 9mm Luger

[Handgun Parts](#) > [Recoil Parts](#) > [Recoil Springs](#)

Für die P226 (Standard & X-Serie) Schließfeder aus Beständen Sig Eckernförde gem. letzten Produktions-/Zeichnungsstand vorliegen:

- Standard-Schließfeder für 9x19 (nicht gedrillt!)



Attributes

- Name: [Schließfeder für P220/P226 - Sig Sauer, SIG - P226, P220 - 1 - 9mm Luger](#)
- Manufacturer: [SIG SAUER, INC.](#)
- Product no.: BRD216012
- Mfr. No.: 71007470
- Caliber: 9mm Luger
- Make: Sig Sauer, SIG
- Model: P226, P220
- Delivery weight: 0.01kg
- Shipping height: 20mm
- Shipping width: 20mm
- Shipping length: 100mm

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for Schließfeder für P220/P226](#)
- [About Us](#)

Safety Instruction Guide for Schließfeder für P220/P226

Introduction

Thank you for choosing the Schließfeder für P220/P226 by Sig Sauer. This guide provides essential safety instructions and guidelines to ensure the safe usage and maintenance of this product. Please read this guide carefully before installation and use.

General Safety Guidelines

- Ensure you are familiar with the operation of your firearm before installing the recoil spring.
- Always handle firearms with care and follow all safety protocols.
- Store the recoil spring in a safe, dry place away from children and unauthorized users.
- Regularly inspect the recoil spring for signs of wear or damage before use.
- Report any unsafe conditions or incidents related to this product to the appropriate authorities.

Specific Safety Precautions for Use

- Use the recoil spring only with compatible models: P220 and P226.
- Ensure the firearm is unloaded before attempting to install or replace the recoil spring.
- Avoid using the recoil spring if it shows signs of damage or if it does not fit properly.
- Keep hands and other body parts clear of the firearm's action during installation and operation.
- Follow all manufacturer instructions regarding the handling and operation of your firearm.

Instructions for Installation and Usage

1. Preparation

- Ensure the firearm is unloaded.
- Gather necessary tools: screwdriver, cleaning cloth, and safety glasses.

2. Installation Steps

- Remove the slide from the firearm according to the manufacturer's instructions.
- Carefully remove the old recoil spring from the slide.
- Inspect the recoil spring housing for any debris or damage.
- Insert the new Schließfeder into the recoil spring housing, ensuring it is seated correctly.
- Reattach the slide to the firearm, ensuring all components are aligned and secure.

3. Usage

- After installation, perform a function check to ensure the firearm operates correctly.
- Use the firearm in accordance with the manufacturer's guidelines and local laws.
- Regularly clean and maintain the firearm to ensure optimal performance.

Disposal Instructions

- Dispose of the Schließfeder responsibly, following local regulations for hazardous materials.
- Do not throw the recoil spring in regular household waste.
- Contact local recycling centers for proper disposal options.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Schließfeder für P220/P226, please refer to the manufacturer's customer support or website for assistance.

By following these safety instructions, you can help ensure a safe and effective experience with your Schließfeder für P220/P226. Thank you for your attention to these important guidelines.

About Us

Brownells Deutschland

**Brownells Deutschland - Einer der größten Lieferanten für Waffenteile,
Büchsenmacherwerkzeug & Schießsportzubehör**

Lahnstraße 1
24539 Neumünster
Deutschland

www.brownells-deutschland.de