

Performance Trigger - 9mm - Gen4/Gen5

The GLOCK Performance trigger offers match trigger characteristics and improved ergonomics thanks to a flat trigger shoe. It enables control and increases shooting performance and precision while fully retaining the safety features of the GLOCK Safe Action System.



Features:

- Significantly reduced trigger weight (2,000g in delivered configuration; 1,600g - 3,200g possible with connector)
- Precisely controllable
- Soft trigger and crisp reset for fast follow-up shots
- Straight trigger blade and flat profile
- Even break of the trigger
- Suitable for G17 Gen4, G19 Gen4, G26 Gen. 4, G34 Gen. 4, G17 Gen5, G19 Gen5, G19X, G26 Gen. 5, G34 G

Conclusion: The GLOCK Performance trigger for Gen. 4 / 5 pistols offers a significant improvement in trigger control and performance. With a reduced trigger pull weight and a precise, smooth trigger pull, this trigger is ideal for shooters looking for accuracy and speed. The retention of the safety features of the GLOCK Safe Action System continues to ensure reliability and safety.

Attributes

- Name: Glock Performance Trigger - 9mm - Gen4/Gen5
- Manufacturer: GLOCK
- Product no.: BRD221047
- Mfr. No.: 2431919
- Caliber: 9mm
- Generation: Gen4/Gen5
- Delivery weight: 0.3kg

Table of Contents

- Startpage
- Deutsch: Sicherheitshinweise für den Glock Match Abzug 9mm Gen4/Gen5
- English: Glock Performance Trigger Safety Instructions

Sicherheitshinweise für den Glock Match Abzug 9mm Gen4/Gen5

Einführung

Herzlichen Glückwunsch zu Ihrem Kauf des Glock Match Abzugs! Dieser Abzug bietet Ihnen eine verbesserte Schießleistung und Präzision. Bitte lesen Sie die folgenden Sicherheitshinweise sorgfältig durch, um sicherzustellen, dass Sie das Produkt sicher und effektiv verwenden.

Allgemeine Sicherheitsrichtlinien

- Achten Sie immer darauf, dass die Waffe in einem sicheren Zustand ist, bevor Sie den Abzug installieren oder verwenden.
- Verwenden Sie den Abzug nur mit kompatiblen GlockModellen (G17 Gen4, G19 Gen4, G26 Gen4, G34 Gen4, G17 Gen5, G19 Gen5, G19X, G26 Gen5, G34 Gen5, G45, G47).
- Halten Sie den Abzug und alle Waffenteile außerhalb der Reichweite von Kindern und unbefugten Personen.
- Überprüfen Sie regelmäßig den Zustand des Abzugs und der Waffe, um sicherzustellen, dass alles einwandfrei funktioniert.
- Befolgen Sie stets die Sicherheitsrichtlinien für den Umgang mit Schusswaffen.

Spezifische Sicherheitsvorkehrungen für die Verwendung

- Verwenden Sie den Glock Match Abzug nur in einer sicheren Umgebung, die für das Schießen geeignet ist.
- Tragen Sie immer geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille.
- Achten Sie darauf, dass keine Hindernisse im Schussbereich sind, bevor Sie abdrücken.
- Halten Sie den Finger immer vom Abzug, bis Sie bereit sind zu schießen.
- Stellen Sie sicher, dass die Waffe entladen ist, bevor Sie den Abzug installieren oder warten.

Anweisungen zur Installation und Verwendung

1. **Vorbereitung:** Stellen Sie sicher, dass die Waffe entladen ist. Überprüfen Sie das Magazin und die Kammer.
2. **Installation:**
 - Entfernen Sie den ursprünglichen Abzug gemäß den Anweisungen im WaffenteileHandbuch.
 - Installieren Sie den Glock Match Abzug, indem Sie ihn an der vorgesehenen Stelle anbringen.
 - Überprüfen Sie, ob der Abzug sicher und fest sitzt.
3. **Testen:**
 - Führen Sie einen Funktionstest durch, um sicherzustellen, dass der Abzug ordnungsgemäß funktioniert.
 - Achten Sie auf das Abzugsgewicht und die Rückmeldung des Abzugs.
4. **Verwendung:**
 - Halten Sie die Waffe stabil und zielen Sie auf das Ziel.
 - Drücken Sie den Abzug sanft, um ein präzises Schießen zu gewährleisten.
 - Üben Sie regelmäßig, um Ihre Fähigkeiten zu verbessern.

Entsorgungsanweisungen

- Entsorgen Sie alle nicht mehr benötigten Teile gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Stellen Sie sicher, dass die Teile nicht in die Hände von Unbefugten gelangen.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder Informationen zu Sicherheitsanliegen stehen Ihnen verschiedene Ressourcen zur Verfügung. Überprüfen Sie die offiziellen Webseiten oder kontaktieren Sie den Hersteller für spezifische Anliegen.

Bitte beachten Sie, dass es wichtig ist, regelmäßig Informationen über Rückrufe oder Sicherheitswarnungen zu überprüfen. Halten Sie sich über die neuesten Entwicklungen auf dem Laufenden, um sicherzustellen, dass Sie und andere sicher bleiben.

Glock Performance Trigger Safety Instructions

Introduction

Thank you for choosing the Glock Performance Trigger for your Gen4/Gen5 pistol. This guide provides essential safety information to ensure the safe use and handling of your new trigger. Please read and follow all instructions carefully to maximize your safety and shooting performance.

General Safety Guidelines

- Always treat your firearm as if it is loaded.
- Keep your finger off the trigger until you are ready to shoot.
- Always be aware of your target and what is beyond it.
- Store your firearm and ammunition securely away from children and unauthorized users.
- Ensure that your firearm is in good working order before use.
- Regularly inspect your Glock Performance Trigger for any signs of wear or damage.
- Follow all local laws and regulations regarding firearm ownership and usage.

Specific Safety Precautions for Use

- Ensure that the trigger is installed correctly before using the firearm.
- Do not modify the trigger or any other components of the firearm unless done by a qualified gunsmith.
- Always use the Glock Performance Trigger with compatible Glock models (G17 Gen4, G19 Gen4, G26 Gen. 4, G34 Gen. 4, G17 Gen5, G19 Gen5, G19X, G26 Gen. 5, G34 Gen. 5, G45, G47).
- Be aware that the reduced trigger weight may lead to unintentional discharges if proper handling procedures are not followed.
- Use appropriate ammunition (9mm) as specified for your firearm.

Instructions for Installation and Usage

1. Installation:

- Ensure the firearm is unloaded and the magazine is removed.
- Follow the manufacturer's instructions for replacing the trigger.
- Use proper tools and ensure all components are securely fastened.
- Test the trigger function in a safe environment before taking the firearm to the range.

2. Usage:

- Grip the firearm securely and maintain proper shooting stance.
- Apply steady pressure to the trigger when ready to fire.
- Be prepared for a crisp reset for followup shots.
- If you experience any malfunctions, cease use immediately and consult a qualified gunsmith.

Disposal Instructions

- Dispose of the Glock Performance Trigger in accordance with local regulations.
- Ensure that any disposed components are rendered unusable to prevent accidents.
- Consider recycling options for metal components where applicable.

Contact Information for Further Support

For safety inquiries or further information regarding your Glock Performance Trigger, please contact your local Glock dealer or visit the official Glock website for support resources.

By following these safety instructions, you can help ensure a safe and enjoyable shooting experience with your Glock Performance Trigger. Always prioritize safety and responsible firearm handling.