

# TL Rear Sight for LLV, Scorpion, Mamba upper - TL Rear Sight for LLV

[Handgun Parts](#) > [Sights](#) > [Rear Sights](#)

Precision-machined to ensure accurate, repeatable click adjustments for windage and elevation. No fitting required. Uses factory dovetail and locks in place with two set screws. Made of steel. Rear sight notch width is 0.110".



## Attributes

- Name: [TL Rear Sight for LLV](#)
- Manufacturer: [VOLQUARTSEN](#)
- Product no.: BRD231008
- Mfr. No.: VC2TL-H
- Model: LLV, Scorpion, Black Mamba uppers
- Delivery weight: 0.02kg
- Shipping height: 20mm
- Shipping width: 115mm
- Shipping length: 175mm
- UPC: 810162014711

# Table of Contents

- Startpage
- TL Rear Sight for LLV, Scorpion, Mamba Upper Safety Instruction Guide
- About Us

# TL Rear Sight for LLV, Scorpion, Mamba Upper Safety Instruction Guide

## Introduction

Thank you for choosing the TL Rear Sight for LLV, Scorpion, and Mamba uppers. This product has been precisionmachined to ensure accurate and repeatable click adjustments for windage and elevation. It is designed for easy installation using the factory dovetail and locks in place with two set screws. This guide provides essential safety instructions to ensure safe and effective use of the product.

## General Safety Guidelines

- Always handle the TL Rear Sight with care to avoid injury.
- Ensure that the firearm is unloaded before installing or adjusting the rear sight.
- Store the rear sight in a safe, dry place when not in use to prevent damage.
- Regularly inspect the rear sight for any signs of wear or damage before use.
- Follow all local laws and regulations regarding firearm accessories and modifications.
- Keep this product out of reach of children and unauthorized users.

## Specific Safety Precautions for Use

### • Installation Precautions:

- Use appropriate tools when installing the rear sight to prevent damage.
- Do not force the rear sight into the dovetail; ensure proper alignment.

### • Operational Safety:

- Always point the firearm in a safe direction when making adjustments.
- Perform adjustments only when the firearm is pointed in a safe direction.
- Ensure that the sight is securely locked in place before use.

### • Maintenance and Inspection:

- Regularly check the tightness of the set screws to ensure the sight remains secure.
- Clean the rear sight with a soft cloth to maintain visibility and function.

## Instructions for Installation and Usage

### 1. Installation:

- Ensure the firearm is unloaded.
- Align the rear sight with the factory dovetail on the upper receiver.
- Gently slide the rear sight into the dovetail until it is fully seated.
- Secure the sight in place using the two set screws provided.
- Use an appropriate tool to tighten the screws without overtightening, which can damage the sight.

### 2. Usage:

- After installation, check the alignment of the sight with the front sight.
- Make windage and elevation adjustments using the click adjustments provided.
- Test the firearm at a safe shooting range to ensure proper function and accuracy.

## **Disposal Instructions**

- Dispose of the TL Rear Sight in accordance with local regulations.
- Do not dispose of the sight in regular household waste; check for recycling options for metal components.
- Ensure that any packaging materials are disposed of responsibly.

## **Contact Information for Further Support**

For any inquiries or support regarding the TL Rear Sight, please reach out to your retailer or manufacturer. Always refer to the product documentation for additional resources and support options.

Thank you for your attention to these safety instructions. Your safety and the safety of others is our top priority. Enjoy your shooting experience with the TL Rear Sight!

# About Us

## **Brownells Deutschland**

**Brownells Deutschland - Einer der größten Lieferanten für Waffenteile,  
Büchsenmacherwerkzeug & Schießsportzubehör**

Lahnstraße 1  
24539 Neumünster  
Deutschland

[www.brownells-deutschland.de](http://www.brownells-deutschland.de)