

Target Disconnecter for 10/22 and 10/22 Magnum

Target Disconnecter for 10/22 and 10/22 Magnum

Manufactured through an EDM process for exacting tolerances. Designed to be used in conjunction with match hammer and sear to provide for a very crisp, clean trigger pull. Made of A2 tool steel and hardened to Rc 58–60.

Attributes

- Name: Target Disconnecter for 10/22 and 10/22 Magnum
- Manufacturer: VOLQUARTSEN
- Product no.: BRD231018
- Mfr. No.: VC10DN
- Material: Steel
- Model: 10/22, 10/22 Magnum
- UPC: 810162010867

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für den Target Disconnecter für 10/22 und 10/22 Magnum](#)
- [English: Target Disconnecter for 10/22 and 10/22 Magnum Safety Instructions](#)

Sicherheitshinweise für den Target Disconnecter für 10/22 und 10/22 Magnum

Einführung

Vielen Dank, dass Sie sich für den Target Disconnecter für 10/22 und 10/22 Magnum entschieden haben. Dieses Produkt wurde entwickelt, um Ihnen eine verbesserte Schussleistung zu bieten. Um die Sicherheit während der Nutzung zu gewährleisten, lesen Sie bitte die folgenden Sicherheitshinweise sorgfältig durch.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass das Produkt in Übereinstimmung mit den geltenden Gesetzen und Vorschriften verwendet wird.
- Verwenden Sie das Produkt nur für den vorgesehenen Zweck.
- Halten Sie das Produkt von Kindern und schutzbedürftigen Personen fern.
- Überprüfen Sie regelmäßig das Produkt auf Abnutzung oder Beschädigungen.
- Melden Sie unsichere Produkte oder Unfälle an die zuständigen Behörden.
- Informieren Sie sich über Rückrufupdates auf der EUSicherheitsplattform.

Besondere Sicherheitsvorkehrungen für die Nutzung

- Verwenden Sie das Produkt nur in Verbindung mit kompatiblen Waffenmodellen.
- Achten Sie darauf, dass der Abzug und andere Teile der Waffe in einwandfreiem Zustand sind.
- Tragen Sie immer geeignete Schutzausrüstung, einschließlich Augen und Gehörschutz.
- Vermeiden Sie es, das Produkt unter Einfluss von Alkohol oder Drogen zu verwenden.
- Halten Sie die Finger immer vom Abzug, bis Sie bereit sind zu schießen.

Anleitung zur Installation und Nutzung

1. Installation

- Stellen Sie sicher, dass die Waffe entladen ist, bevor Sie mit der Installation beginnen.
- Entfernen Sie den alten Disconnecter gemäß der Anleitung des Herstellers.
- Setzen Sie den Target Disconnecter ein und stellen Sie sicher, dass er korrekt sitzt.
- Überprüfen Sie die Funktion des Disconnecter, bevor Sie die Waffe wieder zusammenbauen.

2. Nutzung

- Stellen Sie sicher, dass die Waffe sicher und stabil auf einer geeigneten Schießunterlage platziert ist.
- Überprüfen Sie vor jedem Schießen die Funktion des Abzugs und des Disconnecters.
- Schießen Sie nur auf ausgewiesene Schießstände oder bereiche.
- Achten Sie während des Schießens auf Ihre Umgebung und mögliche Gefahren.

Entsorgungsanweisungen

- Entsorgen Sie das Produkt gemäß den örtlichen Vorschriften für die Entsorgung von Metallabfällen.
- Wenn das Produkt beschädigt ist, bringen Sie es zur nächstgelegenen Sammelstelle für gefährliche Abfälle.
- Stellen Sie sicher, dass das Produkt nicht in die Hände von Kindern oder unbefugten Personen gelangt.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder weitere Unterstützung wenden Sie sich bitte an den Hersteller oder den Händler, bei dem Sie das Produkt erworben haben.

Vielen Dank, dass Sie sich die Zeit genommen haben, diese Sicherheitsanweisungen zu lesen. Ihre Sicherheit und die Sicherheit anderer sind von größter Bedeutung.

Target Disconnecter for 10/22 and 10/22 Magnum

Safety Instructions

Introduction

Thank you for choosing the Target Disconnecter for 10/22 and 10/22 Magnum. This product is designed to enhance your shooting experience by providing a crisp and clean trigger pull. To ensure safe and effective use of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Always treat the firearm as if it is loaded.
- Ensure that the disconnecter is installed correctly to prevent accidental discharge.
- Keep the firearm pointed in a safe direction at all times.
- Store the firearm and disconnecter in a secure location, out of reach of children and unauthorized users.
- Always wear appropriate safety gear, including eye and ear protection, when using firearms.
- Be aware of your surroundings and ensure that you have a clear and safe shooting area.
- Regularly inspect the disconnecter and firearm for signs of wear or damage before use.
- Follow all local laws and regulations regarding the use of firearms.

Specific Safety Precautions for Use

- Ensure that the firearm is unloaded before installing or adjusting the disconnecter.
- Use only the recommended match hammer and sear in conjunction with the disconnecter for optimal performance.
- Avoid using the disconnecter with any modifications not approved by the manufacturer.
- Do not attempt to disassemble or modify the disconnecter.
- Be cautious of the trigger pull weight; ensure it is within safe limits for your shooting style and experience level.
- If you experience any malfunctions or unexpected behavior, cease use immediately and consult a qualified gunsmith.

Instructions for Installation and Usage

1. Installation

- Ensure the firearm is unloaded and pointed in a safe direction.
- Remove the stock from the firearm to access the trigger assembly.
- Carefully remove the existing disconnecter from the trigger assembly.
- Install the Target Disconnecter in the same orientation as the original.
- Reassemble the trigger assembly and ensure all components are securely fastened.
- Reattach the stock to the firearm.

2. Usage

- Before using the firearm, perform a function check to ensure proper installation.
- Verify that the trigger pull is smooth and consistent.
- Practice safe handling and shooting techniques at all times.
- Regularly clean and maintain the disconnecter and firearm to ensure optimal performance.

Disposal Instructions

- Dispose of the disconnecter according to local regulations.
- Do not dispose of the disconnecter in regular household waste.
- Contact your local waste management facility for guidance on proper disposal methods for metal components.

Contact Information for Further Support

For any questions or concerns regarding the Target Disconnect for 10/22 and 10/22 Magnum, please consult the manufacturer or a qualified firearms expert for assistance. Always prioritize safety and compliance with local laws and regulations when using firearms and accessories.

Thank you for your attention to these safety instructions. Enjoy your shooting experience with the Target Disconnect!