

HP Action Kit, Black, 10/22, Add Plus Kit

HP Action Kit, Black, 10/22, Add Plus Kit

This kit consists of our target hammer (includes shims and bushings), hammer spring, target disconnector, target sear and target trigger. Includes polished plunger and spring) with overtravel adjustment. Also included is a recoil buffer to reduce wear on the action and bolt. The HP Action Kit will give the shooter one of the most crisp, clean trigger pulls available. Reduces trigger pull down to approximately 2.25 - 2.5lbs.

HP Action Kit Plus features all of this and adds our Extended Magazine Release and Auto Bolt Release.

Please note our bolt release is only compatible with Volquartsen and Ruger factory bolts and trigger guards, including the BX

Trigger. It may not work correctly with other manufacturers' parts.

Attributes

- Name: HP Action Kit, Black, 10/22, Add Plus Kit
- Manufacturer: VOLQUARTSEN
- Product no.: BRD231030
- Mfr. No.: VC10HP-B-10-P
- Color: Black
- Make: Ruger
- Model: 10/22
- Delivery weight: 0.5kg
- UPC: 810162011482

Table of Contents

- Startpage
- Deutsch: Sicherheitshinweise für das HP Action Kit, Black, 10/22, Add Plus Kit
- English: HP Action Kit Safety Instruction Guide

Sicherheitshinweise für das HP Action Kit, Black, 10/22, Add Plus Kit

Einführung

Vielen Dank, dass Sie sich für das HP Action Kit, Black, 10/22, Add Plus Kit entschieden haben. Dieses Produkt wurde entwickelt, um Ihnen eine verbesserte Leistung und ein besseres Schießerlebnis zu bieten. Es ist wichtig, dass Sie die folgenden Sicherheitshinweise und Anweisungen sorgfältig lesen und befolgen, um eine sichere Verwendung zu gewährleisten.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass Sie alle Sicherheitsvorkehrungen und Anweisungen in dieser Anleitung befolgen.
- Verwenden Sie das HP Action Kit nur in Übereinstimmung mit den Anweisungen des Herstellers.
- Bewahren Sie dieses Handbuch an einem sicheren Ort auf, damit Sie jederzeit darauf zugreifen können.
- Halten Sie das Produkt von Kindern und anderen unbefugten Personen fern.
- Überprüfen Sie regelmäßig auf Rückrufinformationen über das EU Safety GateSystem.

Spezifische Sicherheitsvorkehrungen für die Verwendung

- Tragen Sie immer geeignete Schutzausrüstung, einschließlich Augen und Gehörschutz, während Sie das HP Action Kit verwenden.
- Verwenden Sie das Kit nur mit den angegebenen Modellen (Volquartsen und Ruger Werksverschlüsse und Abzugsbügel).
- Überprüfen Sie vor der Verwendung, ob alle Teile des Kits ordnungsgemäß installiert und in gutem Zustand sind.
- Achten Sie darauf, dass sich keine Fremdkörper im Bereich des Abzugs oder der Mechanik befinden.
- Verwenden Sie das Kit nicht, wenn es beschädigt ist oder Anzeichen von Verschleiß aufweist.

Anweisungen zur Installation und Verwendung

Installation

1. **Vorbereitung:** Stellen Sie sicher, dass die Waffe entladen ist und sich in einem sicheren Zustand befindet.
2. **Teile überprüfen:** Überprüfen Sie alle Teile des Kits auf Vollständigkeit und Unversehrtheit.
3. **Installation:**
 - Entfernen Sie den alten Abzug und die zu ersetzenen Teile gemäß der Herstelleranleitung.
 - Installieren Sie die neuen Teile des HP Action Kits, einschließlich des Target Hammer, Target Disconnector, Target Sear, Target Trigger und der Rückstoßpuffer.
 - Stellen Sie sicher, dass alle Teile fest sitzen und korrekt ausgerichtet sind.
4. **Prüfung:** Testen Sie die Funktion des Abzugs, um sicherzustellen, dass alles ordnungsgemäß funktioniert, bevor Sie das Produkt verwenden.

Verwendung

- Stellen Sie sicher, dass Sie in einem sicheren und geeigneten Bereich schießen.
- Überprüfen Sie vor jedem Schuss die Sicherheit der Waffe.
- Halten Sie den Abzug nicht gedrückt, während Sie die Waffe laden oder entladen.
- Achten Sie auf die Umgebung und andere Personen, wenn Sie das HP Action Kit verwenden.

Entsorgungsanweisungen

- Entsorgen Sie alle Teile des HP Action Kits gemäß den örtlichen Vorschriften für die Entsorgung von Elektronik und gefährlichen Materialien.
- Stellen Sie sicher, dass keine Teile in die Hände von Kindern gelangen.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder Unterstützung zu Ihrem HP Action Kit, Black, 10/22, Add Plus Kit, wenden Sie sich bitte an den Kundendienst des Herstellers oder besuchen Sie die offizielle Website. Dort finden Sie weitere Informationen und Unterstützung.

Bitte beachten Sie, dass diese Sicherheitshinweise dazu dienen, Ihre Sicherheit und die Sicherheit anderer zu gewährleisten. Befolgen Sie alle Anweisungen sorgfältig, um ein sicheres und effektives Schießergebnis zu gewährleisten.

HP Action Kit Safety Instruction Guide

Introduction

Thank you for purchasing the HP Action Kit, Black, 10/22, Add Plus Kit. This guide provides essential safety instructions to ensure the safe and effective use of your product. Please read this document carefully before installation and usage.

General Safety Guidelines

- Ensure the product is used only by individuals who are familiar with firearms and their operation.
- Always treat your firearm as if it is loaded, and follow all standard safety procedures.
- Store the HP Action Kit in a safe place, out of reach of children and unauthorized users.
- Regularly inspect the product for wear or damage. Do not use if any parts are worn or damaged.
- Report any unsafe products or accidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Do not use the HP Action Kit with incompatible parts from other manufacturers.
- Ensure that the firearm is unloaded before installing or adjusting the HP Action Kit.
- Avoid using excessive force during installation to prevent damage to the components.
- Keep fingers away from the trigger until you are ready to shoot.
- Use appropriate eye and ear protection when operating the firearm.
- Be aware of your surroundings and ensure a safe shooting environment.
- Do not modify the HP Action Kit in any way that is not specified in the instructions.

Instructions for Installation and Usage

1. Installation:

- Ensure the firearm is unloaded and pointed in a safe direction.
- Remove the existing trigger assembly from the firearm according to the manufacturer's instructions.
- Install the target hammer, ensuring that all shims and bushings are correctly positioned.
- Replace the hammer spring, target disconnector, target sear, and target trigger as per the installation guidelines.
- Adjust the overtravel using the polished plunger and spring.
- Install the recoil buffer to reduce wear on the action and bolt.

2. Usage:

- After installation, perform a function check to ensure the trigger operates correctly.
- Adjust the trigger pull weight to your preference, aiming for approximately 2.25 - 2.5 lbs.
- Use the Extended Magazine Release and Auto Bolt Release as intended, ensuring compatibility with Volquartsen and Ruger factory bolts and trigger guards.
- Always follow safe shooting practices when using the firearm equipped with the HP Action Kit.

Disposal Instructions

- Dispose of the HP Action Kit in accordance with local regulations regarding electronic and firearm components.
- Do not dispose of the product in regular household waste.
- Contact your local waste management authority for guidance on proper disposal methods.

Contact Information for Further Support

For further assistance or inquiries regarding the HP Action Kit, please contact the manufacturer or your point of purchase. Be sure to have your product details available for reference.

Thank you for prioritizing safety while using the HP Action Kit. Enjoy your enhanced shooting experience!

