

# **Standard Recoil Spring for MKII, MKIII, MK IV, and 22/45**

## **Standard Recoil Spring for MKII, MKIII, MK IV, and 22/45**

Replacement spring for our Recoil Rod and Spring Kit for MKII, MKIII, MK IV, and 22/45 as well as our Black Mamba and Scorpion pistols.

Please note: this spring is designed only for use with the recoil rod packaged in our kit.

### **Attributes**

- Name: Standard Recoil Spring for MKII, MKIII, MK IV, and 22/45
- Manufacturer: VOLQUARTSEN
- Product no.: BRD231094
- Mfr. No.: VC3RSO-S
- Make: Ruger
- Model: MKII, MKIII, MK IV, 22/45
- Delivery weight: 0.3kg
- UPC: 810162018672

# Table of Contents

- Startpage
- Deutsch: Sicherheitshinweise für die Standard Rückstoßfeder für MKII, MKIII, MK IV und 22/45
- English: Standard Recoil Spring for MKII, MKIII, MK IV, and 22/45 Safety Instructions

# Sicherheitshinweise für die Standard Rückstoßfeder für MKII, MKIII, MK IV und 22/45

## Einleitung

Diese Sicherheitshinweise gelten für die Standard Rückstoßfeder, die für die Modelle MKII, MKIII, MK IV und 22/45 entwickelt wurde. Sie sind wichtig, um die sichere Verwendung des Produkts zu gewährleisten und potenzielle Gefahren zu vermeiden. Bitte lesen Sie diese Anleitung sorgfältig durch, bevor Sie das Produkt verwenden.

## Allgemeine Sicherheitshinweise

- Stellen Sie sicher, dass Sie die Rückstoßfeder nur mit der Rückstoßstange aus unserem Kit verwenden.
- Überprüfen Sie das Produkt vor der Verwendung auf sichtbare Schäden oder Abnutzung.
- Lagern Sie die Rückstoßfeder an einem trockenen Ort, fern von Kindern und Haustieren.
- Verwenden Sie das Produkt nur für den vorgesehenen Zweck.
- Halten Sie sich an alle geltenden Gesetze und Vorschriften bezüglich des Umgangs mit Feuerwaffen und deren Zubehör.

## Spezifische Sicherheitsvorkehrungen für die Verwendung

- Verwenden Sie die Rückstoßfeder nicht, wenn Sie Anzeichen von Beschädigungen feststellen.
- Achten Sie darauf, dass die Rückstoßfeder korrekt installiert ist, um Fehlfunktionen zu vermeiden.
- Tragen Sie beim Umgang mit dem Produkt geeignete Schutzausrüstung, wie z.B. Schutzbrille und Handschuhe.
- Lassen Sie das Produkt nicht unbeaufsichtigt, während es in Gebrauch ist.
- Bei Unsicherheiten oder Fragen zur Verwendung wenden Sie sich an einen Fachmann.

## Anweisungen zur Installation und Verwendung

### 1. Vorbereitung:

- Stellen Sie sicher, dass die Waffe entladen ist und sich in einem sicheren Zustand befindet.
- Entfernen Sie die alte Rückstoßfeder, falls vorhanden.

### 2. Installation:

- Setzen Sie die neue Rückstoßfeder vorsichtig in die Rückstoßstange ein.
- Stellen Sie sicher, dass die Feder richtig positioniert ist und sicher sitzt.

### 3. Überprüfung:

- Überprüfen Sie nach der Installation, ob alles ordnungsgemäß funktioniert.
- Führen Sie einen Funktionstest durch, um sicherzustellen, dass die Rückstoßfeder korrekt arbeitet.

### 4. Benutzung:

- Verwenden Sie die Waffe gemäß den Herstelleranweisungen und den geltenden Vorschriften.
- Achten Sie darauf, die Rückstoßfeder regelmäßig auf Abnutzung oder Beschädigung zu überprüfen.

## Entsorgungsanweisungen

- Entsorgen Sie die Rückstoßfeder gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Stellen Sie sicher, dass die Feder nicht in die Hände von Kindern gelangt, wenn Sie sie entsorgen.

## Kontaktinformationen für weitere Unterstützung

Für Fragen oder weitere Informationen zu diesem Produkt wenden Sie sich bitte an den Hersteller oder einen autorisierten Fachhändler. Es ist wichtig, dass Sie bei Unsicherheiten oder Problemen qualifizierte Hilfe in Anspruch nehmen.

Bitte beachten Sie, dass diese Sicherheitshinweise gemäß den EUVorgaben für Produktsicherheit erstellt wurden.  
Halten Sie sich immer an die genannten Richtlinien, um Ihre Sicherheit und die Sicherheit anderer zu gewährleisten.

# Standard Recoil Spring for MKII, MKIII, MK IV, and 22/45 Safety Instructions

## Introduction

Thank you for choosing the Standard Recoil Spring for MKII, MKIII, MK IV, and 22/45. This safety instruction guide is designed to help you understand the proper use, installation, and disposal of the recoil spring, ensuring a safe experience. Please read this guide carefully before using the product.

## General Safety Guidelines

- Ensure that all safety instructions are followed to prevent accidents or injuries.
- Always handle the recoil spring with care, keeping it away from children and pets.
- Use the recoil spring only with the specified recoil rod packaged in our kit.
- Regularly inspect the recoil spring for any signs of wear or damage before each use.
- Report any unsafe conditions or accidents to the appropriate authorities.

## Specific Safety Precautions for Use

- Only use the recoil spring with compatible models: MKII, MKIII, MK IV, and 22/45.
- Do not modify the recoil spring or use it in any manner other than intended.
- Wear appropriate safety gear, such as eye protection, when handling or installing the recoil spring.
- Ensure that the firearm is unloaded and pointed in a safe direction before installation.
- Keep fingers and hands clear of moving parts during installation and use.

## Instructions for Installation and Usage

### 1. Preparation:

- Ensure the firearm is completely unloaded.
- Gather necessary tools, including a suitable screwdriver and safety gear.

### 2. Installation:

- Remove the existing recoil spring from the recoil rod.
- Carefully install the new Standard Recoil Spring onto the recoil rod, ensuring it is seated properly.
- Doublecheck that the recoil spring is securely attached before reassembling the firearm.

### 3. Usage:

- After installation, test the firearm in a safe environment to confirm proper function.
- Monitor the recoil spring during use for any unusual sounds or performance issues.
- If any issues arise, discontinue use immediately and consult a qualified gunsmith.

## Disposal Instructions

- Dispose of the recoil spring in accordance with local regulations.
- Do not dispose of the recoil spring in regular household waste.
- Consider recycling options if available in your area.

## Contact Information for Further Support

For any inquiries or concerns regarding the Standard Recoil Spring, please refer to the official contact points provided with your product packaging or visit the manufacturer's website.

Thank you for your attention to these safety instructions. Your safety is our priority.