

Accurizing Kit for the Ruger MK IV Pistol, Gold Trigger - VOLQUARTSEN

Accurizing Kit for the Ruger MK IV Pistol, Gold Trigger

The complete drop-in kit comes complete with our CNC Machined Disconnector, Target Hammer, Hammer Bushing, and Target Sear. It also comes with pretravel and overtravel adjustments.

The Accurizing Kit for the Ruger MK IV will provide a crisp, clean 2.25lb trigger pull. This kit will eliminate the magazine disconnect.

Attributes

- Name: VOLQUARTSEN Accurizing Kit for the Ruger MK IV Pistol, Gold Trigger
- Manufacturer: VOLQUARTSEN
- Product no.: BRD231118
- Mfr. No.: VC4AK-GT
- Color: Gold
- Make: Ruger
- Model: MK IV
- Weight: 2.25 lbs
- Delivery weight: 0.3kg
- UPC: 810162019556

Table of Contents

- Startpage
- Deutsch: Sicherheitshinweise für das Accurizing Kit für die Ruger MK IV Pistole, Gold Trigger
- English: Accurizing Kit for the Ruger MK IV Pistol Safety Instructions

Sicherheitshinweise für das Accurizing Kit für die Ruger MK IV Pistole, Gold Trigger

Einführung

Herzlichen Glückwunsch zu Ihrem Kauf des Accurizing Kits für die Ruger MK IV Pistole mit Gold Trigger von VOLQUARTSEN. Dieses Kit wurde entwickelt, um die Leistung Ihrer Pistole zu verbessern. Bitte lesen Sie diese Sicherheitshinweise sorgfältig durch, um sicherzustellen, dass Sie das Produkt sicher und effektiv verwenden.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass Sie die Bedienungsanleitung Ihrer Ruger MK IV Pistole vollständig gelesen haben, bevor Sie das Accurizing Kit installieren.
- Verwenden Sie das Kit nur für den vorgesehenen Zweck.
- Halten Sie das Kit und alle Teile außerhalb der Reichweite von Kindern und unbefugten Personen.
- Überprüfen Sie regelmäßig alle Teile auf Beschädigungen oder Abnutzung.
- Melden Sie unsichere Produkte oder Unfälle an die zuständigen Behörden.

Spezifische Sicherheitsvorkehrungen für die Verwendung

- Verwenden Sie bei der Installation des Kits geeignete Schutzausrüstung, einschließlich Schutzbrille und Handschuhe.
- Stellen Sie sicher, dass die Waffe vor der Installation entladen ist.
- Arbeiten Sie in einem gut beleuchteten und sauberen Bereich, um Unfälle zu vermeiden.
- Vermeiden Sie es, während der Installation abgelenkt zu werden.
- Achten Sie darauf, dass alle Teile korrekt installiert und fest angezogen sind, um Fehlfunktionen zu vermeiden.

Anweisungen zur Installation und Verwendung

1. Vorbereitung

- Entladen Sie die Ruger MK IV Pistole vollständig.
- Stellen Sie sicher, dass alle Werkzeuge und Teile bereitliegen.

2. Installation des Kits

- Entfernen Sie den alten Disconnector, Hammer und Sear gemäß der Bedienungsanleitung Ihrer Pistole.
- Installieren Sie den CNCgefrästen Disconnector, Target Hammer, Hammer Bushing und Target Sear des Accurizing Kits.
- Stellen Sie die Pretravel und OvertravelAnpassungen gemäß den Anweisungen im Kit ein.
- Überprüfen Sie alle Verbindungen und stellen Sie sicher, dass sie fest sitzen.

3. Nach der Installation

- Führen Sie einen Funktionstest durch, um sicherzustellen, dass der Abzug ordnungsgemäß funktioniert.
- Achten Sie auf den knackigen, sauberen Abzug von 2,25 lb.

Entsorgungsanweisungen

- Entsorgen Sie alle alten Teile der Pistole und des Kits gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Stellen Sie sicher, dass keine Teile in die Hände von Kindern gelangen.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder weitere Unterstützung steht Ihnen der Hersteller zur Verfügung. Bitte konsultieren Sie die Verpackung oder die Website des Herstellers für spezifische Kontaktdaten.

Bitte beachten Sie, dass diese Sicherheitshinweise nicht alle potenziellen Gefahren abdecken können. Seien Sie stets vorsichtig und verantwortungsbewusst im Umgang mit Ihrer Waffe und dem Accurizing Kit.

Accurizing Kit for the Ruger MK IV Pistol Safety Instructions

Introduction

Thank you for purchasing the Accurizing Kit for the Ruger MK IV Pistol, Gold Trigger by VOLQUARTSEN. This guide provides essential safety instructions and guidelines to ensure the safe use and installation of your product. Please read this document carefully before using the kit to avoid any hazards and ensure compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that all components are compatible with the Ruger MK IV Pistol before installation.
- Always handle firearms with care, treating them as if they are loaded.
- Keep the Accurizing Kit and all related tools out of reach of children and unauthorized users.
- Do not modify or alter any components of the kit beyond the provided instructions.
- Regularly inspect your firearm and the Accurizing Kit for any signs of wear or damage.
- Report any unsafe products or accidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, such as safety glasses and gloves, when handling the kit and during installation.
- Ensure that the firearm is unloaded and pointed in a safe direction before beginning installation.
- Avoid distractions while installing the kit; focus solely on the task at hand.
- Be aware of potential pinch points during installation and use.
- After installation, test the trigger pull in a safe environment to ensure proper function before using the firearm.

Instructions for Installation and Usage

1. Preparation

- Gather all necessary tools and components from the Accurizing Kit.
- Ensure your workspace is clean and free from clutter.

2. Installation Steps

- Remove the magazine and ensure the firearm is unloaded.
- Disassemble the Ruger MK IV Pistol according to the manufacturer's instructions.
- Replace the existing components with those provided in the Accurizing Kit:
 - Install the CNC Machined Disconnector.
 - Replace the Hammer with the Target Hammer.
 - Insert the Hammer Bushing.
 - Install the Target Sear.
- Adjust pretravel and overtravel settings as desired.
- Reassemble the firearm carefully, ensuring all parts are correctly seated.

3. Testing

- After installation, perform a function check:
 - Ensure the trigger pull is crisp and clean, approximately 2.25 lbs.
 - Check that the magazine disconnect has been eliminated.
- Conduct a safety check to confirm the firearm operates correctly.

4. Usage

- Use the firearm in a safe and controlled environment.
- Follow all local laws and regulations regarding firearm usage.

Disposal Instructions

- Dispose of any packaging materials in accordance with local waste management regulations.
- If any components of the Accurizing Kit become damaged or unusable, dispose of them responsibly, ensuring they do not pose a hazard to others.

Contact Information for Further Support

For any questions or additional support regarding the Accurizing Kit for the Ruger MK IV Pistol, please refer to the manufacturer's website or customer service contacts provided with your product.

Thank you for prioritizing safety and compliance while using the Accurizing Kit for the Ruger MK IV Pistol. Enjoy your enhanced shooting experience!