

Accurizing Kit for the Ruger MK IV Pistol, Stainless Trigger

The complete drop-in kit comes complete with our CNC Machined Disconnector, Target Hammer, Hammer Bushing, Target Sear, Target Trigger with plunger and spring. It also comes with pretravel and overtravel adjustments and includes medium strength Loctite to secure the adjustment screws.

The Accurizing Kit for the Ruger MK IV will provide a crisp, clean 2.25lb trigger pull. This kit will eliminate the magazine disconnect.

Attributes

- Name: Accurizing Kit for the Ruger MK IV Pistol, Stainless Trigger
- Manufacturer: VOLQUARTSEN
- Product no.: BRD231120
- Mfr. No.: VC4AK-ST
- Color: Stainless
- Make: Ruger
- Model: MK IV
- Weight: 2.25 lbs
- Delivery weight: 0.3kg
- UPC: 810162017293

Table of Contents

- Startpage
- Deutsch: Sicherheitshinweise für das Accurizing Kit für die Ruger MK IV Pistole
- English: Accurizing Kit for the Ruger MK IV Pistol Safety Instructions

Sicherheitshinweise für das Accurizing Kit für die Ruger MK IV Pistole

Einführung

Herzlichen Glückwunsch zu Ihrem Kauf des Accurizing Kits für die Ruger MK IV Pistole. Dieses Kit wurde entwickelt, um die Leistung Ihrer Waffe zu verbessern und einen sauberen Abzug zu gewährleisten. Um die Sicherheit bei der Verwendung dieses Produkts zu gewährleisten, befolgen Sie bitte die folgenden Sicherheitshinweise und Anweisungen.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass Sie beim Umgang mit Waffen immer die grundlegenden Sicherheitsregeln befolgen.
- Verwenden Sie das Kit nur für den vorgesehenen Zweck, um Verletzungen oder Schäden zu vermeiden.
- Halten Sie das Kit und alle Teile außerhalb der Reichweite von Kindern.
- Überprüfen Sie regelmäßig auf Anzeichen von Abnutzung oder Beschädigung.
- Informieren Sie sich über die gesetzlichen Bestimmungen in Ihrem Land bezüglich der Verwendung von Waffen und Zubehör.

Spezifische Sicherheitsvorkehrungen für die Verwendung

- Verwenden Sie das Kit nicht, wenn Sie unter dem Einfluss von Alkohol oder Drogen stehen.
- Tragen Sie beim Arbeiten an Ihrer Waffe immer Schutzbrille und Handschuhe.
- Stellen Sie sicher, dass die Waffe entladen ist, bevor Sie mit der Installation des Kits beginnen.
- Arbeiten Sie in einem gut beleuchteten und sauberen Bereich, um Unfälle zu vermeiden.
- Führen Sie alle Anpassungen und Installationen gemäß den Anweisungen in diesem Handbuch durch.

Anweisungen zur Installation und Verwendung

1. Vorbereitung

- Stellen Sie sicher, dass die Waffe entladen ist.
- Legen Sie alle Teile des Kits auf eine saubere, flache Oberfläche.

2. Installation

- Entfernen Sie den alten Disconnector, Target Hammer, Hammer Bushing, Target Sear und Target Trigger.
- Installieren Sie die neuen Teile gemäß den beiliegenden Anweisungen.
- Achten Sie darauf, die Pretravel und OvertravelAnpassungen vorzunehmen.
- Verwenden Sie mittlere Stärke Loctite, um die Einstellschrauben zu sichern.

3. Überprüfung

- Überprüfen Sie nach der Installation, ob alle Teile korrekt sitzen und funktionieren.
- Führen Sie einen Funktionstest durch, um sicherzustellen, dass der Abzug sauber und reaktionsschnell ist.

4. Verwendung

- Nutzen Sie die Pistole nur auf zugelassenen Schießständen oder in sicheren Umgebungen.
- Halten Sie die Waffe immer in eine sichere Richtung und seien Sie sich Ihrer Umgebung bewusst.

Entsorgungsanweisungen

- Entsorgen Sie alle Verpackungsmaterialien und nicht verwendeten Teile gemäß den örtlichen Vorschriften für Abfallentsorgung.
- Stellen Sie sicher, dass keine Teile des Kits im Müll verbleiben, die für Kinder oder Haustiere gefährlich sein könnten.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder weitere Informationen zu Ihrem Accurizing Kit wenden Sie sich bitte an den Hersteller oder einen autorisierten Fachhändler.

Bitte beachten Sie, dass die Sicherheit Ihrer Waffe und der richtigen Verwendung des Kits in Ihrer Verantwortung liegt. Halten Sie sich stets an die Sicherheitsrichtlinien und vorkehrungen, um ein sicheres Schießerlebnis zu gewährleisten.

Accurizing Kit for the Ruger MK IV Pistol Safety Instructions

Introduction

Thank you for choosing the Accurizing Kit for the Ruger MK IV Pistol. This guide provides essential safety instructions and information to ensure the safe and effective use of your product. Please read this manual carefully before installation and usage.

General Safety Guidelines

To ensure your safety and the safety of others, please adhere to the following general safety guidelines:

- Always treat your firearm as if it is loaded, even if you believe it is not.
- Ensure your workspace is clean and free of distractions during installation and usage.
- Keep the Accurizing Kit and all firearm components out of reach of children and unauthorized users.
- Use protective eyewear when handling tools and during installation.
- Always follow the manufacturer's instructions for your firearm.

Specific Safety Precautions for Use

When using the Accurizing Kit, please observe the following precautions:

- Ensure the firearm is unloaded before beginning installation.
- Do not attempt to install the kit if you are unfamiliar with firearm components or lack the necessary tools.
- Be cautious of sharp edges on machined parts.
- Ensure all parts are securely fastened before using the firearm.
- Regularly inspect the installed components for wear or damage.
- Do not modify the kit or use it in ways not intended by the manufacturer.

Instructions for Installation and Usage

Follow these steps for the safe installation and usage of the Accurizing Kit:

1. Preparation:

- Gather all necessary tools, including a screwdriver and medium strength Loctite.
- Ensure the Ruger MK IV Pistol is unloaded and pointed in a safe direction.

2. Installation Steps:

- Remove the existing trigger components from the Ruger MK IV Pistol.
- Install the CNC Machined Disconnector in accordance with the manufacturer's specifications.
- Attach the Target Hammer and Hammer Bushing securely.
- Install the Target Sear and ensure it is correctly positioned.
- Insert the Target Trigger with plunger and spring.
- Make adjustments for pretravel and overtravel as needed.
- Use medium strength Loctite to secure the adjustment screws.

3. Final Checks:

- After installation, perform a function check of the trigger to ensure proper operation.
- Confirm that the magazine disconnect has been eliminated as intended.
- Store the firearm in a safe location when not in use.

Disposal Instructions

When disposing of the Accurizing Kit or any firearm components:

- Follow local laws and regulations regarding the disposal of firearm parts.
- Do not dispose of components in regular household waste.
- Contact local law enforcement or a licensed firearms dealer for proper disposal methods.

Contact Information for Further Support

For safety inquiries or additional support regarding the Accurizing Kit for the Ruger MK IV Pistol, please refer to the manufacturer's contact information included with the product packaging or visit their official website.

Conclusion

By following these safety instructions, you can help ensure a safe and enjoyable experience with your Accurizing Kit for the Ruger MK IV Pistol. Always prioritize safety and responsibility when handling firearms. Thank you for your attention to these important guidelines.