

Summit Rifle, 22 LR, Barreled Action Only

[Rifle Parts](#) > [Receiver Parts](#) > [Receivers](#) > [Barreled Receivers](#)

The Volquartsen Summit bolt action is based on a concept originally developed by Primary Weapons Systems. The Volquartsen Summit represents the combination of their innovative design and 40+ years of our own rimfire experience,



Designed for both competition shooting as well as small game hunting, this unique rifle is a straight-pull bolt action inspired by the 10/22 style platform. The CNC-machined receiver features an integral 20 MOA Picatinny Rail, making it the perfect rifle for any rimfire long range shooting.

This innovative design is built for everyone from the junior just getting into shooting to the accomplished competitor. It features everything you could ask for.

Attributes

- Name: [Summit Rifle, 22 LR, Barreled Action Only](#)
- Manufacturer: [VOLQUARTSEN](#)
- Product no.: BRD231155
- Mfr. No.: VCB-LR-BA
- Barrel Finish: Carbon
- Caliber: .22lr
- Elevation: 20 MOA
- Make: Ruger
- Material: Anodized Aluminum
- Model: Summit
- Muzzle Threads: 1/2-28
- Rounds: 10-Round
- Twist Rate: 1-16
- Delivery weight: 1.8kg
- UPC: 810162019204

Item details

EU Export Disabled

Table of Contents

- Startpage
- Safety Instruction Guide for the Summit Rifle, 22 LR, Barreled Action Only
- About Us

Safety Instruction Guide for the Summit Rifle, 22 LR, Barreled Action Only

Introduction

Thank you for choosing the Summit Rifle, 22 LR, Barreled Action Only by Volquartsen. This guide provides essential safety instructions to ensure the safe use of your rifle. Please read and understand all safety guidelines and instructions before using the product. Adhering to these guidelines will help you avoid potential hazards and enjoy your shooting experience.

General Safety Guidelines

- Always treat the rifle as if it is loaded, even when you believe it is not.
- Keep the rifle pointed in a safe direction at all times.
- Only load the rifle when you are ready to shoot.
- Ensure the safety is engaged until you are ready to fire.
- Keep your finger off the trigger until you are ready to shoot.
- Be aware of your target and what lies beyond it.
- Use appropriate eye and ear protection while shooting.
- Store the rifle in a secure location, out of reach of children and unauthorized users.
- Regularly inspect the rifle for any signs of damage or wear before use.
- Follow all local laws and regulations regarding firearm use and ownership.

Specific Safety Precautions for Use

- Ensure you are of legal age to possess and operate a firearm in your jurisdiction.
- Do not use the rifle under the influence of alcohol, drugs, or any substances that may impair your judgment.
- Only use ammunition that is specified for the Summit Rifle, .22 LR.
- Be cautious of environmental conditions, such as wind and lighting, that may affect shooting safety.
- Always inform others in the vicinity when you are about to shoot.
- Do not attempt to modify or alter the rifle in any way.
- If the rifle fails to fire, keep the muzzle pointed downrange and wait at least 30 seconds before attempting to clear the malfunction.

Instructions for Installation and Usage

Installation

1. **Unboxing:** Carefully remove the rifle from the packaging. Inspect all components for damage.
2. **Mounting Accessories:** If you plan to mount a scope or other accessories, ensure they are compatible with the 20 MOA Picatinny Rail.
3. **Loading the Magazine:** Insert the .22 LR ammunition into the 10round magazine. Ensure that the rounds are seated properly.
4. **Inserting the Magazine:** Insert the loaded magazine into the rifle until it clicks into place.
5. **Chambering a Round:** Pull the bolt back fully and release it to chamber a round. Ensure the safety is engaged during this process.

Usage

1. **Setting Up for Shooting:** Find a safe and appropriate shooting range or area. Ensure you have a clear line of sight and a safe backdrop.
2. **Aiming:** Use proper shooting stance and grip. Align your sights with the target.
3. **Firing:** When ready, disengage the safety and gently squeeze the trigger to fire.

4. **After Shooting:** Once you have finished shooting, engage the safety, remove the magazine, and clear the chamber by pulling the bolt back and visually inspecting it.

Disposal Instructions

When disposing of the Summit Rifle or its components, follow these guidelines:

- Do not dispose of the rifle in regular household waste.
- Contact local authorities or a licensed firearms dealer for safe disposal options.
- Ensure all ammunition is used or disposed of in accordance with local regulations.

Contact Information for Further Support

For any inquiries regarding safety, usage, or support, please refer to the manufacturer's contact information included in the product packaging or your purchase receipt.

Conclusion

By following these safety instructions, you can ensure a safe and enjoyable experience with your Summit Rifle, 22 LR, Barreled Action Only. Always prioritize safety and responsibility in all aspects of firearm use. Thank you for your attention to these important guidelines.

About Us

Brownells Deutschland

**Brownells Deutschland - Einer der größten Lieferanten für Waffenteile,
Büchsenmacherwerkzeug & Schießsportzubehör**

Lahnstraße 1
24539 Neumünster
Deutschland

www.brownells-deutschland.de