

# **Target Hammer for Remington 597**

This is a wire EDM-cut, fully machined hammer. It will provide approximately a 50% lighter trigger pull. It is a drop-in item designed to be used in an unaltered factory trigger guard. Made of A2 tool steel, hardened to Rc 58–60. Fits the Remington 597 22LR, 22 WMR and 17 HMR.

## **Attributes**

- Name: Target Hammer for Remington 597
- Manufacturer: VOLQUARTSEN
- Product no.: BRD231203
- Mfr. No.: VCRTH
- Make: Remington
- Model: 597 22LR, 22 WMR, 17 HMR
- Delivery weight: 0.2kg
- UPC: 810162011321

# Table of Contents

- Startpage
- Deutsch: Sicherheitshinweise für den Target Hammer für Remington 597
- English: Target Hammer for Remington 597 Safety Instruction Guide

# Sicherheitshinweise für den Target Hammer für Remington 597

## Einleitung

Herzlichen Glückwunsch zu Ihrem Kauf des Target Hammers für Remington 597. Dieses Produkt wurde entwickelt, um Ihnen ein verbessertes Schießerlebnis zu bieten. Bitte lesen Sie diese Sicherheitshinweise sorgfältig durch, um sicherzustellen, dass Sie das Produkt sicher und effektiv verwenden.

## Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass das Produkt nur von Personen verwendet wird, die über die erforderlichen Kenntnisse im Umgang mit Feuerwaffen verfügen.
- Bewahren Sie den Target Hammer außerhalb der Reichweite von Kindern auf.
- Überprüfen Sie regelmäßig den Zustand des Hammers und der Waffe, um sicherzustellen, dass sie einwandfrei funktionieren.
- Melden Sie unsichere Produkte oder Unfälle umgehend den zuständigen Behörden.
- Informieren Sie sich über Rückrufupdates über die Plattform Safety Gate der EU.

## Spezifische Sicherheitsvorkehrungen für die Verwendung

- Verwenden Sie den Target Hammer nur in Verbindung mit der Remington 597 Waffe.
- Achten Sie darauf, dass die Waffe immer in einem sicheren Zustand ist, bevor Sie den Hammer installieren oder entfernen.
- Tragen Sie beim Umgang mit der Waffe immer geeignete Schutzausrüstung, einschließlich Gehörschutz und Augenschutz.
- Verwenden Sie den Hammer nicht, wenn Sie Anzeichen von Beschädigungen oder Abnutzung feststellen.
- Halten Sie den Bereich um die Waffe während der Installation frei von Personen und Hindernissen.

## Anweisungen zur Installation und Verwendung

### • Installation:

1. Stellen Sie sicher, dass die Waffe entladen ist.
2. Entfernen Sie den ursprünglichen Hammer gemäß der Bedienungsanleitung der Remington 597.
3. Setzen Sie den Target Hammer an der vorgesehenen Stelle ein.
4. Vergewissern Sie sich, dass der Hammer richtig sitzt, bevor Sie die Waffe wieder zusammenbauen.

### • Verwendung:

1. Überprüfen Sie vor jedem Schuss den Zustand der Waffe und des Hammers.
2. Betätigen Sie den Abzug sanft und gleichmäßig.
3. Nach jedem Gebrauch reinigen Sie den Hammer und die Waffe gemäß den Herstelleranweisungen.

## Entsorgungsanweisungen

- Entsorgen Sie das Produkt gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Stellen Sie sicher, dass alle Teile, die nicht mehr benötigt werden, sicher und umweltgerecht entsorgt werden.

## Kontaktinformationen für weitere Unterstützung

- Bei Fragen oder Anliegen zu Ihrem Produkt wenden Sie sich bitte an den Hersteller oder den zuständigen Händler.

Bitte beachten Sie, dass diese Sicherheitshinweise dazu dienen, Ihre Sicherheit und die Sicherheit anderer zu gewährleisten. Verwenden Sie das Produkt verantwortungsbewusst und beachten Sie alle relevanten Gesetze und Vorschriften.

# Target Hammer for Remington 597 Safety Instruction Guide

## Introduction

Thank you for choosing the Target Hammer for Remington 597. This product is designed to enhance your shooting experience by providing a lighter trigger pull. Please read this safety instruction guide carefully to ensure safe and proper use of the product in compliance with the EU General Product Safety Regulation (GPSR).

## General Safety Guidelines

- Always handle firearms with care and treat every firearm as if it is loaded.
- Ensure that the hammer is installed correctly to prevent accidental discharges.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the hammer for signs of wear or damage before use.
- Use only in accordance with the manufacturer's instructions.
- Report any unsafe conditions or accidents to the appropriate authorities.

## Specific Safety Precautions for Use

- Ensure the firearm is unloaded before installing or replacing the hammer.
- Always wear appropriate eye protection when handling firearms.
- Avoid using the hammer with modified or damaged trigger guards.
- Do not attempt to modify or alter the hammer in any way.
- Store the hammer in a secure location when not in use.
- Be aware of your surroundings and ensure a safe shooting environment.

## Instructions for Installation and Usage

### 1. Preparation

- Ensure the firearm is unloaded and pointed in a safe direction.
- Gather necessary tools for installation (screwdriver, etc.).

### 2. Installation Steps

- Remove the factory trigger guard from the Remington 597.
- Carefully detach the existing hammer from the trigger mechanism.
- Align the Target Hammer with the trigger mechanism.
- Securely attach the Target Hammer, ensuring it is properly seated.
- Reinstall the trigger guard, ensuring it is unaltered and fits securely.

### 3. PostInstallation Check

- Perform a function check by dry firing the firearm in a safe environment.
- Ensure that the trigger pull is lighter and the hammer operates smoothly.

### 4. Usage

- When using the firearm, maintain a proper grip and stance.
- Always be aware of the firearm's condition and functionality during use.
- Follow all standard firearm safety practices.

## Disposal Instructions

- Dispose of the Target Hammer in accordance with local regulations.
- Do not dispose of in regular household waste.
- Contact your local waste disposal authority for proper disposal methods.

## Contact Information for Further Support

For any inquiries regarding the Target Hammer for Remington 597, please consult your retailer or the manufacturer's official website for support and additional information.

By following these safety instructions, you can ensure a safe and enjoyable experience with your Target Hammer for Remington 597. Thank you for your attention to safety and responsible firearm handling.