

Extended Safety - Black - MKII, MKIII, 22/45

Volquartsen Extended Safety for Ruger MKII, MKII 22/45, MKIII and MKIII 22/45

The Volquartsen Extended Safety offers the shooter improved access to the safety on the Ruger MKII, MKII 22/45, MKIII and MKIII 22/45 pistols. It is the perfect addition, especially in combination with target grips. The contour is precisely cut from 17-4 stainless steel using wire EDM. The Extended Safety is .150" longer than the original safety button and comes complete with safety detent and spring.

Features:

- **Fits for:** Ruger MKII, MKII 22/45, MKIII, MKIII 22/45
- **Length:** .150" longer than the original safety button
- **Material:** Precisely cut from 17-4 stainless steel by wire EDM
- **Scope of delivery:** Includes safety detent and spring
- **Compatibility:** Ideal in conjunction with target grip panels

Attributes

- Name: Extended Safety - Black - MKII, MKIII, 22/45
- Manufacturer: VOLQUARTSEN
- Product no.: BRD231504
- Mfr. No.: VC3ES-B
- Finish: Black
- Model: MKII, MKIII, 22/45
- Delivery weight: 0.2kg
- UPC: 810162013103

Table of Contents

- Startpage
- Deutsch: Sicherheitshinweise für die verlängerte Daumensicherung Black MKII, MKIII, 22/45
- English: Extended Safety User Safety Instruction Guide

Sicherheitshinweise für die verlängerte Daumensicherung Black MKII, MKIII, 22/45

Einführung

Herzlichen Glückwunsch zum Kauf der verlängerten Daumensicherung von Volquartsen für die Ruger MKII, MKII 22/45, MKIII und MKIII 22/45 Pistolen. Dieses Produkt wurde entwickelt, um Ihnen eine verbesserte Handhabung und Sicherheit zu bieten. Bitte lesen Sie diese Sicherheitshinweise sorgfältig durch, um eine sichere Nutzung zu gewährleisten.

Allgemeine Sicherheitsrichtlinien

- Sicherstellen, dass das Produkt nur für den vorgesehenen Zweck verwendet wird.
- Vor der Verwendung die Funktionstüchtigkeit des Produkts überprüfen.
- Bei Fragen oder Unsicherheiten zur Verwendung des Produkts, umgehend professionelle Hilfe in Anspruch nehmen.
- Sicherheitsvorkehrungen sind für alle Benutzer wichtig, insbesondere für Kinder und unerfahrene Personen.
- Bei unsachgemäßer Verwendung oder Beschädigung des Produkts, sofortige Nutzung einstellen und das Produkt überprüfen lassen.

Besondere Sicherheitsvorkehrungen für die Verwendung

- Verwenden Sie die verlängerte Daumensicherung nur mit den angegebenen Modellen (Ruger MKII, MKII 22/45, MKIII, MKIII 22/45).
- Achten Sie darauf, dass die Sicherung beim Schießen korrekt funktioniert und leicht zugänglich ist.
- Halten Sie den Finger stets vom Abzug entfernt, bis Sie bereit sind zu schießen.
- Verwenden Sie die Sicherung nicht unter Bedingungen, die die Sicherheit beeinträchtigen könnten, wie z.B. bei Nässe oder Schmutz.
- Bei Anzeichen von Beschädigungen oder Fehlfunktionen, das Produkt umgehend nicht mehr verwenden und einen Fachmann konsultieren.

Anweisungen zur Installation und Verwendung

1. Installation:

- Entfernen Sie die alte Sicherung gemäß der Anleitung des Herstellers.
- Setzen Sie die verlängerte Daumensicherung in die vorgesehene Position ein.
- Achten Sie darauf, dass die Sicherung fest sitzt und korrekt funktioniert.
- Überprüfen Sie die Installation, indem Sie die Sicherung mehrmals betätigen.

2. Verwendung:

- Stellen Sie sicher, dass die Waffe entladen ist, bevor Sie die Sicherung aktivieren oder deaktivieren.
- Um die Sicherung zu aktivieren, drücken Sie die verlängerte Daumensicherung nach unten.
- Um die Sicherung zu deaktivieren, drücken Sie die verlängerte Daumensicherung nach oben.
- Überprüfen Sie regelmäßig die Funktionalität der Sicherung während der Nutzung.

Entsorgungsanweisungen

- Entsorgen Sie das Produkt nach den örtlichen Vorschriften für Metallabfälle.
- Stellen Sie sicher, dass das Produkt nicht in die Hände von Kindern gelangt, wenn es entsorgt wird.
- Bei Unsicherheiten zur Entsorgung, wenden Sie sich an die örtlichen Behörden oder Recyclingzentren.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder Unterstützung zu diesem Produkt, wenden Sie sich bitte an den Hersteller oder den Händler, bei dem Sie das Produkt erworben haben. Es ist wichtig, dass Sie bei Sicherheitsanfragen einen Ansprechpartner haben.

Bitte beachten Sie, dass diese Sicherheitshinweise Ihnen helfen sollen, das Produkt sicher und effektiv zu nutzen. Ihre Sicherheit hat oberste Priorität.

Extended Safety User Safety Instruction Guide

Introduction

Thank you for choosing the Volquartsen Extended Safety for your Ruger MKII, MKII 22/45, MKIII, and MKIII 22/45 pistols. This safety component is designed to enhance your shooting experience by providing improved access to the safety mechanism. Please read this safety instruction guide carefully to ensure safe usage and compliance with EU General Product Safety Regulations.

General Safety Guidelines

- Ensure that you handle all firearms with care and treat them as if they are always loaded.
- Familiarize yourself with the specific safety features of your firearm model.
- Always follow the manufacturer's instructions and guidelines when using firearm accessories.
- Keep this product out of reach of children and unauthorized users.
- Report any unsafe products or incidents to the appropriate authorities.
- Regularly check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always ensure that the firearm is unloaded before installing or adjusting the Extended Safety.
- Inspect the Extended Safety for any damage before use. Do not use if damaged.
- Avoid any modifications to the Extended Safety that are not approved by the manufacturer.
- Do not rely solely on the safety mechanism; always follow proper firearm handling procedures.
- Be mindful of your surroundings and ensure that you have a safe shooting environment.

Instructions for Installation and Usage

1. Installation of the Extended Safety:

- Ensure the firearm is unloaded.
- Use a proper tool to remove the original safety button.
- Align the Volquartsen Extended Safety with the designated area on the firearm.
- Securely fasten the Extended Safety in place.
- Install the safety detent and spring as provided in the package.

2. Usage of the Extended Safety:

- To engage the safety, push the Extended Safety button fully forward.
- To disengage the safety, push the button fully backward.
- Ensure that the safety mechanism operates smoothly and without obstruction.
- Regularly check the functionality of the Extended Safety before each use.

Disposal Instructions

- Dispose of the Extended Safety in accordance with local regulations for metal waste.
- Ensure that all components are disposed of properly to prevent environmental harm.
- Do not throw away in regular household waste.

Contact Information for Further Support

For any inquiries related to the product or safety concerns, please consult the manufacturer's official website or customer service channels.

By following these guidelines and instructions, you can ensure the safe usage of the Volquartsen Extended Safety and enhance your overall shooting experience. Thank you for your attention to safety.