

Loaded Chamber Indicator Filler - Black - MKIII

Volquartsen Loaded Chamber Indicator Filler for Ruger MKIII

The Volquartsen Loaded Chamber Indicator Filler for the Ruger MKIII pistol is precision cut from stainless steel using wire EDM. This filler replaces the original indicator and provides a clean, smooth look and improved reliability of the gun.

Features:

- **Material:** Stainless steel
- **Manufacture:** Precisely cut using wire EDM
- **Function:** Replaces the original load level indicator for improved appearance and reliability
- **Compatibility:** Fits Ruger MKIII pistols

Attributes

- Name: Loaded Chamber Indicator Filler - Black - MKIII
- Manufacturer: VOLQUARTSEN
- Product no.: BRD231506
- Mfr. No.: VC3LCI-B
- Finish: Black
- Model: MKIII
- Delivery weight: 0.1kg
- UPC: 810162013936

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für den Volquartsen Loaded Chamber Indicator Filler Black MKIII](#)
- [English: Safety Instruction Guide for Volquartsen Loaded Chamber Indicator Filler Black MKIII](#)

Sicherheitshinweise für den Volquartsen Loaded Chamber Indicator Filler Black MKIII

Einleitung

Herzlichen Glückwunsch zu Ihrem Kauf des Volquartsen Loaded Chamber Indicator Filler für die Ruger MKIII. Dieser Filler wurde entwickelt, um den OriginalLadezustandsanzeiger zu ersetzen und bietet ein verbessertes Aussehen sowie eine höhere Zuverlässigkeit. Bitte lesen Sie diese Sicherheitshinweise sorgfältig durch, um sicherzustellen, dass Sie das Produkt sicher und effizient verwenden.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass das Produkt für den vorgesehenen Gebrauch geeignet ist.
- Verwenden Sie das Produkt nur in Übereinstimmung mit den Anweisungen des Herstellers.
- Halten Sie das Produkt außerhalb der Reichweite von Kindern und anderen gefährdeten Gruppen.
- Überprüfen Sie regelmäßig auf mögliche Beschädigungen oder Abnutzungen des Produkts.
- Melden Sie unsichere Produkte und Unfälle an die zuständigen Behörden.

Besondere Sicherheitsvorkehrungen für die Verwendung

- Verwenden Sie den Loaded Chamber Indicator Filler nur mit Ruger MKIII Pistolen.
- Vermeiden Sie den Kontakt mit scharfen Gegenständen, um Verletzungen zu verhindern.
- Achten Sie darauf, dass der Filler korrekt installiert ist, um Fehlfunktionen zu vermeiden.
- Verwenden Sie das Produkt nicht, wenn es sichtbare Schäden aufweist.
- Lagern Sie das Produkt an einem trockenen Ort, um Korrosion zu vermeiden.

Anweisungen zur Installation und Verwendung

1. Installation des Loaded Chamber Indicator Fillers:

- Entfernen Sie den OriginalLadezustandsanzeiger vorsichtig aus der Ruger MKIII.
- Setzen Sie den Loaded Chamber Indicator Filler in die vorgesehene Öffnung ein.
- Stellen Sie sicher, dass der Filler fest sitzt und keine Lücken aufweist.

2. Verwendung des Loaded Chamber Indicator Fillers:

- Überprüfen Sie vor jedem Gebrauch, ob der Filler korrekt installiert ist.
- Achten Sie darauf, dass der Filler nicht blockiert ist und frei von Schmutz oder Ablagerungen bleibt.
- Bei der Verwendung der Waffe immer die grundlegenden Sicherheitsregeln beachten.

Entsorgungsanweisungen

- Entsorgen Sie das Produkt gemäß den örtlichen Vorschriften für die Entsorgung von Metallabfällen.
- Stellen Sie sicher, dass keine gefährlichen Materialien in die Umwelt gelangen.
- Bei Unsicherheiten zur Entsorgung wenden Sie sich an die zuständigen Entsorgungsbehörden.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder weitere Informationen zu Ihrem Produkt wenden Sie sich bitte an den Hersteller oder den Händler, bei dem Sie das Produkt erworben haben. Es ist wichtig, dass Sie alle Sicherheitsrichtlinien befolgen, um eine sichere Verwendung zu gewährleisten.

Safety Instruction Guide for Volquartsen Loaded Chamber Indicator Filler Black MKIII

Introduction

Thank you for choosing the Volquartsen Loaded Chamber Indicator Filler for your Ruger MKIII pistol. This guide provides essential safety instructions and guidelines to ensure the safe use of the product in compliance with the EU General Product Safety Regulation (GPSR). Please read this document carefully before installation and use.

General Safety Guidelines

- Ensure that all users are familiar with the safe handling and operation of firearms.
- Always treat firearms as if they are loaded, even when you believe they are not.
- Store the Loaded Chamber Indicator Filler and your firearm in a secure location, away from children and unauthorized users.
- Regularly inspect the Loaded Chamber Indicator Filler for signs of wear or damage before each use.
- If you notice any defects or issues with the product, discontinue use immediately and seek assistance.

Specific Safety Precautions for Use

- Only use the Loaded Chamber Indicator Filler with Ruger MKIII pistols.
- Do not attempt to modify or alter the Loaded Chamber Indicator Filler in any way.
- Ensure that the firearm is completely unloaded before installing or removing the Loaded Chamber Indicator Filler.
- Do not use the firearm with the Loaded Chamber Indicator Filler installed if it is damaged or not functioning correctly.
- Always follow the manufacturer's instructions for the safe operation of your Ruger MKIII pistol.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is pointed in a safe direction.
- Confirm that the firearm is unloaded by visually and physically checking the chamber and magazine.

2. Installation:

- Remove the original load level indicator from the Ruger MKIII pistol.
- Carefully insert the Volquartsen Loaded Chamber Indicator Filler into the designated slot.
- Ensure that the filler is seated properly and securely.

3. Usage:

- Once installed, the Loaded Chamber Indicator Filler will provide a clean appearance and improved reliability.
- Regularly check the filler for proper fit and function during routine firearm inspections.

4. Removal:

- To remove the Loaded Chamber Indicator Filler, ensure the firearm is unloaded.
- Gently pull the filler from its position, taking care not to damage the firearm.

Disposal Instructions

- Dispose of the Loaded Chamber Indicator Filler in accordance with local regulations for metal waste.
- If the product is damaged or no longer usable, ensure it is disposed of in a manner that prevents accidental use.

Contact Information for Further Support

For any safety inquiries or additional support regarding the Volquartsen Loaded Chamber Indicator Filler, please refer to the manufacturer's contact details provided with your product or on their official website.

Conclusion

By following these safety instructions, you can ensure the safe and effective use of the Volquartsen Loaded Chamber Indicator Filler for your Ruger MKIII pistol. Always prioritize safety and compliance with relevant regulations to protect yourself and others. Thank you for your attention to these important guidelines.