

Lever Quick Takedown Screw - Henry Lever Quick Takedown Screw - Black Nitride - Ranger Precision Logo

Oversized, Henry lever-action quick take down screws allow for easy lever removal for a thorough cleaning, plus makes it easy to swap out standard levers for larger loop levers for gloved hands or cowboy action shooting. Replaces the original, factory lever screw without alteration.

Made of 4140 chromoly steel with a black nitride coating.

Fits Henry H009 30-30, H010 45-70, H012 Henry Big Boy Steels, H014 Long Ranger Series (.243, .308, etc), H018 .410, H024 Side Loading (.30-30 Win, .38-55 Win, .35 Rem)

Does NOT fit Henry Long Rangers, SingleShots or 22 rifles.

Oversized, Henry lever-action quick take down screws allow for easy lever removal for a thorough cleaning, plus makes it easy to swap out standard levers for larger loop levers for gloved hands or cowboy action shooting.

Replaces the original, factory lever screw without alteration.

Made of 4140 chromoly steel with a black nitride coating.

Fits Henry H009 30-30, H010 45-70, H012 Henry Big Boy Steels, H014 Long Ranger Series (.243, .308, etc), H018 .410, H024 Side Loading (.30-30 Win, .38-55 Win, .35 Rem)

Does NOT fit Henry Long Rangers, SingleShots or 22 rifles.

Attributes

- Name: Henry Lever Quick Takedown Screw - Black Nitride - Ranger Precision Logo
- Manufacturer: Ranger Point Precision
- Product no.: BRD261042
- Mfr. No.: 72
- Finish: Black Nitride
- Model: Henry
- Delivery weight: 0.5lb
- Shipping height: 150mm
- Shipping width: 200mm
- Shipping length: 25mm

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die Schnellwechselschraube für Hebel Henry](#)
- [English: Safety Instruction Guide for Henry Lever Quick Takedown Screw](#)

Sicherheitshinweise für die Schnellwechselschraube für Hebel Henry

Einführung

Vielen Dank, dass Sie sich für die Schnellwechselschraube für Hebel Henry entschieden haben. Diese Anleitung bietet wichtige Sicherheitsinformationen und Anweisungen zur Installation und Verwendung des Produkts. Bitte lesen Sie alle Informationen sorgfältig durch, um eine sichere Nutzung zu gewährleisten.

Allgemeine Sicherheitsrichtlinien

- Achten Sie darauf, dass das Produkt nur für den vorgesehenen Zweck verwendet wird.
- Halten Sie das Produkt außerhalb der Reichweite von Kindern.
- Überprüfen Sie das Produkt regelmäßig auf Beschädigungen oder Abnutzung.
- Verwenden Sie das Produkt nicht, wenn es beschädigt ist oder nicht ordnungsgemäß funktioniert.
- Befolgen Sie alle Anweisungen in dieser Anleitung, um Verletzungen oder Schäden zu vermeiden.

Spezifische Sicherheitsvorkehrungen für die Verwendung

- Verwenden Sie die Schnellwechselschraube nur in Verbindung mit kompatiblen HenryModellen (H009, H010, H012, H014, H018, H024).
- Stellen Sie sicher, dass der Hebel sicher befestigt ist, bevor Sie das Produkt verwenden.
- Tragen Sie geeignete Schutzausrüstung, insbesondere bei der Installation oder beim Umgang mit dem Produkt.
- Vermeiden Sie den Kontakt mit scharfen Kanten oder beweglichen Teilen während der Installation.

Anweisungen zur Installation und Verwendung

Installation

1. **Vorbereitung:** Stellen Sie sicher, dass die Waffe entladen ist und sich in einem sicheren Zustand befindet.
2. **Entfernen des Hebels:** Lösen Sie die originale Hebelschraube vorsichtig mit einem geeigneten Werkzeug.
3. **Einsetzen der Schnellwechselschraube:** Setzen Sie die Schnellwechselschraube in die vorgesehene Öffnung ein und ziehen Sie sie fest, ohne übermäßigen Druck auszuüben.
4. **Überprüfung:** Überprüfen Sie, ob die Schraube sicher sitzt und der Hebel korrekt befestigt ist.

Verwendung

- Verwenden Sie das Produkt nur in Verbindung mit den angegebenen HenryModellen.
- Überprüfen Sie regelmäßig den Sitz der Schraube und des Hebels, insbesondere vor und nach dem Schießen.
- Achten Sie darauf, dass der Hebel während der Benutzung nicht locker wird.

Entsorgungsanweisungen

- Entsorgen Sie das Produkt gemäß den örtlichen Vorschriften für Metallabfälle.
- Stellen Sie sicher, dass alle Teile des Produkts umweltgerecht entsorgt werden.

Kontaktinformationen für weitere Unterstützung

Für Unterstützung oder Fragen zu Sicherheitsanfragen wenden Sie sich bitte an den Hersteller oder einen autorisierten Händler.

Bitte beachten Sie, dass die Sicherheit Ihrer Nutzung von größter Bedeutung ist. Halten Sie sich an alle Anweisungen und Richtlinien, um ein sicheres und effektives Erlebnis mit Ihrer Schnellwechselschraube für Hebel Henry zu gewährleisten.

Safety Instruction Guide for Henry Lever Quick Takedown Screw

Introduction

Thank you for choosing the Henry Lever Quick Takedown Screw from Ranger Point Precision. This product is designed to enhance the functionality of your Henry leveraction rifle, allowing for easy maintenance and customization. Please read this safety instruction guide carefully to ensure safe and proper use of the product.

General Safety Guidelines

- Always ensure that the firearm is unloaded before performing any maintenance or modifications.
- Store the product in a safe place, away from children and unauthorized users.
- Regularly inspect the product for signs of wear or damage before use.
- Use only the recommended tools and techniques for installation and maintenance.
- Follow all local laws and regulations regarding firearm modifications and safety.

Specific Safety Precautions for Use

- Ensure the firearm is completely unloaded before attempting to install or remove the quick takedown screw.
- Do not attempt to modify the screw or any firearm parts beyond the manufacturer's specifications.
- Always wear appropriate safety gear, such as safety glasses, when working with firearms.
- Be cautious of the environment in which you are handling the firearm. Avoid working in crowded or confined spaces.
- If you experience any difficulty during installation or use, stop immediately and seek assistance.

Instructions for Installation and Usage

1. Preparation

- Ensure the firearm is unloaded and pointed in a safe direction.
- Gather necessary tools, including a screwdriver compatible with the screw head.

2. Installation

- Locate the original lever screw on your Henry rifle.
- Using the screwdriver, carefully remove the original lever screw.
- Take the new Henry Lever Quick Takedown Screw and align it with the screw hole.
- Gently insert the screw and tighten it securely, but do not overtighten as this may strip the threads.

3. Usage

- To remove the lever for cleaning, simply unscrew the quick takedown screw.
- For swapping levers, follow the same removal process and install the new lever using the quick takedown screw.

4. PostInstallation Check

- After installation, ensure that the lever operates smoothly and securely.
- Perform a function check by cycling the action to ensure everything is working correctly.

Disposal Instructions

- Dispose of any packaging materials in accordance with local waste management regulations.
- If the product is damaged or worn beyond use, please dispose of it responsibly, ensuring that it does not pose a safety risk to others.

Contact Information for Further Support

For any questions or concerns regarding the Henry Lever Quick Takedown Screw, please refer to the manufacturer's contact details provided with your product packaging or visit the manufacturer's website.

Important Note

This product is designed for specific Henry rifle models, including: * Henry H009 3030 * Henry H010 4570 * Henry H012 Big Boy Steels * Henry H014 Long Ranger Series (.243, .308, etc.) * Henry H018 .410 * Henry H024 Side Loading (.3030 Win, .3855 Win, .35 Rem)

Does NOT fit: * Henry Long Rangers * Single Shots * 22 rifles

Please ensure compatibility with your firearm before installation.

By following these guidelines, you can ensure a safe and effective experience with your Henry Lever Quick Takedown Screw. Thank you for your attention to safety!